

[Skip to content](#)

Manuals+

User Manuals Simplified.



makita DC64WA Battery Charger Instruction Manual

July 28, 2022 July 28, 2022 [Leave a comment on makita DC64WA Battery Charger Instruction Manual](#)

[Home](#) » [Makita](#) » makita DC64WA Battery Charger Instruction Manual 

Contents [hide](#)

[1 makita DC64WA Battery Charger Instruction Manual](#)

[2 makita DC64WA 64Vmax Battery Charger](#)

[3 WARNING](#)

[4 Symbols](#)

[5 Only EU countries](#)

[6 CAUTION](#)

[7 Charging](#)

[8 Read More About This Manual & Download PDF:](#)

[9 Documents / Resources](#)

[9.1 References](#)

[9.2 Related Manuals / Resources](#)

makita DC64WA Battery Charger Instruction Manual



makita DC64WA 64Vmax Battery Charger




Fig.1




Fig.2

WARNING

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction the concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

Symbols

The followings show the symbols which may be used for the equipment. Be sure that you understand their meaning before use.



indoor use only.



Read the instruction manual.



DOUBLE INSULATION



Do not short battery.



Do not expose the battery to water or rain.



Do not destroy the battery by fire.



Always recycle the battery.



Only EU countries

Due to the presence of hazardous components in the equipment, waste electrical and electronic equipment, accumulators and batteries may have a negative impact on the environment and human health. Do not dispose of electrical and electronic appliances or batteries with household waste!

In accordance with the European Directive on waste electrical and electronic equipment and on accumulators and batteries and waste accumulators and batteries, as well as their adaptation to national law, waste electrical equipment, batteries and accumulators should be stored separately and delivered to a separate collection point for municipal waste, operating in accordance with the regulations on environmental protection.

This is indicated by the symbol of the crossed-out wheeled bin placed on the equipment.

► Fig.1



Ready to charge



Delay charge (too hot or too cold battery).



Charging (0 – 80 %).



Charging (80 – 100 %).



Charging complete.



Defective battery.

CAUTION

1. SAVE THESE INSTRUCTIONS – This manual contains important safety and operating instructions for the battery chargers.
2. Before using a battery charger, read all instructions and cautionary markings on (1) battery charger, (2) battery, and (3) product using the battery.
3. **CAUTION** – To reduce risk of injury, charge only Makita-type rechargeable batteries. Other types of batteries may burst to cause personal injury and damage.
4. Non-rechargeable batteries cannot be charged with this battery charger.
5. Use a power source with the voltage specified on the nameplate of the charger.
6. Do not charge the battery cartridge in presence of flammable liquids or gases.
7. Do not expose charger to rain, snow, or wet condition.
8. Never carry charger by cord or yank it to disconnect from receptacle.
9. Remove the battery from the charger when carrying the charger.
10. After charging or before attempting any maintenance or cleaning, unplug the charger from the power source. Pull by plug rather than cord whenever disconnecting charger.
11. Make sure cord is located so that it will not be stepped on, tripped over, or otherwise subjected to damage or stress.
12. Do not operate the charger with a damaged cord or plug. If the cord or plug is damaged, ask Makita's authorized service center to replace it in order to avoid a hazard.
13. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
14. Do not operate or disassemble charger if it has received a sharp blow, been dropped, or otherwise damaged in any way; take it to a qualified serviceman. Incorrect use or reassembly may result in a risk of electric shock or fire.
15. Do not charge the battery cartridge when the room temperature is BELOW 10°C (50°F) or ABOVE 40°C (104°F). At the cold temperature, charging may not start.
16. Do not attempt to use a step-up transformer, an engine generator or DC power receptacle.
17. Do not allow anything to cover or clog the charger vents.
18. Do not plug or unplug the cord and insert or remove the battery with wet hands.
19. Never use gasoline, benzene, thinner, alcohol or the like to clean the charger. Discoloration, deformation or cracks may result.

Charging

1. Plug the battery charger into the proper AC voltage source. Charging lights will flash in green color repeatedly.
2. Insert the battery cartridge into the charger until it stops while aligning the guide of the charger.
3. When the battery cartridge is inserted, the charging light color will change from green to red, and charging will begin. The charging light will keep lighting up steadily during charging. One red charging light indicates charged condition in 0–80 % and the red and green ones indicate 80–100 %. The 80 % indication mentioned above is an approximate value. The indication may differ according to



battery temperature or battery condition.

4. When charging is finished, red and green charging lights will change to one green light.
After charging, remove the battery cartridge from the charger while pushing the hook. Then unplug the charger.

NOTE: If the hook does not open smoothly, clean dust around mounting parts.

► **Fig.2: 1. Hook**

NOTE: Charging time varies by temperature (10°C (50°F)–40°C (104°F)) that battery cartridge is charged at and conditions of the battery cartridge, such as a battery cartridge that is new or has not been used for a long period of time.

Voltage	Number of cells	Li-ion battery cartridge	Capacity (Ah) according to IEC61960	Charging time (Minutes)
57.6 V  64 V  (max.)	32	BL6440	4.0	120

NOTICE: The battery charger is for charging Makita battery cartridge. Never use it for other purposes or for other manufacturers' batteries.

NOTE: If the charging light flashes in red color, charging may not start due to the condition of the battery cartridge as below:

- Battery cartridge from a just-operated tool or battery cartridge that has been left in a location exposed to direct sunlight for a long time.
- Battery cartridge that has been left for a long time in a location exposed to cold air.

NOTE: When the battery cartridge is too hot, charging does not begin until the battery cartridge temperature reaches the degree at which charging is possible.

NOTE: If the charging light flashes alternately in green and red color, charging is not possible. The terminals on the charger or battery cartridge are clogged with dust or the battery cartridge is worn out or damaged.

Makita Europe N.V.

Jan-Baptist Vinkstraat 2,
3070 Kortenberg, Belgium
885921A928

Makita Corporation

3-11-8, Sumiyoshi-cho,
Anjo, Aichi 446-8502 Japan
www.makita.com

Read More About This Manual & Download PDF:

Documents / Resources



[makita DC64WA Battery Charger](#) [pdf] Instruction Manual
DC64WA, Battery Charger, DC64WA Battery Charger

References

- [MAKITA Industrial Power Tools - The Leader In Cordless with 18V LXT Lithium-Ion](#)

Related Manuals / Resources



[makita DC18WA Battery Charger Instruction Manual](#)

Makita DC18WA Battery Charger Instruction Symbols The followings show the symbols used for the equipment. Be sure that...



[makita DC64WA 64Vmax Battery Charger Instruction Manual](#)

Battery Charger Instruction Manual WARNING This appliance can be used by children aged from 8 years and above...



[makita DC18SD Battery Charger Instruction Manual](#)

makita DC18SD Battery Charger Symbols The followings show the symbols used for the equipment. Be sure that you...



[STREX SP186 Smart Battery Charger Instruction Manual](#)

STREX SP186 Smart Battery Charger SMART BATTERY CHARGER Thanks for choosing Strex! Read the manual carefully, for correct...

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

Save my name, email, and website in this browser for the next time I comment.

[Manuals+](#)

- [home](#)
- [privacy](#)