

manhattan 180771 Wireless USB Keyboard and Mouse Combo **Set Instructions**

Home » Manhattan » manhattan 180771 Wireless USB Keyboard and Mouse Combo Set Instructions 🖺





MWK7350 Wireless **USB** Keyboard and **Mouse Combo Set** Instructions Model 180771 Important: Read before use



Contents

- 1 For additional benefits:
- **2 WASTE ELECTRICAL & ELECTRONIC EQUIPMENT**
- 3 Documents / Resources
 - 3.1 References

For additional benefits:



or go to: register.manhattanproducts.com/r/180771

- 1. Take the wireless receiver located under the mouse's battery cover and plug it into an available USB port on your computer.
- 2. Insert two AAA battery into the keyboard's battery compartment
- 3. Insert one AA battery into the mouse's battery compartment.
- 4. The keyboard and mouse automatically connect to the wireless receiver.

For specifications, please visit manhattanproducts.com.

WASTE ELECTRICAL & ELECTRONIC EQUIPMENT

Disposal of Electric and Electronic Equipment (applicable in the E.U. and other countries with separate collection systems)

This symbol on the product or its packaging means that this product must not be treated as unsorted household waste. In accordance with EU Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), this electrical product must be disposed of in accordance with the user's local regulations for electrical or electronic waste. Please dispose of this product by returning it to your local point of sale or recycling pickup point in your municipality.

WARRANTY AT:

manhattanproducts.com | manhattanproducts.de/garantie (Germany only)

REGULATORY STATEMENTS

FCC Class B | FCC ID: 2ADQY-180771KB (Keyboard) / 2ADQY-180771MS (Mouse) / 2ADQY-DGL (Receiver) This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of Federal Communications Commission (FCC) Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: reorient or relocate the receiving antenna; increase the separation between the equipment and the receiver; connect the equipment to an outlet on a circuit different from the receiver; or consult the dealer or an experienced radio/TV technician for help.

The frequency band used by this product is 2402 – 2480 MHz. The maximum emitted transmission power is 0.0123 mW E.I.R.P. This device complies with the requirements of CE RED 2014/53/EU. The Declaration of Conformity for is available at:

support.manhattanproducts.com/barcode/180771











North & South America

IC Intracom Americas 550 Commerce Blvd. Oldsmar, FL 34677, USA Asia & Africa

IC Intracom Asia 4-F, No. 77, Sec. 1, Xintai 5th Rd. Xizhi Dist., New Taipei City 221, Taiwan **Europe**

IC Intracom Europe Löhbacher Str. 7 D-58553 Halver, Germany

All trademarks and trade names are the property of their respective owners. © IC Intracom. All rights reserved. Manhattan is a trademark of IC Intracom, registered in the U.S. and other countries.



Documents / Resources



manhattan 180771 Wireless USB Keyboard and Mouse Combo Set [pdf] Instructions 180771, 180771 Wireless USB Keyboard and Mouse Combo Set, Wireless USB Keyboard and Mouse Combo Set, USB Keyboard and Mouse Combo Set, Keyboard and Mouse Combo Set, Mouse Combo Set, Combo Set, Set

References

- Manhattan Products: HDMI Adapters, Cables, TV Mounts, Barcode Scanners
- Manhattan Deutschland
- Manhattan Products Account and Product Registration
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.