




[Home](#) » [Manhattan](#) » **manhattan KM-242W Wireless Keyboard Instructions** 

Contents [[hide](#)]

- [1 manhattan KM-242W Wireless Keyboard](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Connect via Bluetooth](#)
- [5 Keyboard function keys](#)
- [6 FCC Warning](#)
- [7 FAQs](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)



manhattan KM-242W Wireless Keyboard



Specifications

- Model: KM-242W
- Compliance: Part 15 of the FCC Rules
- RF Exposure: General exposure requirement met

Product Usage Instructions

Warnings and Compliance

Ensure compliance with FCC Rules Part 15 when operating the KM-242W device. Follow these guidelines:

- This device must not cause harmful interference.
- The device must accept any received interference, including that which may lead to undesired operation.
- Avoid making changes or modifications not approved by the responsible party for compliance, as this could void the user's authority to operate the equipment.

RF Exposure

The device has been evaluated to meet general RF exposure requirements. To ensure safe usage:

- Avoid prolonged exposure to RF emissions from the device.
- Maintain a safe distance between the device and your body during operation.

REGULATORY STATEMENTS

This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the Federal Communications Commission (FCC) Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: reorient or relocate the receiving antenna; increase the separation between the equipment and the receiver; connect the equipment to an outlet on a circuit different from the receiver; or consult the dealer or an experienced radio/TV technician for help.

- The frequency band used by this product is 2402 – 2480 MHz. The maximum emitted transmission power is 0.0123 mw E.I.R.P. This device complies with the requirements of CE RED 2014/53/EU. The Declaration of Conformity is available at:

- **North & South America**

IC Intracom Americas 550 Commerce Blvd. Oldsmar, FL 34677, USA

- **Asia & Africa IC Intracom Asia**

4-F, No. 77, Sec. 1, Xintai 5th Rd. Xizhi Dist., New Taipei City 221, Taiwan

- **Europe IC Intracom Europe**

Löhbacher Str. 7 D-58553 Halver, Germany

All trademarks and trade names are the property of their respective owners. © IC Intracom. All rights reserved. Manhattan is a trademark of IC Intracom, registered in the U.S. and other countries. intad an rarurlad nanar Connecting via 2.4 GHz Receiver:

1. Insert the receiver

- Remove the wireless receiver located under the mouse's battery cover

- Plug the receiver into an available USB port on your computer.

2. Power the keyboard

- Insert two AAA batteries into the keyboard's battery compartment.
- Press the 2.4G button to switch to 2.4G mode (the indicator light with turn red).

3. Power the mouse

- Insert one AA battery into the mouse's battery compartment.
- Press the switch button at the bottom of the mouse to switch to 2.4G mode (the indicator light with turn white).

Connect via Bluetooth

Pair the keyboard

- Press and hold the BT1/BT2 button for 3 seconds until the corresponding indicator light (green /blue) flashes quickly.
- Select MH-Keyboard from the Bluetooth device list.
- Press the button to switch between devices.

Pair the mouse

- Press the button at the bottom of the mouse until the corresponding light (green for BT1, blue for BT2) flashes.
- Press and hold the button for 3 seconds until the light flashes quickly
- Select MH-Mouse from the Bluetooth device list.

Keyboard function keys

Function		Description
Fn +	F1	Mute
	F2	Volume Down
	F3	Volume Up
	F4	Previous Track
	F5	Play / Pause
	F6	Next Track
	F7	Brightness Down
	F8	Brightness Up
	F9	Select All
Fn +	F10	Copy
	F11	Paste
	F12	Cut
	Esc	Switch between Fn+ / single press
2.4G (red) BT 1 (green) BT 2 (blue)		Switch between devices
Win/Mac		Switch layout mode for OS

manhattanproducts.com

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
 2. This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- **NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee

that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help
 - **NOTE:** This device and its antenna(s) must not be co-located or operate in conjunction with any other antenna or transmitter. The device has been evaluated to meet the general RF exposure requirements.

FAQS


Q: What should I do if the device is causing interference?

A: If the device is causing interference, try repositioning it or moving it away from other electronic devices. If the issue persists, contact customer support for further assistance.

Q: Can I modify the device for better performance?

A: No, any modifications not approved by the responsible party for compliance can void your authority to operate the equipment. For performance-related concerns, contact customer support.

Documents / Resources



[manhattan KM-242W Wireless Keyboard \[pdf\]](#) Instructions

180580KB, 2ADQY-180580KB, 2ADQY180580KB, KM-242W Wireless Keyboard, KM-242W, Wireless Keyboard, Keyboard

References

- [User Manual](#)

Manhattan

180580KB, 2ADQY-180580KB, 2ADQY180580KB, Keyboard, KM-242W, KM-242W Wireless Keyboard, Manhattan, Wireless Keyboard

—Previous Post

manhattan M7034 Wireless Mouse Instructions

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.