

matata studio VinciBot Coding Toy



## matata studio VinciBot Coding Toy User Guide

[Home](#) » [matata studio](#) » matata studio VinciBot Coding Toy User Guide 

### Contents

- [1 matata studio VinciBot Coding Toy](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Frequently Asked Questions](#)
- [5 PRODUCT IDENTIFICATION](#)
- [6 Safety instructions](#)
- [7 FCC Caution](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)
- [9 Related Posts](#)

matata  
studio

matata studio VinciBot Coding Toy



## Product Information

### Specifications

- Compliance: Part 15 of FCC Rules
- RF Exposure: General exposure requirements met
- Usage: Portable exposure condition without restriction

### Product Usage Instructions

#### Safety Guidelines

Before using the device, please read the safety guidelines in the user manual to ensure safe operation.

#### Power On/Off

To power on the device, press and hold the power button for 3 seconds. To power off, repeat the same process.

#### Charging

Connect the device to a power source using the provided charger. Allow sufficient time for a full charge before first use.

#### Functionality

Explore the various functions of the device by referring to the user manual. Familiarize yourself with the features for optimal usage.

### Frequently Asked Questions


**Q: Is the device safe for use in all environments?**

A: Yes, the device can be used in portable exposure conditions without any restrictions.

**Q: How do I reset the device?**

A: To reset the device, locate the reset button on the back and press it with a small pin for 5 seconds.

**PRODUCT IDENTIFICATION**



1. Fill light 1
2. Camera
3. Fill light 2
4. 1.5-inch Full-color LCD screen (Resolution: 240\*240)
5. Right selection button
6. Left selection button
7. Enter button
8. Extended USB-C communication interface
9. Learning button
10. USB-C firmware burning interface

Before using, please log in to the official website to upgrade VinciBot to the latest firmware version. Camera usage instructions and examples, please log in to VinciBot's programming official website tutorial and help center to view.

**Safety instructions**

- This product is not intended for use by children under the age of three
- This product shotony based with transformer. Keepit out ofthe reach of children.
- Do not use or charge the product in temperatures outside its operating range.
- If this product is not to be used for a long period of time, fully charge it before storage and recharge it at least once every three months.
- Use only a recommended power adapter (5V/2A) to charge the product.

- Regularly check whether the cable, plug, shell or other components are damaged. If damaged, stop using immediately.

## WARNING

CHOKING HAZARD-smell ports. Not for children under 3 years.

This user Guide contains important information, please keep it!

<https://vinci.matatastudio.com>

## FCC Caution


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

## Documents / Resources

	<p><a href="#">matata studio VinciBot Coding Toy</a> [pdf] User Guide 2APCM-VISION1, 2APCMVISION1, vision1, VinciBot Coding Toy, VinciBot, VinciBot Toy, Coding Toy, Toy</p>
---	--

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.