



Home » MAX sensor » MAX sensor MX0054 TPMS Sensor Instruction Manual 📆

Contents [hide]

- 1 MAX sensor MX0054 TPMS Sensor
- 2 Instructions Manual
- 3 Installation
- **4 LIMITED WARRANTY**
- 5 FCC Statement
- 6 Documents / Resources
 - 6.1 References



MAX sensor MX0054 TPMS Sensor



Instructions Manual

- 1. Screw
- 2. Senso

- 3. Valve Stem
- 4. Nut
- 5. Valve Cap



CAUTION:

- The MAX assemblies are replacements or maintenance parts for vehicles that have factory installed TPMS.
- Make sure to program sensor by using the MAX program ming tool for your specific vehicle make, model and year prior to installation.
- In order to guarantee optimal function, the sensor may only be installed with valves and accessories by MAX.
- Upon completion of installation, test the vehicles TPMS system using procedures described in the original manufacturer's user guide to confirm proper installation and functionality.

Installation

- 1. Remove the valve nut.
- 2. Pass the valve through the rim hole, and mount the nut, use a torque wrench with 4 Nm. Make sure the valve is seated correctly.
- 3. Mount the tire, please make sure that the sensor is not damaged during mounting.
- 4. Remove the valve cap and inflate the tire to the correct tire pressure according to the vehicle specification. Screw the valve cap back on.







Please note the vehicle manufacturer-specific learning method, which you can find in the vehicle manual or in our MAX Sensor programming device.

LIMITED WARRANTY

MAX warrants to the original purchaser that the TPMS sensor complies with MAX product specifications and shall be free from defects in material and workmanship under normal and intended use for a period of sixty (60) months or fifty thousand (50,000)miles, whichever occurs first, from the date of purchase. The warranty shall be void if any of the following should occur:

- 1. Improper or incomplete installation of products.
- 2. Improper usage.
- 3. Introduction of defects by other products.
- 4. Mishandling of products and/or any modifications to the products.
- 5. Incorrect application.
- 6. Damage due to collision or tire failure.
- 7. Racing or competition.

MAX's sole and exclusive obligation under this warranty will be to repair or replace, at MAX's discretion, without charge. Any merchandise that does not conform to this above warranty should be returned with a copy of the original sales receipt to the dealer from whom the product was originally purchased. Notwithstanding the foregoing, in the event that the product is no longer available, MAX's liability to the original purchaser shall not exceed the actual amount paid for the products.

OTHER THAN AS EXPRESSLY STATED HEREIN, MAX GIVES NO WARRANTIES HEREUNDER ON THE MAX AND HEREBY EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, AND/OR NONINFRINGEMENT. IN NO EVENT WILL MAX BE LIABLE TO ANY PURCHASER

ARISING OUT OF ANY CLAIM, DEMAND, SUIT, ACTION, ALLEGATION, OR ANY OTHER PROCEEDING INVOLVING MAX THAT HAVE BEEN ALTERED OR REPAIRED OTHER THAN BY MAX OR AN AUTHORIZED DEALER OR INSTALLED ON CUSTOMIZED VEHICLES (I.E., NON-OEM VEHICLES) OR FOR INCIDENTAL AND CONSEQUENTIAL DAMAGES (e.g., loss of time, loss of use of vehicle, towing charges, road services, and inconveniences).

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be detennined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Documents / Resources



MAX sensor MX0054 TPMS Sensor [pdf] Instruction Manual 2BC6S-GEN5N, 2BC6SGEN5N, MX0054 TPMS Sensor, MX0054, TPMS Sensor, Sensor

References

- User Manual
 - 2BC6S-GEN5N, 2BC6SGEN5N, MAX sensor, MX0054, MX0054 TPMS Sensor, Sensor, TPMS
- MAX sensor Sensor

Email

Leave a comment

Your email address will not be published. Required fields are marked*

Comment *

Name

Website	
☐ Save my name, email, and website in this browser for the next time I comment.	
Post Comment	

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.