

MAYFAIR TR.COM V1.2 29.04.2015 Chrome Heated Towel Rail Radiator Instruction Manual

<u>Home</u> » <u>MAYFAIR</u> » MAYFAIR TR.COM V1.2 29.04.2015 Chrome Heated Towel Rail Radiator Instruction Manual



Contents

- 1 MAYFAIR TR.COM V1.2 29.04.2015 Chrome Heated Towel Rail Radiator
- **2 Product Information**
- **3 Product Usage Instructions**
- **4 TOOLS REQUIRED (NOT SUPPLIED)**
- **5 SAFETY**
- 6 Care & Maintenance
- 7 Documents / Resources
 - 7.1 References

MAYFAIR

MAYFAIR TR.COM V1.2 29.04.2015 Chrome Heated Towel Rail Radiator



Product Information

The Mayfair/Soho Towel Rail is a wall-mounted radiator designed to warm towels. It comes with a 10-year guarantee and is manufactured in accordance with British and European Standards. The radiator is not included and is shown for illustration purposes only.

Safety precautions should be followed during installation. It is recommended to hire a qualified professional or a fully competent person to install the towel rail. The relevant British and European Standards (BS7593:2006, EN12828:2012+A1;2014, EN12831:2003 & EN14336:2004) should be followed. Before drilling walls, it is important to check for hidden pipes and cables. Personal protective equipment, including safety eyewear, should be worn during installation. The product should be handled with care, and small parts should be kept away from children. Before starting the installation, ensure that all components are present and that you are satisfied with the size, design, and finish of the towel rail.

Please note that any damage or faults should be immediately reported to the retailer. The manufacturer cannot be held responsible for any installation costs resulting from the installation of a damaged or faulty product.

Product Usage Instructions

- 1. Gently remove the radiator from its packaging.
- 2. Apply sufficient PTFE tape to the valve-tail threads before installation. Use silicone thread sealant on threaded components with O-rings.
- 3. Screw the air vent into the hole on the top of the radiator.
- 4. Ensure that the selected wall is strong enough to support the weight of the towel rail when filled with water.
- 5. Note that the wall plugs and screws provided are suitable for masonry walls. Different fixings may be required for other wall types.
- 6. Before drilling, ensure that there are no hidden pipes or wires in the wall.
- 7. Using the radiator and a spirit level, mark the position of the brackets on the wall.
- 8. Mark the centers of the brackets on the wall and drill four suitable holes. Insert wall plugs.
- 9. Screw the round external brackets into the wall plugs using the provided wall screws.
- 10. Screw the round internal bracket to the front cover plate. These two parts connect through the radiator horizontal bar.
- 11. Mount the radiator onto the wall by sliding the internal brackets on the radiator into the external brackets on the wall
- 12. Secure the radiator in position by tightening the grub screws into the holes on the side of the external brackets using the hexagonal key.

TOOLS REQUIRED (NOT SUPPLIED)

- · Drill & Drill Bit
- · Residual Current Device (recommended)
- Pozi Drive Screwdriver / Flathead Screwdriver
- PTFE Tape
- Measuring Tape
- Spirit Level
- Pencil


SAFETY

- Installation should be carried out by a qualified professional or other fully competent person and should be installed in accordance with the relevant British and European Standards (BS7593:2006, EN12828:2012+A1;2014, EN12831:2003 & EN14336:2004).
- When drilling walls, check first for hidden pipes and/or cables.
- Please ensure that you wear all necessary personal protective equipment for your safety. Use safety eyewear when drilling.
- · Handle the product with care.
- · Keep small parts away from children.
- Please check that all components are present and that you are entirely happy with the size, design and finish before starting installation.

DISCLAIMER

Please notify the retailer immediately of any damage or faults. The manufacturer cannot be held responsible for any installation costs that may arise from damaged or faulty product being installed.

List of additional parts supplied





Fixing Tips:

- A piece of insulating tape or a couple of layers of masking tape applied to the wall before drilling will help stop the drill from wandering, particularly on tiled surfaces.
- Exercise great care when using power tools near water. The use of a Residual Current Device (RCD) or Cordless Drill is recommended.
- Always double check the position and your measurements before drilling holes.

• When working near a basin or bath, insert the plug into the waste. This could help you avoid losing small parts.

Fitting the Radiator onto the wall.

- Gently remove the radiator from all packaging. Sufficient PTFE tape must be applied to valve-tail threads prior to their installation. Silicone thread sealant should be applied to all threaded components manufactured with 'O-rings'.
- 2. Screw the air vent into the one hole on the top of the radiator.
- 3. Ensure the selected wall is sufficiently strong enough to hold the weight of the towel warmer filled with water.
- 4. **NOTE**: Wall plugs and screws supplied are intended for masonry walls. Alternative fixings may be required dependent on wall type.
- 5. Before drilling, please make sure there are no hidden pipes or wires in the wall.
- 6. Using the radiator and a spirit level, mark the position of the brackets.
- 7. Mark the centres of the brackets on the wall. Drill four suitable holes and insert wall plugs.
- 8. Screw the round external brackets into the wall plugs using the wall screws.
- 9. Screw the round internal bracket to the front cover plate. These two parts connect through the radiator horizontal bar.
- 10. Mount the radiator onto the wall by sliding the internal brackets on the radiator into the external brackets on the wall. Secure the radiator into position by tightening the grub screws into the holes on the side of the external brackets using the hexagonal key.

Make the necessary connections to the heating circuit. Finally, remove any trapped air from the radiator using the air vent. This step may need to be repeated to ensure all air is removed.

Care & Maintenance

- Regular cleaning with a soft cloth will keep the surface of your Designer Radiator looking new. Soapy water can be used to remove stubborn stains, then buff dry with a soft cloth.
- Do not use abrasive or chemical cleaners to clean your radiator as these will damage the surface finish over time.
- We have taken great care to ensure that this product reached you in perfect condition. However, should any parts be damaged or missing, please contact your point of purchase. This does not affect your statutory rights. In addition, if you require any replacement parts, your point of purchase will be happy to assist.

TR.COM V1.2 29.04.2015

Documents / Resources



MAYFAIR TR.COM V1.2 29.04.2015 Chrome Heated Towel Rail Radiator [pdf] Instruction Ma

TR.COM V1.2 29.04.2015 Chrome Heated Towel Rail Radiator, TR.COM V1.2 29.04.2015, Chrome Heated Towel Rail Radiator, Heated Towel Rail Radiator, Towel Rail Radiator, Rail Radiator, Radiator

References

• G Redirect Notice

Manuals+,