

# **MEAN WELL RSP-2000 series Switching Power Supply Owner's Manual**

Home » MEAN WELL » MEAN WELL RSP-2000 series Switching Power Supply Owner's Manual



#### Contents

- 1 MEAN WELL RSP-2000 series Switching Power
- **2 Product Usage Instructions**
- 3 Features
- **4 SPECIFICATION**
- **5 Function Manual**
- **6 Mechanical Specification**
- 7 Documents / Resources
  - 7.1 References
- **8 Related Posts**



MEAN WELL RSP-2000 series Switching Power Supply



### **Specifications**

• Model: RSP-2000-12 / RSP-2000-24 / RSP-2000-48

• DC Voltage: 12V / 24V / 48V

Rated Power: 1200W / 1920W / 2016W

• Efficiency: 87% typical

• Input Voltage Range: 90 ~ 264VAC

• Output Ripple & Noise: 150mVp-p max.

• Power Factor: 0.97 typical at full load

• Dimensions: 295 x 127 x 41mm (L x W x H)

## **Product Usage Instructions**

#### Installation

- 1. Ensure input power is within the specified voltage range (90 ~ 264VAC).
- 2. Connect the output terminals to your device following the correct polarity.
- 3. Securely mount the power supply in a well-ventilated area using appropriate mounting hardware.

### Operation

- 1. Apply AC power to the unit within the specified voltage range.
- 2. If required, program the output voltage within the adjustable range.
- 3. Monitor the device for any abnormal behavior or alarm signals.

#### **Maintenance**

- 1. Regularly inspect the power supply for dust and debris accumulation.
- 2. Ensure proper airflow around the unit for efficient cooling.

3. Refer to the user manual for troubleshooting steps in case of issues.

#### **FAQ**

Q: What are the main protections provided by the power supply?

A: The power supply offers protections against short circuit, overload, over voltage, and over temperature conditions.

• Q: What are the typical applications of the RSP-2000 series power supply?

A: The power supply is commonly used in factory control, test and measurement instruments, laser machines, burn-in facilities, digital broadcasting, and RF applications.

2000W Power Supply with Single Output























## **Features**


- Universal AC input / Full range
- · Built-in active PFC function
- High efficiency up to 92%
- Forced air cooling by built-in DC fan
- · Output voltage programmable
- Active current sharing up to 8000W (3+1)
- Built-in remote ON-OFF control / remote sense / auxiliary power / DC OK signal / OTP alarm signal
- Protections: Short circuit / Overload / Over voltage / Over temperature
- Optional conformal coating
- 5 years warranty

#### **Applications**

- Factory control or automation apparatus
- Test and measurement instrument
- · Laser related machine
- · Burn-in facility
- · Digital broadcasting
- · RF application
- GTIN CODE MW Search: <a href="https://www.meanwell.com/serviceGTIN.aspx">https://www.meanwell.com/serviceGTIN.aspx</a>

#### **Description**

RSP-2000 is a 2KW single output enclosed type AC/DC power supply with 1U low profile. This series operates for 90~264VAC input voltage and offers the models with the DC output mostly demanded from the industry. Each model is cooled by the built-in fan with fan speed control, working for the temperature up to 70°C. Moreover, RSP-2000 provides vast design flexibility by equipping various built-in functions such as the output programming, active current sharing, remote ON-OFF control, auxiliary power, etc.



## **SPECIFICATION**

MODEL	-	RSP-2000-12	RSP-2000-24	RSP-2000-48		
	DC VOLTAGE	12V	24V	48V		
	RATED CURREN T	100A	80A	42A		
	CURRENT RANG E	0 ~ 100A	0 ~ 80A	0 ~ 42A		
	RATED POWER	1200W	1920W	2016W		
	RIPPLE & NOISE (max.) Note.2	150mVp-p	200mVp-p	300mVp-p		
	VOLTAGE ADJ. R ANGE	10.5 ~ 14V	21 ~ 28V	42 ~ 56V		
	VOLTAGE TOLER ANCE Note.3	±2.0%	±1.0%	±1.0%		
OUTP	LINE REGULATI ON	±1.0%	±0.5%	±0.5%		
	LOAD REGULATI ON	±1.0%	±0.5%	±0.5%		
	SETUP, RISE TIM E	1500ms, 60ms/230VAC at full load				
	HOLD UP TIME ( Typ.)	16ms/230VAC at 75% load 10ms/230VAC at full load				
VOLTAGE RANG E 90 ~ 264VAC 250 ~ 320VDC Note.4,5						
	FREQUENCY RA	47 ~ 63Hz				
	POWER FACTOR (Typ.)	0.97/230VAC at full load				

	EFFICIENCY (Ty p.)	87%	90.5%	92%				
INPU T	AC CURRENT (Ty p.) Note.4	13A/115VAC 7A/230 VAC	16A/115VAC 10A/23 0VAC	16A/115VAC 10A/23 0VAC				
	INRUSH CURRE NT (Typ.)	COLD START 50A						
	LEAKAGE CURR ENT	<2mA / 240VAC						
		105 ~ 125% rated output p	ower					
	OVERLOAD	Protection type : Constant ec. re-power on to recover	current limiting, unit will shut	down o/p voltage after 5 s				
		14.7 ~ 17.5V	29.5 ~ 35V	57.6 ~ 67.2V				
PROT ECTI ON	OVER VOLTAGE	Protection type : Shut down o/p voltage, re-power on to recover						
	OVER TEMPERA TURE	Shut down o/p voltage, recovers automatically after temperature goes down						
	OUTPUT VOLTA GE PROGRAMM ABLE(PV)	Adjustment of output voltage is allowable to 40 ~ 115% of nominal output voltage. Please refer to the Function Manual.						
	CURRENT SHAR	Up to 8000W or (3+1) units. Please refer to the Function Manual.						
	AUXILIARY POW ER	5V @ 0.3A, 12V @ 0.8A						
FUNC TION	REMOTE ON-OF F CONTROL	By electrical signal or dry contact Power ON:open Power OFF:short. Please refer t o the Function Manual.						
	REMOTE SENSE	Compensate voltage drop on the load wiring up to 0.5V. Please refer to the Functi on Manual.						
	DC OK SIGNAL	The isolated TTL signal out. Please refer to the Function Manual.						
	WORKING TEMP.	-35 ~ +70°C (Refer to "Der	ating Curve")					
	WORKING HUMI DITY	20 ~ 90% RH non-condens	sing					
ENVI	STORAGE TEMP. , HUMIDITY	-40 ~ +85℃, 10 ~ 95% RF	I non-condensing					
RON MENT	TEMP. COEFFICI ENT	±0.03%/°C (0 ~ 50°C)						
	VIBRATION	10 ~ 500Hz, 2G 10min./1c	ycle, 60min. each along X, Y	, Z axes				


WITHSTAND VO LTAGE	I/P-O/P-3KVAC I/P-EG-2KV						
	I/P-O/P:3KVAC I/P-FG:2KVAC O/P-FG:0.5KVAC						
ISOLATION RESI STANCE	I/P-O/P, I/P-FG, O/P-FG:100M Ohms / 500VDC / 25°C/ 70% RH						
	Parameter	Standard	Test Level / Note				
	Conducted	BS EN/EN55032 (CISPR 32)	Class B				
EMC EMISSION	Radiated	BS EN/EN55032 (CISPR 32)	Class A				
	Harmonic Current	BS EN/EN61000-3-2	_				
	Voltage Flicker	BS EN/EN61000-3-3	_				
	BS EN/EN55035, BS EN/EN61000-6-2, BSMI CNS13438						
	Parameter	Standard	Test Level / Note				
	ESD	BS EN/EN61000-4-2	Level 3, 8KV air ; Level 2, 4KV contact				
	Radiated	BS EN/EN61000-4-3	Level 3				
	EFT / Burst	BS EN/EN61000-4-4	Level 3				
	Surge	BS EN/EN61000-4-5	Level 4, 4KV/Line-Earth; Level 3, 2KV/Line-Line				
	Conducted	BS EN/EN61000-4-6	Level 3				
EMC IMMUNITY	Magnetic Field	BS EN/EN61000-4-8	Level 4				
	Voltage Dips and Interrup tions	BS EN/EN61000-4-11	>95% dip 0.5 periods, 30 % dip 25 periods, >95% interruptions 250 p eriods				
MTBF	487.7K hrs min. Telcordia SR-332 (Bellcore) ; 42.9K hrs min. MIL-HDBK-7F (25°C)						
DIMENSION	295*127*41mm (L*W*H)						
PACKING	1.95Kg; 6pcs/12.7Kg/1.15CUFT						
	EMC IMMUNITY  MTBF  DIMENSION	Conducted  Radiated  Harmonic Current  Voltage Flicker  BS EN/EN55035, BS EN/E  Parameter  ESD  Radiated  EFT / Burst  Surge  Conducted  Magnetic Field  Voltage Dips and Interruptions  MTBF  487.7K hrs min. Telcord 7F (25°C)  DIMENSION  295*127*41mm (L*W*H)	Conducted   BS EN/EN55032 (CISPR 32)				

- 1. All parameters NOT specially mentioned are measured at 230VAC input, rated load and 25°C of am bient temperature.
- 2. Ripple & noise are measured at 20MHz of bandwidth by using a 12" twisted pair-wire terminated wit h a 0.1uf & 47uf parallel capacitor.
- 3. Tolerance: includes set up tolerance, line regulation and load regulation.
- 4. Derating may be needed under low input voltages. Please check the derating curve for more details.
- 5. Please contact MEANWELL for 320~370VDC application.


#### **NOTE**

- 6. The power supply is considered a component which will be installed into a final equipment. All the E MC tests are been executed by mounting the unit on a 720mm\*360mm metal plate with 1mm of th ickness. The final equipment must be re-confirmed that it still meets EMC directives. For guidance on how to perform these EMC tests, please refer to "EMI testing of component power supplies." (as a vailable on <a href="https://www.meanwell.com//Upload/PDF/EMI">https://www.meanwell.com//Upload/PDF/EMI</a> statement en.pdf)
- 7. The ambient temperature derating of 3.5°C/1000m with fanless models and of 5°C/1000m with fan models for operating altitude higher than 2000m(6500ft).
- \* Product Liability Disclaimer For detailed information, please refer to <a href="https://www.meanwell.com/serviceDisclaimer.aspx">https://www.meanwell.com/serviceDisclaimer.aspx</a>


### **Block Diagram**



**Static Characteristics** 




INPUT MODEL	12V	24V	48V
180~264VAC	1200W	1920W	2016W
	100A	80A	42A
115VAC	1080W	1632W	1713.6W
	90A	68A	35.7A
100VAC	1020W	1440W	1512W
	85A	60A	31.5A
90VAC	960W	1248W	1310.4W
	80A	52A	27.3A



## **Function Manual**


#### 1. Remote Sense

The Remote Sense compensates voltage drop on the load wiring up to 0.5V




- $\bigcirc$  The +S signal should be connected to the positive terminal of the load whereas -S signal to the negative terminal.
- Output Voltage Programming (or, PV / remote voltage programming / remote adjust / margin programming / dynamic voltage trim)

In addition to the adjustment via the built-in potentiometer, the output voltage can be trimmed to  $40\sim115\%$  of the nominal voltage by applying EXTERNAL VOLTAGE.




©+S & +V, -S & -V also need to be connected on CN501.



#### 3. Remote ON-OFF Control

The power supply can be turned ON/OFF individually or along with other units by using the "Remote ON-OFF" function.




#### 4. Current Sharing with Remote Sense

RSP-2000 has the built-in active current sharing function and can be connected in parallel, up to 4 units, to provide higher output power as exhibited below:

- The power supplies should be paralleled using short and large diameter wiring and then connected to the load.
- Difference of output voltages among parallel units should be less than 0.2V.
- The total output current must not exceed the value determined by the following equation:
   Maximum output current at parallel operation=(Rated current per unit) (Number of unit)××0.9
- Under parallel operation, the minimum output load should be greater than 5% of total output load;
   otherwise, it is likely that only one unit operates whereas other units may enter standby mode or their
   LED status indicators may not turn on.
- When the total output current is less than 5% of the total rated current, or say (5% of Rated current per unit)×(Number of unit) the current shared among units may not be fully balanced.
- CN502/CN504 Function pin connection


	PSU1		PSU2		PSU3		PSU4	
Parallel	CN502	CN504	CN502	CN504	CN502	CN504	CN502	CN504
1 unit	X	V						I
2 unit	V	V	V	V	I	I	I	
3 unit	V	V	V	x	V	V	I	I
4 unit	V	V	V	Х	V	Х	V	V

V is CN502/CN504 connected to plug pin, X is CN502/CN504 not connected to plug pin.




 $\hfill \bigcirc$  DA,DB and GND are connected mutually in parallel.

## **Mechanical Specification**




Hole No	Recommended Screw Si ze	MAX. Penetration Depth <b>L</b>	Recommended mounting torque
1	M4	6mm	7~10Kgf-cm
2	M4	4mm	7~10Kgf-cm



Control Pin No. Assignment (CN501): HRS DF11-12DP-2DS or equivalent

Mating Housing	HRS DF11-12DS or equivalent
Terminal	HRS DF11-**SC or equivalent



Pin No	Functi on	Description
1	+S	Positive sensing for remote sense.
2	-S	Negative sensing for remote sense.
3	PV	Connection for output voltage programming. (Note.1)
4	GND	This pin connect to the negative terminal(-V).
		High (4.5 ~ 5.5V) : When the Vout ≦80%±6%. Low (0 ~ 0.5V) : When Vout ≧80%±6%.
5	DC-OK	The maximum sourcing current is 10mA and only for output. (Note.2)
	T-	High (4.5 $\sim$ 5.5V) : When the internal temperature (TSW1 or TSW2 open) exceeds the limit o f temperature alarm.
6	ALARM	Low (0 $\sim$ 0.5V): When the internal temperature (TSW1 or TSW2 short) under the limit tempe rature. The maximum sourcing current is 10mA and only for output. (Note.2)
7	Remote ON-OF F	The unit can turn the output on and off by electrical signal or dry contact between Remote $O$ <i>N-OFF</i> and $+5V$ - $AUX$ . (Note.2) Short (4.5 $\sim$ 5.5V) : Power OFF ; Open (0 $\sim$ 0.5V) : Power ON ; The maximum input voltage is 5.5V.
	GND-A	Auxiliary voltage output GND.
8,9,10	UX	The signal return is isolated from the output terminals (+V & -V).
		Auxiliary voltage output, 4.5~5.5V, referenced to GND-AUX.
11	+5V-AU X	The maximum load current is 0.3A. This output has the built-in "Oring diodes" and is not controlled by the Remote ON-OFF control.
		Auxiliary voltage output, 10.6~13.2V, referenced to GND-AUX.
12	+12V-A UX	The maximum load current is 0.8A. This output has the built-in "Oring diodes" and is not controlled by the Remote ON-OFF control.

**Note1:** Non-isolated signal, referenced to the output terminals (-V).


Note 2: Isolated signal, referenced to GND-AUX.

## LED Indicators & Corresponding Signal at Function Pins

Function	LED	Description	* Signal	Power Supply Output
DC-OK	GREEN	When output voltage $\geq$ 80% $\pm$ 5% of Vo rated.	0 ~ 0.5V	ON
DC-NG	RED	When output voltage $\leq$ 80% $\pm$ 5% of Vo rated.	4.5 ~ 5.5V	ON
T-OK	GREEN	When the internal temperature (TSW1 & TSW2 short) is within safe limit	0 ~ 0.5V	ON
T-ALARM	RED	When the internal temperature (TSW1 or TSW2 open) exceeds the limit of temperature alarm	4.5 ~ 5.5V	OFF

Signal between function pin and "GND-AUX".

Control Pin No. Assignment (CN502): HRS DF11-6DP-2DSA or equivalent



Mating Housing	HRS DF11-6DS or equivalent
Terminal	HRS DF11-**SC or equivalent

Pin No	Functi on	Description
1,2	DA	Differential digital signal for parallel control.
3,4	DB	Differential digital signal for parallel control.
5,6	GND	These pins connect to the negative terminal (-V).

## Control Pin No. Assignment (CN504):

Pin No	Functi on	Description
1,2	Termin al resist ance	CN504 is the selector of terminal resistor that is designed for DA/DB signals and parallel con trol function.

## **AC Input Terminal Pin No. Assignment**

Pin No.	Assignment	Diagram		Maximum mounting torque
1	AC/N			
2	AC/L			18Kgf-cm
3	FG ±			

## DC Output Terminal Pin No. Assignment

Assignment	Diagram	Maximum mounting torque
+V, -V		10Kgf-cm

## **Installation Manual**

Please refer to : <a href="http://www.meanwell.com/manual.html">http://www.meanwell.com/manual.html</a>

Downloaded from Arrow.com.

## **Documents / Resources**



MEAN WELL RSP-2000 series Switching Power Supply [pdf] Owner's Manual RSP-2000-12, RSP-2000-24, RSP-2000-48, RSP-2000 series Switching Power Supply, RSP-20 00 series, Switching Power Supply, Power Supply, Supply

#### References

- △ TÜV Rheinland Home | US | TÜV Rheinland
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.