

MeLaSen Electronics MLSK17L Remote Control User Manual


Home » MeLaSen Electronics » MeLaSen Electronics MLSK17L Remote Control User Manual

Contents

- 1 MeLaSen Electronics MLSK17L Remote Control
- **2 Product Information**
- **3 Product Usage Instructions**
- **4 PRODUCT OVERVIEW**
- **5 FCC Statements**
- **6 Frequently Asked Questions**
- 7 Documents / Resources
 - 7.1 References

melasen

MeLaSen Electronics MLSK17L Remote Control



Product Information

Specifications

• Model: MLSK17L

• Power Source: 2 x 1.5V AAA batteries

• Regulatory Compliance: FCC and IC standards

Product Usage Instructions

Battery Installation


Install 2 x 1.5V AAA batteries into the remote control. Ensure correct polarity.

Note: To prevent damage to the remote control, remove the batteries if the remote control will not be used for an extended period.

FCC Warning Statements:

This device complies with FCC regulations regarding electromagnetic interference. To maintain compliance, do not modify the device without authorization.

PRODUCT OVERVIEW



- Install 2 x1.5V AAA batteries.
- To prevent damage to the remote control, remove the battery if it has not been used for a long time.

FCC Statements

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IC Warning Statements

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic

Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

- 1. This device may not cause interference.
- 2. This device must accept any interference, including interference that may cause undesired operation of the device.

Frequently Asked Questions

- Q: How do I know when to replace the batteries?
 - **A:** When the remote control becomes unresponsive or has a reduced range, it is advisable to replace the batteries with new ones.
- Q: Can I use rechargeable batteries with this remote control?
 - A: Yes, you can use rechargeable AAA batteries with this remote control. Ensure they are fully charged before usage.

Documents / Resources



MeLaSen Electronics MLSK17L Remote Control [pdf] User Manual 2AYGE-MLSK17L, 2AYGEMLSK17L, mlsk17l, MLSK17L Remote Control, MLSK17L, Remote Control, Control

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.