

# MERCKU M6a Mesh WiFi 6 Router User Guide

Home » MERCKU M6a Mesh WiFi 6 Router User Guide 🖔




# Contents

- 1 Quickstart Guide
  - 1.1 Thank you for choosing Mercku
  - 1.2 Set-up in 3 steps:
    - 1.2.1 1. Connect provided power and WAN cables to the
    - 1.2.2 2. Connect to Wi-Fi
    - 1.2.3 3. Open browser or app
  - 1.3 Expand your Wi-Fi coverage
    - 1.3.1 Quick tips
    - 1.3.2 FCC ID: XXXXX-XX
    - 1.3.3 LED indicator color
- 2 Documents / Resources
- **3 Related Posts**

**Quickstart Guide** 

Thank you for choosing Mercku



Port configuration


- 1. RESET
- 2. CONNECT
- 3. LAN
- 4. WAN
- 5. POWER

# Set-up in 3 steps:

1. Connect provided power and WAN cables to the M6a


Red light indicates that there is power.

When the device has an internet connection, the light will turn white.



#### 2. Connect to Wi-Fi

Use your mobile device or computer to search for and connect to the open **MERCKU-XXXX** Wi-Fi network.



- \* MERCKU-XXXX Please locate this SSID on the bottom label.
- 3. Open browser or app

Visit <u>mywifi.mercku.tech</u> through a web browser to complete setup.

Or scan the **QR code** below to download the Mercku app and complete setup, plus manage your network.








#### **Expand your Wi-Fi coverage**

After setting up the M6a router, you can expand your wireless coverage by adding additional M6a devices as nodes to form a larger mesh network Note: Does not support adding nodes in batches.

### **Quick tips**

M6a performance is optimal when nodes are no more than two rooms apart from each other or the main M6a router.



## 1. Connect M6a to power

Please wait for 1 minute after connecting the M6a to power. Once the indicator light becomes solid orange, proceed to the next step.

#### 2. Press the "Connect" button of the node

The indicator light of node will begin flashing blue to signify that the device is in pairing mode and will change to white once the mesh connection is successful.

# 3. Press the "Connect" button of the router or Click the "Next" button in the App

The indicator light of router will begin flashing blue to signify that the device is in pairing mode and will change to white once the mesh connection is successful.



Visit <u>mywifi.mercku.tech</u> Or download the **Mercku app** to add and manage the network.

Questions about M6a installation? please visit <a href="www.mercku.com/help">www.mercku.com/help</a>

#### FCC ID: XXXXX-XX

This device complies with Part 15 of the FCC rules. Operation is subjected to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

The device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful

interference to co-channel mobile satellite systems;

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The distance between user and products should be no less than 20cm.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### LED indicator color



Blinking: Interactions (upgrades firmware, reboots router)

Blinking frequently: Restore to factory settings



Blinking: Pairing mode (Adding a node)



Steadily illuminated: Stable network connection

Blinking: Poor mesh connection



Steadily illuminated: No Internet connection



Website:

www.mercku.com



Email:

support@mercku.com



Need help:

www.mercku.com/help



www.mercku.com



# **Documents / Resources**



MERCKU M6a Mesh WiFi 6 Router [pdf] User Guide

M6A, 2APR4-M6A, 2APR4M6A, M6a Mesh WiFi 6 Router, Mesh WiFi 6 Router, WiFi 6 Router, Router

Manuals+,