

MERCKU M6S Ms Router User Guide



Quick start Guide

MAAA



Mercku APP
Manage your router easily




Online Manual
Scan to learn more detail



110101230001

Thank you for choosing Mercku



Port configuration


1. RESET
2. CONNECT
3. LAN
4. WAN
5. POWER

Set-up 3 in steps:

1. Connect provided power and WAN cables to the M6s


Red light indicates that there is power.

When the device has an internet connection, the light will turn white.



2. Connect to Wi-Fi

Use your mobile device or computer to search for and connect to the open **MERCKU-XXXX** Wi-Fi network.



- MERCKU-XXXX – Please locate this SSID on the bottom label.

3. Open browser or app

Visit mywifi.mercku.tech through a web browser to complete setup.

Or scan the **QR code** below to download the Mercku app and complete setup, plus manage your network.



Questions about M6s installation? please visit www.mercku.com/help


Expand your Wi-Fi coverage

After setting up the M6s router, you can expand your wireless coverage by adding additional M6s devices as nodes to form a larger mesh network.

Note: Does not support adding nodes in batches.

Quick tips

M6s performance is optimal when nodes are no more than two rooms apart from each other or the main M6s router.



More Details Visit the online description for more product details

LED indicator color



Red

Blinking: Interactions (upgrades firmware, reboots router)

Blinking frequently: Restore to factory settings



Blue

Blinking: Pairing mode (Adding a node)



White

Steadily illuminated: Stable network connection Blinking: Poor mesh connection



Orange

Steadily illuminated: No Internet connection



Website:

www.mercku.com



Email:

support@mercku.com



Need help:

www.mercku.com/help

This guide provides a brief introduction to Mercku hardware and software. The images, steps, and descriptions are purely for illustrative purposes and may not accurately represent your personal experience. Please note that this guide is for informational purposes only, and we cannot guarantee the accuracy or completeness of the information provided. Additionally, please be aware that updates to the content may happen without prior notice.

FCC ID: APR-MS

This device complies with Part of the FCC rules. Operation is subjected to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

The device for operation in the band – MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference; and

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. The distance between user and products should be no less than 20cm.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

The device meets the exemption from the routine evaluation limits in section . of RSS and compliance with RSS-RF exposure, users can obtain Canadian information on RF exposure and compliance.


Contents

[1 Documents / Resources](#)

[1.1 References](#)

[2 Related Posts](#)

Documents / Resources

| | |
|---|--|
|  | MERCKU M6S Ms Router [pdf] User Guide M6S, M6S Ms Router, Ms Router, Router |
|---|--|

References

-  [Welcome to the New Era of Connectivity | Mercku](#)
-  [Mercku](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.