



meross MS200HK Smart Door And Window Sensor User Manual

[Home](#) » [Meross](#) » meross MS200HK Smart Door And Window Sensor User Manual 

Contents

- [1 meross MS200HK Smart Door And Window Sensor](#)
- [2 Safety Information](#)
- [3 Package Contents](#)
- [4 Installation Guide](#)
- [5 LED and Button Rules](#)
- [6 How to Use General Settings](#)
- [7 How to Install the Sensor](#)
- [8 FAQ](#)
- [9 FCC STATEMENT](#)
- [10 Documents / Resources](#)
- [11 Related Posts](#)

meross


meross MS200HK Smart Door And Window Sensor



Safety Information

1. Do not attempt to disassemble, repair, or modify the device.
2. This product should not be exposed to direct sunlight.
3. Please contact the seller for replacement if there is any damage caused by transportation.
4. Indoor use only.

Package Contents



If you find any part missing in the package, please contact us at <https://www.meross.com/support/Email> Support. we will provide a proper solution for you.

Installation Guide

Download the Merass app.




Set up the device

1. Connect your smartphone or tablet to a 2.4 GHz Wi-Fi network.
2. Make sure your smart hub is covered by a strong Wi-Fi signal.
3. The smart hub supports iOS 13/ iPodOS 13 and later. It is recommended that you upgrade your iOS or iPod to the latest version before pairing it with the smart hub.
4. Launch the Meross app and log in to your account, or if you are a new user, tap Sign up to create a new account.
5. Tap the "+" icon to select the type of smart device you want to add, then you can just follow the setup wizard to finish the configuration.
6. Relocation of the smart hub does not require additional operations provided that it remains on the same network with a strong Wi-Fi signal.

NOTE

1. If this is not the first time you've added this smart hub, you'll have to reset it before going any further.
2. As long as you finish the configuration, you'll be able to manage the device in Apple Home app.
3. If the QR code does not work, please try to add the smart device in Apple Home app.

LED and Button Rules




1. Status LED
2. Flash green once: The device is powered on.
3. Flash green rapidly: Pairing mode.
4. Solid green: Successfully connected. LED will be OFF automatically in 5 seconds.

Button

Insert a pin into the hole and press the button once, the LED will flash twice. Within 5 seconds:

1. press the button once again to enter pairing mode.
2. Then, press the button again and hold for 5 seconds to factory reset the device.
3. Status LED
4. Solid amber: Initiating/Reset/Firmware upgrading. Flashing amber and green: Configuration mode.
5. Flashing green: Pairing mode/Connecting to Wi-Fi/ Disconnected from Wi-Fi.
6. Solid green: Connected to Wi-Fi with an internet connection. Solid red: No internet connection.

How to Use General Settings



Device name: Change device name. Smart hub: Set smart hub and check status.

User manual: Check the user manual. Alert: Enable/disable push notifications. Automation: Set certain trigger conditions to allow settings by other Meross smart devices.

Export history: Export history records.

History Records




Record the time when the sensor is open and closed.


You can also clear the records.

How to Install the Sensor


1. Test at the location to be installed to ensure that the sensor can communicate with the hub normally.



2. Take out the double-sided adhesive tape from the package and install it on the product.




3. When installing, try to align the installation marking lines on the side of the main body and the magnet. Please ensure that the surface of the paste location is clean and dry.
4. It is recommended that the main body (large part) be installed on the fixed surface, and the magnet (small part) should be installed on the movable surface.




5. The installation gap should be less than 0.94 in. (24mm) when the doors and windows are closed.

Replace Battery


1. Prepare the pin and the main body.




2. Insert the pin into the gap.



3. Pry up hard to open the shell.



4. Remove and replace the battery CR2450.



5. It is recommended that you purchase a Panasonic battery for replacement, which supports smart devices to prevent rapid power depletion.

FAQ

At Meross, we strive to assure your satisfaction. Attached below is a non-exhaustive list of questions that users are mostly concerned about.

What should I do when my Meross app is unable to check the added smart sensor?

You can troubleshoot the following

- Check the Wi-Fi internet connection.
- Make sure the Wi-Fi password hasn't been changed.
- Make sure the device's battery is not used up.
- Make sure the paired Smart Hub is still online. You can check its LED color, if it is not solid green, please power cycle it once, if it still does not work, please reset the Smart Hub and configure it with the Smart Sensor once more.

How to fix a HomeKit pairing failure?

<https://www.meross.com/support/Email> Support HTML for a solution.

Why Is my Meross smart device not responding In the Apple Home app?

This is an existing issue with Apple Home app. You need to exit and reboot your Home app to fix this problem.

To learn more, you can visit

<https://www.meros.com/support/fags> to find solutions for more frequently asked questions.

Warranty

Meross products are covered by a 12-month limited warranty from the date of purchase. Please visit <https://www.meros.com/support/warranty> for detailed warranty policy and product registration.

NOTE

The warranty does NOT cover the batteries supplied.

Disclaimer

1. The function of this smart device is tested under a typical circumstance described in our specifications. Meross does NOT guarantee that the smart device shall perform exactly the same as described under all circumstances.
2. By using third-party services including but not limited to Amazon Alexa, Apple HomeKit, and SmartThings, customers acknowledge that Meross shall not be held liable in any way for the data and private information collected by such parties. Meross's total liability is limited to what is expressly covered in its Privacy Policy.
3. Damages arising from ignorance of the SAFETY INFORMATION shall not be covered by Meross aftersales service, nor does Meross take any legal responsibility therefrom. Customers acknowledge their understanding of these articles clearly by reading this manual.

FCC STATEMENT

FCC Compliance Information Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Canadian Compliance Statement

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science, and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.


The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 on compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

SIMPLE DEVICE SIMPLIFY YOUR LIFE

Email: support@merass.com Website: www.merass.com

Manufacturer: Chengdu Meross Technology Co . Ltd. Address Floor 3. Building A5. Shijlcheng Rood No 1129, Gaoxln. Free Trade Trial Zone, Chengdu. Slchuan.Chlno.

Documents / Resources

 <small>User Manual</small>	meross MS200HK Smart Door And Window Sensor [pdf] User Manual MS200HK Smart Door And Window Sensor, MS200HK, Smart Door And Window Sensor, Door And Window Sensor, And Window Sensor, Window Sensor
---	--