



## **milwaukee M12 Pal Rotating Workshop Lamp User Manual**

[Home](#) » [Milwaukee](#) » milwaukee M12 Pal Rotating Workshop Lamp User Manual 

**milwaukee M12 Pal Rotating Workshop Lamp User Manual**



### **Contents**

- [1 IMPORTANT SAFETY INSTRUCTIONS](#)
- [2 ADDITIONAL BATTERY SAFETY RULES](#)
- [3 SPECIFICATIONS](#)
- [4 SYMBOLOGY](#)
- [5 LIGHT](#)
- [6 MAINTENANCE](#)
- [7 WARRANTY – AUSTRALIA and NEW ZEALAND](#)
- [8 SERVICE – AUSTRALIA and NEW ZEALAND](#)
- [9 Documents / Resources](#)
- [10 Related Posts](#)

### **IMPORTANT SAFETY INSTRUCTIONS**



**WARNING** READ AND UNDERSTAND ALL INSTRUCTIONS. When using electric appliances, basic precautions should always be followed, including the following:

Before using the flood light, read this operator's manual, your battery pack and charger operator's manual, and all labels on the battery pack, charger and flood light.

- Read and understand all the instructions before using the appliance.
- To reduce the risk of injury, close supervision is necessary when an appliance is used near children.
- Store idle flood light out of reach of children. Warm flood lights can become hazardous in the hands of children.
- Do not use outdoors.
- For a rechargeable appliance – Use only the charger supplied by the manufacturer to recharge.
- Know your flood light. Read this manual carefully to learn your flood light's applications and limitations as well as potential hazards associated with this type of tool.
- Batteries must be recharged only with the charger specified by the manufacturer. A charger that may be suitable for one type of battery may create a risk of fire when used with another battery.
- Use flood light only with specifically designated battery pack. Use of any other batteries may create a risk of fire.
- When battery pack is not in use, keep it away from metal objects like: paper clips, coins, keys, nails, screws, or other small metal objects that can make a connection from one terminal to another. Short-ing the battery terminals together may cause sparks, burns, or a fire.
- Maintain labels and nameplates. These carry important information. If unreadable or missing, contact a MILWAUKEE service facility for a replacement.

## SAVE THESE INSTRUCTIONS

## ADDITIONAL BATTERY SAFETY RULES



**WARNING** To reduce the risk of fire, personal injury, and product damage due to a short circuit, never immerse your tool, battery pack or charger in fluid or allow a fluid to flow inside them. Corrosive or conductive fluids, such as seawater, certain industrial chemicals, and bleach or bleach-containing products, etc., can cause a short circuit.










**WARNING** Do not charge non-rechargeable batteries.


## SPECIFICATIONS

- Cat. No.: M12 PAL
- Volts: 12V DC
- Battery Type : M12™
- Charger Type: 12™
- USB Output : 5V DC
- USB Amps: 2.1A
- Recommended Ambient
- Operating Temperature: -17°C to 51°C

## SYMBOLLOGY

- **V** Volts
-  Direct Current
- **A** Amps
-  Read Operator's Manual
-  Indoor use
-  Do not stare at the operating light source.
-  Class III appliance
-  Regulatory Compliance mark (RCM). This product meets applicable regulatory requirements.
-  Do not dispose of electric tools together with household waste material. Electric tools and electronic equipment that have reached the end of their life must be collected separately and returned to an environmentally compatible recycling facility


## LIGHT

 **WARNING:** Recharge only with the charger specified for the battery. For specific charging instructions, read the operator's manual supplied with your charger and battery.

### Inserting/Removing Battery Pack

Insert the battery pack by sliding battery pack into the body of the tool. Insert the battery pack until the battery latches lock. To remove the battery pack, press in both battery latches and slide the battery pack off of the tool

### Power


 **CAUTION** To reduce the risk of injury, do not stare at the operating light source.

Press the power button to cycle through HIGH, LOW, and OFF settings

### USB Port

To charge a phone or other electronic device using the 2.1A USB port, plug in the USB and press the USB wake button. The port will remain ON for about 2 hours.

## MAINTENANCE

 **WARNING:** To reduce the risk of injury, always unplug the charger and remove the battery pack from the charger or tool before performing any maintenance. Never disassemble the tool, battery pack or charger. Contact a MILWAUKEE® service facility for ALL repairs.

## Maintain Light

Keep your light, battery pack and charger in good repair by adopting a regular maintenance program. If the light does not work properly, return the light to a MILWAUKEE® service facility for repairs



**WARNING:** To reduce the risk of personal injury and damage, never immerse your tool, battery pack or charger in liquid or allow a liquid to flow inside them.

## Cleaning

Keep tool handles clean, dry and free of oil or grease. Use only mild soap and a damp cloth to clean the tool, battery pack and charger since certain cleaning agents and solvents are harmful to plastics and other insulated parts. Some of these include gasoline, turpentine, lacquer thinner, paint thinner, chlorinated cleaning solvents, ammonia and household detergents containing ammonia. Never use flammable or combustible solvents around tools.

## WARRANTY – AUSTRALIA and NEW ZEALAND

Please refer to Australian and New Zealand warranty supplied with tool. This warranty applies only to product sold by authorised dealers in Australia and New Zealand.

## SERVICE – AUSTRALIA and NEW ZEALAND

MILWAUKEE® prides itself in producing a premium quality product that is Nothing But Heavy Duty™. Your satisfaction with our products is very important to us! If you encounter any problems with the operation of this tool, please contact your authorised MILWAUKEE® dealer.

For a list of MILWAUKEE® dealers, guarantee or service agents please contact MILWAUKEE® Customer Service or visit our website.

(Australia Toll Free Telephone Number 1300 645 928)

(New Zealand Toll Free Telephone Number 0800 645 928) or visit [milwaukeeetool.com.au](http://milwaukeeetool.com.au/) / [milwaukeeetool.co.nz](http://milwaukeeetool.co.nz).

Milwaukee Electric Tool Corporation 13135 West Lisbon Road, Brookfield, Wisconsin U.S.A. 53005

### Milwaukee Tool (Australia)

21 Kelleets Road, Rowville, VIC 3178  
Melbourne, Australia


### Milwaukee Tool (New Zealand)

274 Church Street, Penrose,  
Auckland, 1061, New Zealand

DESIGNED BY MILWAUKEE ELECTRIC TOOL CORP. PROFESSIONALLY

**MADE IN CHINA PRINTED IN CHINA**

Documents / Resources

The thumbnail shows the first page of the user manual. It includes the Milwaukee logo, a title section for 'M12 PAL', and several sections: 'IMPORTANT SAFETY INSTRUCTIONS' with multiple warning icons, 'SYMBOLS' with icons for battery, power, and other symbols, 'SPECIFICATIONS' with a table of technical details, and 'LIGHT' section with a table of light output. The bottom of the page has 'ABOUT THE M12 SYSTEM' and 'CONTACT INFORMATION'.

[milwaukee M12 Pal Rotating Workshop Lamp](#) [pdf] User Manual

M12 Pal, Rotating Workshop Lamp

Manuals+,