

MINISO
L99 TWS
Wireless
Earbuds



MINISO L99 TWS Wireless Earbuds User Manual

[Home](#) » [MINISO](#) » MINISO L99 TWS Wireless Earbuds User Manual 

Contents

- [1 MINISO L99 TWS Wireless Earbuds](#)
- [2 Accessories](#)
- [3 Product Parts](#)
- [4 Product Parameters](#)
- [5 Functions](#)
- [6 Troubleshooting](#)
- [7 FCC Warning](#)
- [8 FCC Statement](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)

MINISO

MINISO L99 TWS Wireless Earbuds




Accessories

- Device*1,
- User Manual*1,
- USB-C Charging Cable*1

Product Parts

1. Earphone Touch Button
2. Mic
3. Earphone Charging Touch
4. Charging Case LED Light
5. USB-C Port



Product Parameters

BT Version	V5.4	Charging Time	Around 1.5h
BT Name	MINISO-L99	Transmission Distance	10m
Music Playback Time	Around 3h (50% volume)	Charging Port	USB-C
Earphone Battery Capacity	25mAh	Charging Case Battery Capacity	250mAh

Functions

Function	Charging Case Instructions
Turn On	Take the earphones out of charging case
Turn Off	Put the earphones into charging case
Pairing Mode	For first time connection, open the upper lid charging case, the earphones enter into pairing mode automatically. Search for MINISO-L99 and choose to connect, there is a prompt after the earphones are connected successfully. The next time you turn on, the earphones will connect automatically with the last device.
Manual Pairing	Take one of the earphones out of charging case and press five times, do the same with the other earphone to erase pairing information and turn off automatically, put the earphones again into the charging case for automatic re-pairing, turn on the Bluetooth of the phone, search for "MINISO-L99" to connect

	Earphones Instructions
Play/Pause	Press left/right earphone once
Next Track	Press right earphone twice
Previous Track	Press left earphone twice
Volume+	Long press right earphone
Volume-	Long press left earphone
Answer/ End Call	Press left/right earphone once
Reject Call	Press left/right earphone twice
Activate Phone's Voice Assistant	Press left/right earphone three times
Light	Charging case charging earphones: charging case white light constantly on when charging, and turns off when fully charged Charging case getting charged: charging case white light blinks Charging case fully charged: white light constantly on.

Cautions

1. Reasonable control of the volume and time of usage is required to avoid hearing damage.

2. For your safety, do not use it in potentially hazardous condition.
3. Do not listen to music, call up or answer the phone while driving to avoid danger caused by distraction.
4. Keep it out of reach of children to avoid danger caused by improper use.
5. Do not throw to avoid damage caused by dropping.
6. Do not store or use it under -20°C or above 45°C to avoid shortening the lifespan of earphones and battery.
7. Do not modify, disassemble or repair the product.
8. Irreplaceable battery. It should be disposed of according to local rules & regulations or be recycled by professional institute. Do not throw away or toss into fire.
9. When not in use for a long time, charge the earphones once every 3 months to extend its lifespan.
10. Avoid contact with water and other liquids to prevent them from penetrating into the product.

Troubleshooting

1. Wireless earphones fail to be paired with the phone.

Solution: Check if the earphones are in pairing mode, and whether the phone has BT function on. Check the list on your phone, remove earphones from the list, follow the instructions of user manual to pair the earphones with your phone again.

2. Cannot turn on the wireless earphones.

Solution: Check the battery to see if it is low.

3. Can the battery of the wireless earphones be replaced?

Answer: No. The lithium polymer battery in the earphones is irreplaceable.

4. The wireless earphones got disconnected with the phone within 10 meters.

Solution: BT is wireless so that it is very sensitive to objects between the earphones and the connected device. Check if there are any metal or other objects that may affect the connection within the effective distance.

5. Cannot hear audio playing when the earphones are connected to the computer or phone.

Solution: Check whether the computer's audio output is already connected to wireless device and whether the Bluetooth in the computer supports A2DP protocol. Make sure the volume is up on your phone or computer.

6. Can I operate the Apps of my phone through the earphones after connecting the wireless earphones to the phone?

Answer: Some apps may not support being operated through the earphones due to their settings.

FCC Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

IC WARNING

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

WEEE Warning:

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

FCC Statement

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference

by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Documents / Resources

	MINISO L99 TWS Wireless Earbuds [pdf] User Manual L99, L99 TWS Wireless Earbuds, TWS Wireless Earbuds, Wireless Earbuds, Earbuds
---	---

References

- [User Manual](#)

[Manuals+](#). [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.