





# **MIRO A67 Smart Phone User Guide**

Home » miro » MIRO A67 Smart Phone User Guide Ta

#### **Contents**

- 1 MIRO A67 Smart Phone
- **2 Product Usage Instructions**
- **3 Product Safety Information**
- 4 Getting to Know Your

**Phone** 

- **5 Before Getting Started**
- **6 Basic Settings**
- **7 Technical Specifications**
- **8 FCC Warning**
- 9 FAQ
- 10 Documents / Resources
  - 10.1 References
- 11 Related Posts



**MIRO A67 Smart Phone** 



## **Product Information**

## Specifications:

Model: 790Model: 798

## **Product Usage Instructions**

Thank you for choosing MIRO product. Please follow the instructions when start using this product.

## **Product Safety Information**

	Γ
A	Do not use while re-charging.
	Do not use hand-held while driving.
	This device may produce a bright or flash light.
A	For body-worn operation, maintain aspiration of 5 mm.
A	Do not dispose of the phone in a fire.
	Small parts may cause a choking hazard.
	Avoid contact with magnetic media.
ALE:	This device may produce a loud sound.
<b>P</b>	To prevent possible hearing damage, do not listen at high volume levels for long periods.
	Avoid extreme temperatures.
R	Keep away from pacemakers and other personal medical devices.
	Avoid any contact with liquid. Keep it dry.
<b>A</b>	Switch off when instructed in hospitals and medical facilities.
1	Do not attempt to disassemble your phone.
	Switch off when instructed in aircrafts and airports.
	Do not rely on this device for emergency communications.
	Switch off in explosive environments.

#### What are in the Box

## The phone packaging box should contain the following items and accessories:

Phone, Charger, USB Type-C cable, Protective film (applied), SIM card tool. Phone case, Quick Start Guide.


## **Notices for the Use of Your Phone**

Your phone should be treated with care. The following suggestions can help you extend the life of your mobile phone.

1. Place the mobile phone and its parts and components out of reach of young children.

- 2. Keep the phone dry. Rain, humidity and all types of liquids which contain minerals will corrode electronic circuits.
- 3. Don't touch the phone with wet hands when charging. it will cause an electric shock or damage the phone.
- 4. Avoid placing the device in high temperature environments. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- 5. Avoid placing the device in a low temperature environment. When the temperature rises, the phone will produce water vapor that may damage electronic circuits.
- 6. Avoid placing the phone in dusty, dirty places, otherwise parts may be damaged.
- 7. Avoid placing the phone near a lit cigarette, open flame or any heat source.
- 8. Do not drop, knock or shake the phone. Rough handling can damage internal circuit boards.
- 9. Do not paint the phone. The paint may block headphones, microphones or other removable parts, and cause them not to work.
- 10. Use a clean, soft, dry cloth to clean the camera, light sensor lenses. Prohibit the use of harmful chemicals and cleaning agents to clean the phone.
- 11. Pacemaker manufacturers recommend that a minimum separation of 5mm be maintained between a mobile phone and a pacemaker to avoid a potential interference with the pacemaker (when the device is used in the USA, the separation distance can be maintained at 10mm between user's body and handset). To achieve this use the phone on the opposite ear to your pacemaker and do not carry it in a breast pocket.
- 12. Please consult your doctor and the device manufacturer to determine if operation of your phone may interfere with the operation of your medical device.
- 13. Turn off your mobile phone or wireless devices when in a blasting area or in areas posted turn off "two-way radios" or "electronic devices" to avoid interfering with blasting operations.
- 14. There is a risk of explosion if the battery is replaced with an incorrect type. Dispose of a used batteries according to the instructions.

### **Getting to Know Your Phone**





## **Power Key**

- Press and hold to Power on/off, or Restart the phone.
- Press to wake up or turn off the display.

## **Home Key**

- Touch to return to the home screen.
- Touch and hold to open the Google Assistant for Android ™

## Menu Key

• Touch to see recently used applications.

### **Back key**

• Touch to go back to the previous screen.

## **Volume Keys**

• Press or hold to turn the volume up or down.


## **Before Getting Started**

## **Installing SIM Cards**

Insert a SIM tool into the small hole to eject the SIM tray.



Put 1 or 2 nano-SIM cards onto the SIM tray with the gold contacts facing down and the notched edges match the positions on the SIM tray.



### Installing a microSD Card (Not Included)

A micro-SD card will occupy SIM2 location. Therefore, only SIMI is supported when a micro-SD is installed. Please insert the micro-SD card with the gold contact facing down on the SIM tray. Push the SIM tray back in until it clicks into place and is flush with the side of the device.



Caution: Please use standard nano-SIM card only.

Non-standard SIM or hand-cut SIM card may damage the SIM tray or phone and causes SIM rejection situation. Always turn off the phone before installing or replacing SIM cards or a micro-SD card.

**NOTE:** Some applications may require a micro D card to work normally or may store certain data on it. Therefore, it is recommended that you keep a microSD card installed and not remove or replace it randomly.

### **Basic Settings**

Your service provider may default some device settings, so you may not be able to change these settings.




- Brightness
  - Brightness level: Adjust the screen brightness.
- · Lock display
  - Lock screen: Customized what to show on lock screen.
  - Screen timeout: Adjust the time allowed before the screen goes to sleep after inactively.
- Appearance
  - Dark theme: turn on/off the dark background.
  - Font size: Set the font size of the system.
  - Display size: Set the display size of the screen.
- · Other display controls
  - Auto-rotated screen: Swipe to turn on or off.
  - Screen saver: Choose the screen saver and when to start.







- 1. You can set up all the languages supported by the phone.
- 2. Keyboards: You can set on-screen keyboard or physical keyboard.



- 1. Set time automatically: Swipe right to use date and time provided by network.
- 2. Time zone: You can choose to use the time zone provided by network or use the location to set time zone.
- 3. Time format: You can choose to use local default time format or to use 24-hour format.



#### Here you can check out basic information including:

Device name, phone number, local software update, and device details including SIM status, Model, RAM, IMEI, Android version, IP address, Uptime, Build number, etc.

#### **Technical Specifications**

Network: 2G: B2/3/5/8

o 3G: B2/4/5

4G: B2/4/5/7/12/13/17/25/26/28AB/41/66/71

• Display: 6.75"

• Memory: 4GB(LPDDR3)+64GB

Camera: 13MP+VGA/5MP

• FM/ MP3 / MP4 / GPS/ G-sensor

· Battery Capacity: 4000mAh Li-ion

(\*): The storage capacity actually available in the unit's internal memory may be less due to the preloaded operating system and/ or other pre-installed or configured applications. Check the space actually available on your computer.

#### **SAR Information Statement**

The SAR limit of USA (FCC) is 1.6W/kg averaged over one gram of tissue.

Device types: smartphone (FCC ID: 2AQRM-A67) has also been tested against this SAR limit. The highest SAR value for this mobile phone tested is 0. 790W/kg aginst the head and 0. 798W/kg at 10mm from the body. Use the smartphone in an environment with the temperature between -10°C~+45°C/+14°F~+113°F. Use the earphone carefully. Excessive sound pressure from earphones and headphones can cause hearing loss.



The product shall only be connected to a USB interface of version USB2.0

**CAUTION:** RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Manufacturer: Foxx Development Inc.

3480 Preston Ridge Road, Suite500, Alpharetta, CA 30005

#### Information for auxiliary equipment

Battery		
Model	A67	
capacity	15.4Wh	
Manufacturer	Shenzhenshi jiuliyuan electronic technology co., LTD.	
Address of Manufacturer	201, Jiuli Yuan Factory, No. 470, Bingsinan Ajinbio. Road, Biling Community, Biling S treet, Pingshan District, Shenzhen	



#### WEEE Recycling

This product should not be treated as household waste, instead it should be handed over to the applicable collection point for the recycling of electrical and electronic equipment.

GSM				
Operation Frequency	GSM 850 TX:824-849MHz; RX:869-894MHz GSM 900 TX:890-915MHz; RX:935-960MHz DCS 1800 TX:1710-1785MHz;RX:1805-1880MHz PCS 1900 TX:1850-1910MHz;RX:1930-1990MHz			
WCDMA				
Operation Frequency	Band 2:TX:1852-1908MHz; RX:1932-1988MHz Band 4:TX:1712-1753MHz; RX:2112-2153MHz Band 5:TX:826-847MHz; RX:871-892MHz			

LTE			
Operation Frequency	Band 2:TX:1850-1910MHz; RX:1930-1990MHz Band 4:TX:1710-1760MHz; RX:2110-2155MHz Band 5:TX:824-849MHz; RX:869-894MHz Band 7:TX:2500-2570MHz; RX:2620-2690MHz Band 12:TX:699-716MHz; RX:729-746MHz Band 13:TX:777-787MHz; RX:746-756MHz Band 17:TX:704-716MHz; RX:734-746MHz Band 25:TX:1850-1915MHz; RX:1930-1995MHz Band 26:TX:814-849MHz; RX:859-894MHz Band 28A:TX:703-733MHz; RX:758-788MHz Band 28B:TX:718-748MHz; RX:773-803MHz Band 41:TX:2496-2690MHz Band 66:TX:1710-1780MHz; RX:2110-2180MHz Band 71:TX:663-698MHz; RX:617-652MHz		
FM			
Operation Frequency	87.5MHz-108MHz		
GPS/GLONASS			
Operation Frequency	L1:1559MHz~1610MHz R1:1559MHz~1610MHz		

Google and Android are trademarks of Google LLC.

## **FCC Warning**

## Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### Information to the user.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### **Absorption Rate (SAR) information:**

This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

#### **FCC RF Exposure Information and Statement**

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. This device was tested for typical body-worn operations with the back of the device kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a appropriate separation distance between the user's body and the back of the device. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided. Use only the supplied or an approved antenna.

#### **FAQ**

• Q: What should I do if the device causes interference?

A: If the device causes interference, try reorienting or relocating the receiving antenna. If the issue persists, consult a dealer or a radio/TV technician for assistance.

• Q: How can I ensure optimal performance of the equipment?

A: To ensure optimal performance, increase the separation between the equipment and receiver, and connect the equipment to a different circuit than the receiver. Following these steps can help improve overall performance.

#### **Documents / Resources**



MIRO A67 Smart Phone [pdf] User Guide A67, A67 Smart Phone, Smart Phone

#### References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.