

MONKEY LOOP MLA-10AC Antennas User Manual

Home » MONKEY LOOP » MONKEY LOOP MLA-10AC Antennas User Manual



MONKEY LOOP



MLA-10AC **USER'S MANUAL**

Contents

- 1 PRECAUTIONS
- **2 CONTROLS AND**

FUNCTIONS

- **3 BATTERY LOAD**
- **4 SPECIFICATIONS**
- 5 Documents / Resources
 - 5.1 References

PRECAUTIONS

Location

Using the unit in the following locations can result in a malfunction.

- In direct sunlight
- · Locations of extreme temperature or humidity
- · Excessively dusty or dirty locations
- · Locations of excessive vibration
- · Close to magnetic fields

Power supply

Be sure to turn the power OFF when the unit is not in use. Remove the battery in order to prevent it from leaking when the unit is not in use for extended periods. If using a power adapter, please connect the designated AC adapter to an AC outlet of the correct voltage.

Do not connectit to an AC outlet of voltage other than that for which your unit is intended. Interference with other electrical devices Radios and televisions placed nearby may experience reception interference. Operate this unit at a suitable distance from radios and televisions.

Handling

To avoid breakage, do not apply excessive force to the switches or controls.

Care

If the exterior becomes dirty, wipe it with a clean, dry cloth. Do not use liquid cleaners such as benzene or thinner, or cleaning compounds of flammable polishes.


Keep this manual


After reading this manual, please keep it for later reference.

Keeping foreign matter out of your equipment

Never set any container with liquid in it near this equipment. If liquid gets into the equipment, it could cause a breakdown, fire, or electrical shock. Be careful not to let metal objects get into the equipment.

CONTROLS AND FUNCTIONS








- 1. GUITAR Input: Link to an acoustic guitar by guitar cable
- 2. GUITAR VOLUME: Use this knob to control guitar volume
- 3. MIC Input: Link to a microphone
- 4. MIC-VOLUME: Use this knob to control microphone volume
- 5. AUX In: Link to MP3 player or smart phone by 3. 5mm gauge audio cable
- Music Volume: Adjust music volume
- 7. MASTER Volume: Adjust master volume
- 8. Power Switch: Switch On/Off power. When power is On, the indicator is lit.
- 9. Power Adapter In: Link DC 12V (DC min = 5V) adapter
- 10. Battery Compartment: Load 6 AA batteries.

Remind: When AC 12V adapter is connected, the batteries power is cut off. When the adapter link off, the batteries power is connected automatically again.

BATTERY LOAD









Please load batteries by steps as below when needed:

- 1. Press the buckle and pull out to open the battery compartment lid as shown by diagram ①②.
- 2. Insert two batteries according to the polarity direction marked as shown by diagram ③ And then press the joint area as shown by diagram 4 to load batteries successfully.
- 3. Load all the other four batteries following step 2 and cover the battery compartment lid.

SPECIFICATIONS

Max. output :10W

Speaker spec: 5 inch, 4Ω

Power: 6 AA batteries, or enclosed AC adapter

Dimension: 238x179X224mm

Net weight: 2.83kg

Accessories: AC adapter (DC12V/1A ———), manual, 3.5mm gauge audio cable, shoulder strap, hand strap.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if notinstalled and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which there ceiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2)this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body

MONKEY LOOP



Documents / Resources



MONKEY LOOP MLA-10AC Antennas [pdf] User Manual MLA-10AC Antennas, MLA-10AC, Antennas

References

• User Manual

Manuals+, Privacy Policy