



monport LRA-0730 Rotary Axis Attachment Instruction Manual

[Home](#) » [monport](#) » monport LRA-0730 Rotary Axis Attachment Instruction Manual 

Contents

- [1 monport LRA-0730 Rotary Axis Attachment](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 Safety Information](#)
- [6 Installation](#)
- [7 Specifications](#)
- [8 Operation](#)
- [9 Maintenance](#)
- [10 Contact Us](#)
- [11 Documents / Resources](#)
 - [11.1 References](#)
- [12 Related Posts](#)



monport LRA-0730 Rotary Axis Attachment



Specifications

- **Operation**
- **Input Voltage:** 24 V
- **Rated Power:** 10 W
- **Product Dimensions:**
 - **Roller Length:** 10.4 in. (26.4 cm)
 - **Fixed Roller Height:** 2.9 in. (7.3 cm)
 - **Net Weight:** 3.5 lb. (1.6 kg)

Product Usage Instructions

Installation

1. Place the rotary axis attachment on the workbed ensuring the laser head can move along the full X-axis range without obstruction.
2. Connect the rotary device's connection to the Y-axis port inside the engraver or the rotary axis port behind your engraver.

Operation

1. Place your item gently on the rollers.
2. Use your engraver's control panel or engraving software to add your design, making necessary adjustments as you go.

Maintenance

If you have any questions while reading the manual or setting up your machine, feel free to contact us at +1 (213)554-8829 or email support@monportlaser.com for assistance.

FAQ

- **Can I use this rotary axis attachment with any engraving machine?**

The rotary axis attachment should be compatible with most engraving machines, but it's recommended to check for compatibility with your specific model.

- **How do I clean the rollers of the rotary axis attachment?**

To clean the rollers, use a soft cloth dampened with water. Avoid using harsh chemicals or abrasive materials that may damage the rollers.

Safety Information

- Keep this device clean and free of potentially flammable or reflective dust and swarf.
- DO NOT place body parts in or near the engraving path.
- ALWAYS wear appropriate personal protective equipment such as protective eyewear when operating your laser. If this device is being used on an open bed, it is also recommended to secure the worksite or erect protective screens around the laser path to prevent injury to passersby.
- DO NOT use this device with items too wide or long for its rails.
- DO NOT assemble or disassemble this device without proper training.

Installation

1. Place this rotary axis on the workbed. Ensure that the placement allows the laser head to move along the full range of its X axis without obstruction.
2. Connect the rotary device's connection to the Y-axis port inside the engraver or the rotary axis port behind your engraver.

Specifications

- **Input Voltage** 24 V
- **Rated Power** 10 W
- **Product Dimensions** 14.1×6.1×2.9 in. (35.9×15.5×7.3cm)
- **Distance between Rollers** 0.2–2.9 in. (5–73 mm)
- **Roller Length** 10.4 in. (26.4 cm)
- **Fixed Roller Height** 2.9 in. (7.3 cm)
- **Net Weight** 3.5 lb. (1.6 kg)

Operation

1. Place your item gently on the rollers.
2. Use your engraver's control panel or your engraving software to add your design, making any necessary adjustments as you go.

Maintenance

Clean this device with a soft moist cloth to remove any dust or debris that may accumulate. Allow time for any moisture to air dry before further use.

Contact Us

If you do have any questions while reading the manual or setting up your machine, feel free to give us a call at +1

(213)554-8829 or email support@monportlaser.com and a member of our technical support team would be happy to answer your questions.

Documents / Resources



[monport LRA-0730 Rotary Axis Attachment](#) [pdf] Instruction Manual
LRA-0730 Rotary Axis Attachment, LRA-0730, Rotary Axis Attachment, Axis Attachment, Attachment

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.