

MONTECH MKey PRO Mechanical Gaming Keyboard Instruction Manual

Home » MONTECH » MONTECH MKey PRO Mechanical Gaming Keyboard Instruction Manual




MONTECH MKey PRO Mechanical Gaming Keyboard Instruction Manual




MKey PRO Update Firmware SOP

Step 1: Download and Install QMK Toolbox



Step 2: Get Ready for QMK Toolbox



- 1. Click "Open".
- 2. Find out the bin document which is provided by MONTECH.
- 3. Click "MCU" and select "ATmega32U4".
- 4. Choose "Auto-Flash".

Step 3: Get Ready for MKey PRO




1. Set the switch to USB mode.

Connect the cable between MKey PRO and the device.

- 2. Press and hold "ESC" key.
- 3. Remove the cable (Type-C) from MKey PRO.
- Connect the cable(Type-C) to MKey PRO again. Release the "ESC" key you kept pressing.

Step 4: Finish the Update Process



- 1. After step 3, you will see "Flash complete".
- 2. Remove the cable (Type-C) from MKey PRO again.

Connect the same cable (Type-C) to MKey PRO again.

MKey PRO's ARGB will be turned on again.

The whole process is finished.

bin Documents

- ANSI_MKey PRO_241127
- ISO_MKey PRO_241127
- Released on Nov 27th, 2024.
- Update Ins and End hotkey (Fn+PgUp=Ins / Fn+PgDn=End).
- Update Fn+F4 (F4), knob must be functional even the light is off.

Contents

1 Documents / Resources

1.1 References

Documents / Resources



References

- QMK Firmware
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.