




# MOSITOECO MST-F304B Remote Control Instruction Manual

[Home](#) » [MOSITOECO](#) » MOSITOECO MST-F304B Remote Control Instruction Manual 

## Contents

- [1 MOSITOECO MST-F304B Remote Control](#)
- [2 Product Information](#)
- [3 Features](#)
- [4 Specifications](#)
- [5 Safety Information](#)
- [6 Product Usage Instructions](#)
- [7 OVERVIEW](#)
- [8 FCC STATMENTS](#)
- [9 Documents / Resources](#)
- [10 Related Posts](#)

## MOSITOECO

### MOSITOECO MST-F304B Remote Control



### Product Information

The MST-F304B Remote Control is a device designed for controlling the functions of a fan and light. It is equipped

with a transmitter that communicates with the fan and light receiver to enable remote operation.

## Features

- Allows remote control operation of fan and light functions
- Easy setup and learning process
- Complies with Part 15 of the FCC Rules
- Designed to meet general RF exposure requirements

## Specifications

- **Model:** MST-F304B
- **Power Source:** Requires electrical power
- **Range:** Effective within a certain distance from the receiver
- **Operating Frequency:** Standard RF frequency

## Safety Information

This device has been evaluated to meet general RF exposure requirements, allowing it to be used in portable exposure conditions without restriction. However, it is important to follow the safety guidelines provided in the user manual to ensure safe and proper usage.


**Warning:** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Product Usage Instructions






1. Restore electrical power to the fan and light.
2. Within 30 seconds of restoring power, press and hold the button on the remote control transmitter for 5 seconds or until the light on the fan blinks twice.
3. Use the remote control transmitter to test the light and fan functions to confirm that the learning process is complete.


Make sure to follow the steps in the correct sequence for the successful operation of the remote control. Refer to the user manual for additional instructions and troubleshooting information.

## OVERVIEW



As shown in the figure:

1.  button: Press this key to turn on or off the fan
2. 1 -3Number button: Gear 1-3 is the fan/motor speed button, gear 1 is the lowest speed, gear 3 is the highest speed
3.  Night lamp button: Press this key for the night light mode, and the lamp power is directly reduced to the minimum
4.  anti-theft model button: Press this key for anti-theft mode, turn off the fan, turn on the light, and turn on the light for 5 minutes every 2 hours
5.  Natural wind button: Press this key for natural wind, and the fan rotates from the current gear to the first gear
6. CT button: Short press this key to change the color temperature from 2700/3000/4500/5700/6500K, and long press this key to change the color temperature from 6500->2700K or 2700K->6500K
7.  LED ON/OFF button: Press this key to turn the light on and off
8. DIM button: Long press this key to adjust the brightness, long press the brightness downward or upward adjustment, until adjusted to the highest or lowest brightness, to the target brightness release will stop adjusting the brightness
9. 1H 2H 4H: Is the timed shutdown key, press this key, 1H/2H/4H later turn off the motor
10. Blue light: Press any key of the remote control, the indicator light will light up, and there mote control will issue instructions

Restore electrical power. With in 30 seconds of restoring electrical power, press and hold the “  ”button on the remote controtrans matter for 5 seconds or until right on the fanblinkstwicUse the remote control transmitter to test the liaht and fan functions to confirm the learning process is complete.

## FCC STATMENTS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference,
2. This device must accept any interference received, including interference that may cause undesired operation

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.


If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Warning:** changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment

- The devices has been evaluated to meet general RF exposure requirement the device can be used in portable exposure condition without restriction

**Documents / Resources**

	<p><a href="#">MOSITOECO MST-F304B Remote Control</a> [pdf] Instruction Manual 2AU7R-MST-F304B, 2AU7RMSTF304B, mst f304b, MST-F304B Remote Control, MST-F304B, Remote Control</p>
---	---