

MOTOROLA PMMN4131 RM730 IMPRES Windporting Remote Speaker Microphone, Small IP68 User Guide

Home » Motorola » MOTOROLA PMMN4131 RM730 IMPRES Windporting Remote Speaker Microphone, Small IP68 User Guide [™]



PMMN4131 RM730 IMPRES Windporting Remote Speaker Microphone, Small (IP68) User Guide

Contents

- 1 Copyrights
- 2 Contact Us
- **3 Icon Conventions**
- **4 Style Conventions**
- **5 RF Energy Exposure and Product Safety Guide**
- 6 About PMMN4131 RM730 IMPRES Windporting RSM, Small (IP68)
- 7 Recommended Practices for RM730
 - 7.1 Transmitting and Receiving
- 8 Attaching the RSM to the Radio
- 9 Detaching the RSM from the Radio
- 10 Cable Management
- 11 Optional Accessories
- 12 Replacement Parts
- 13 Service and Warranty
- 14 Replacing Coil Cord
- 15 Removing Dust Cover
- **16 Inserting Dust Cover**
- 17 Attaching Swivel Clip
- 18 Detaching Swivel Clip
- 19 Documents / Resources
- **20 Related Posts**

Copyrights

The Motorola Solutions products described in this document may include copyrighted Motorola Solutions computer programs. Laws in the United States and other countries preserve for Motorola Solutions certain exclusive rights for copyrighted computer programs. Accordingly, any copyrighted Motorola Solutions computer programs contained in the Motorola Solutions products described in this document may not be copied or reproduced in any manner without the express written permission of Motorola Solutions.

© 2020 Motorola Solutions, Inc. All Rights Reserved

No part of this document may be reproduced, transmitted, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without the prior written permission of Motorola Solutions, Inc.

Furthermore, the purchase of Motorola Solutions products shall not be deemed to grant either directly or by implication, estoppel or otherwise, any license under the copyrights, patents, or patent applications of Motorola Solutions, except for the normal non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Disclaimer

Please note that certain features, facilities, and capabilities described in this document may not be applicable to or licensed for use on a specific system, or maybe dependent upon the characteristics of a specific mobile subscriber unit or configuration of certain parameters. Please refer to your Motorola Solutions contact for further information.

Trademarks

MOTOROLA, MOTO, MOTOROLA SOLUTIONS, and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners.

Open Source Content

This product contains Open Source software used under license. Refer to the product installation media for full Open Source Legal Notices and Attribution content.

European Union (EU) Waste of Electrical and Electronic Equipment (WEEE) directive

The European Union's WEEE directive requires that products sold into EU countries must have the crossedout trash bin label on the product (or the package in some cases)

As defined by the WEEE directive, this cross-out trash bin label means that customers and end-users in EU countries should not dispose of electronic and electrical equipment or accessories in household waste.

Customers or end-users in EU countries should contact their local equipment supplier representative or service center for information about the waste collection system in their country.

Contact Us

The Solutions Support Center (SSC) is the primary contact for technical support included in your organization's service agreement with Motorola Solutions. Service agreement customers should be sure to call the SSC in all situations listed under Customer Responsibilities in their agreement, such as:

- Before reloading software
- To confirm troubleshooting results and analysis before taking action

Your organization received support phone numbers and other contact information appropriate for your geographic region and service agreement. Use that contact information for the most efficient response. However, if needed, you can also find general support contact information on the Motorola Solutions website, by following these steps:

- 1. Enter motorolasolutions.com in your browser.
- 2. Ensure that your organization's country or region is displayed on the page. Clicking or tapping the name of the region provides a way to change it.

3. Select "Support" on the motorolasolutions.com page.

Comments

Send questions and comments regarding user documentation to <u>documentation@motorolasolutions.com</u>. Provide the following information when reporting a documentation error:

- The document title and part number
- The page number or title of the section with the error
- · A description of the error

Motorola Solutions offers various courses designed to assist in learning about the system. For information, go to https://learning.motorolasolutions.com to view the current course offerings and technology paths.

Icon Conventions

The documentation set is designed to give the reader more visual clues. The following graphic icons are used throughout the documentation set.

DANGER: The signal word DANGER with the associated safety icon implies information that, if disregarded, will result in death or serious injury.

WARNING: The signal word WARNING with the associated safety icon implies information that, if disregarded, could result in death or serious injury, or serious product damage.

CAUTION: The signal word CAUTION with the associated safety icon implies information that, if disregarded, may result in minor or moderate injury, or serious product damage.

CAUTION: The signal word CAUTION may be used without the safety icon to state potential damage or injury that is not related to the product.

IMPORTANT: IMPORTANT statements contain information that is crucial to the discussion at hand, but is not CAUTION or WARNING. There is no warning level associated with the IMPORTANT statement.

NOTICE: NOTICE contains information more important than the surrounding text, such as exceptions or preconditions. They also refer the reader elsewhere for additional information, remind the reader how to complete an action (when it is not part of the current procedure, for instance), or tell the reader where something is on the screen. There is no warning level associated with a notice.

Style Conventions

The following style conventions are used:

Convention	Description
Bold	This typeface is used for names of, for instance, windows, buttons, and labels when these names appear on the screen (example: the Alarms Browser window). When it is clear that w e are referring to, for instance, a button, the name is used alone (example: Click OK).
Monospacing fo nt in bold	This typeface is used for words to be typed in exactly as they are shown in the text (example : In the Address field, type http://ucs01.ucs:9080/).
Monospacing fo nt	This typeface is used for messages, prompts, and other text displayed on the computer scre en (example: A new trap destination has been added).
<monospacing f<br="">ont in bold Italic ></monospacing>	This typeface is used with angle brackets as placeholders for a specific member of the group that the words represent (example: <router number="">).</router>
	NOTICE: In sequences to be typed in, the angle brackets are omitted to avoid confusion about whether to include the angle brackets in the text to be typed.
CAPITAL LETTE RS	This typeface is used for keyboard keys (example: Press Y, and then press ENTER).
Italic	This typeface is used for citations. A citation usually is the name of a document or a phrase f rom another document (example: Dimetra IP System Overview).
→	An \rightarrow (arrow pointing right) is used for indicating the menu or tab structure in instructions on how to select a certain menu item (example: File \rightarrow Save) or a certain sub-tab.

Chapter 1

RF Energy Exposure and Product Safety Guide

This document contains important safety and operating instructions. Read these instructions carefully and save them for future reference.

CAUTION:

Before using this accessory, read this guide which contains important operating instructions for safe usage and RF energy awareness and control for compliance with applicable standards and regulations.

The Remote Speaker Microphone (RSM), when attached to the radio, is restricted to occupational use only to satisfy FCC/ICNIRP RF energy exposure requirements. Before using this product, read the RF energy awareness information and operating instructions in the Product Safety and RF Exposure booklet enclosed with your radio to ensure compliance with RF energy exposure limits.

Acoustic Safety

Exposure to loud noises from any source for extended periods of time may temporarily or permanently affect your hearing. The louder the volume of the radio, the less time is required before your hearing can be affected. Hearing damage from loud noise is sometimes undetectable at first and can have a cumulative effect. Follow the following guidelines to protect your hearing:

- Use the lowest volume necessary to do your job.
- Turn up the volume only if you are in noisy surroundings.
- Turn down the volume before attaching the headset or earpiece.
- Limit the amount of time you use headsets or earpieces at high volume.
- When using the radio without a headset or earpiece, do not place the speaker of the radio directly against your ear.

• If you experience hearing discomfort, ringing in your ears, or muffled speech, you should stop listening to your radio through your headset or earpiece, and have your hearing checked by your doctor. To change the volume level, refer to Radio Product Safety Leaflet or CPS for Surveillance extra loud (xL) Kit Configurations.

Chapter 2

About PMMN4131 RM730 IMPRES Windporting RSM, Small (IP68)

2.1
RSM Feature
Figure 1: RSM Features




Table 1: RSM Feature Callouts

No	Descriptions
1	Push-to-Talk Button
2	Receive-only 3.5 mm Audio Jack (Non-threaded) covered by Dust Cover
3	Accessory Orange/Emergency Button) ¹

¹Check with your dealer for available programmable functions

Recommended Practices for RM730



- Cover the audio jack with a dust cover when it is not plugged with the earpiece. Do not fill water into the audio jack
- If water enters the audio jack, remove water by shaking the RSM.

Transmitting and Receiving


Figure 2: Transmitting



Figure 3: Receiving



Recommended Wearing Position Figure 4: RM730 Wearing Position



Attaching the RSM to the Radio

Procedure:

- 1. Attach the RSM connector to the side connector of the radio.
- 2. Secure the connection screw in a clockwise direction until tightened.


NOTICE: To ensure proper operation, turn off the radio before connecting the RSM to the radio. Connecting the RSM to the radio disables the speaker of the radio, but does not disable the microphone and PTT of the radio.


Procedure:

- 1. Unscrew and detach the RSM connector from the radio side connector.
- 2. Keep the dust cover inserted in the audio jack of the RSM when a secondary accessory is not being used.

Cable Management

Figure 5: Cable Management





NOTICE: To ensure optimum range and user experience, it is recommended to avoid crossing accessory cable with the radio antenna.

Optional Accessories

No	Descriptions
PMLN8120	Rx only xL Clear Tube Earpiece, 3.5 mm Jack

Replacement Parts




Table 2: Replacement Parts Callouts

No	Descriptions
1	Low Profile Swivel Clip (PMLN8121)
2	Dust Cover 10 pieces/pack (PMLN8523)
3	Coil Cord (PMKN4232)


Service and Warranty

Motorola Solutions offers warranty for your RSM. Refer to your Motorola Solutions dealer or point-of purchase for detailed information.




NOTICE: Warranty is void after customer replacement of any parts other than replacements parts listed.


Replacing Coil Cord



Removing Dust Cover




Inserting Dust Cover




Attaching Swivel Clip

Procedure:



- 1 Match and align the arrowhead icons and side wings.
- 2 Push down the top of the clip.
- 3 Simultaneously, push slide clip upward.

Detaching Swivel Clip



- 1 Push top of the clip to raise the clip to the highest position.
- 2 Lift up the bottom release latch.
- 3 Slide the clip to remove the clip.



EU Contact: Motorola Solutions, Czerwone Maki 82, 30-392 Krakow, Poland



NOVEMBER 2020

© 2020 Motorola Solutions, Inc. All rights reserved

Documents / Resources



Manuals+, home privacy