

msi G2712F G Series LCD Monitor



msi G2712F G Series LCD Monitor User Guide

[Home](#) » [MSI](#) » msi G2712F G Series LCD Monitor User Guide 

Contents

- [1 msi G2712F G Series LCD Monitor](#)
- [2 Package Contents](#)
- [3 Installing the Monitor Stand](#)
- [4 Adjusting the Monitor](#)
- [5 Monitor Overview](#)
- [6 Connecting the Monitor to the PC](#)
- [7 Professional](#)
- [8 Specifications](#)
- [9 Preset Display Modes](#)
- [10 Troubleshooting](#)
- [11 Safety Instructions](#)
- [12 FCC STATEMENT](#)
- [13 Green Product Features](#)
- [14 Documents / Resources](#)
 - [14.1 References](#)



msi G2712F G Series LCD Monitor



Getting Started

This chapter provides you with the information on hardware setup procedures. While connecting devices, be careful in holding the devices and use a grounded wrist strap to avoid static electricity.

Package Contents


Monitor	G2412F
	G2712F
Documentation	Quick Start Guide
Accessories	Stand with Screw(s)
	Stand Base with Screw(s)
	Stand Cover
	External Power Supply
	Power Cord
Cables	Premium High Speed HDMI™ Cable (Optional)

Important

- Contact your place of purchase or local distributor if any of the items are damaged or missing.
- Package contents may vary by country.
- The included power cord is exclusively for this monitor and should not be used with other products.

Installing the Monitor Stand

1. Leave the monitor in its protective foam packaging. Align the stand bracket to the monitor groove. Tighten the stand bracket with screws.
2. Align and push the stand cover towards the stand until it locks in place.
3. Connect the base to the stand and tighten the base screw to secure the base.
4. Make sure the stand assembly is properly installed before setting the monitor upright.



Important

- Place the monitor on a soft, protected surface to avoid scratching the display panel.
- Do not use any sharp objects on the panel.
- This product comes with NO protective film to be removed by the user! Any mechanical damages to the product including removal of the polarizing film may affect the warranty!






Adjusting the Monitor



- This monitor is designed to maximize your viewing comfort with its adjustment capabilities.

Important

Avoid touching the display panel when adjusting the monitor.


**Monitor Overview**



1	Power Button
2	Navi Key
3	Kensington Lock
4	Power Jack
5	 <p>HDMI™ Connector <small>HIGH-DEFINITION MULTIMEDIA INTERFACE</small></p> <p>Supports HDMI™ CEC, 1920×1080@180Hz as specified in HDMI™ 2.0b.</p>
6	 <p>HDMI™ Connector <small>HIGH-DEFINITION MULTIMEDIA INTERFACE</small></p> <p>Supports 1920×1080@180Hz as specified in HDMI™ 2.0b.</p>
7	<p>DisplayPort</p> <p>Supports 1920×1080@180Hz as specified in DisplayPort 1.2a.</p>
8	Headphone Jack

Connecting the Monitor to the PC

1. Turn off your computer.
2. Connect the video cable from the monitor to your computer.
3. Assemble the external power supply & power cord. (Figure A)
4. Connect the external power supply to the monitor power jack. (Figure B)
5. Plug the power cord into the electrical outlet. (Figure C)
6. Turn on the monitor. (Figure D)
7. Power on the computer and the monitor will auto-detect the signal source.



OSD Setup


This chapter provides you with essential information on OSD Setup.

Important

All information is subject to change without prior notice.

Navi Key

The monitor comes with a Navi Key, a multi-directional control that helps navigate the On-Screen Display (OSD) menu.



Up/Down/Left/Right

- selecting function menus and items
- adjusting function values
- entering into/exiting from function menus


Press (OK)

- launching the On-Screen Display (OSD)
- entering submenus
- confirming a selection or setting

Hot Key

- Users may enter into preset function menus by moving the Navi Key up, down, left or right when the OSD menu is inactive.
- Users may customize their own Hot Keys to enter into different function menus.

OSD Menus




Gaming

1st Level Menu	2nd/3rd Level Menu	Description
Game Mode	User	<ul style="list-style-type: none"> · Use the Up or Down Button to select and preview mode effects. · Press the OK Button to confirm and apply your mode type.
	FPS	
	Racing	
	RTS	
	RPG	
Night Vision	OFF	<ul style="list-style-type: none"> · This function optimizes background brightness and is recommended for FPS games.
	Normal	
	Strong	
	Strongest	
	A.I.	
Response Time	Normal	<ul style="list-style-type: none"> · Setting to Fastest will reach the shortest response time and help improve blurred images when playing very fast games.
	Fast	
	Fastest	

1st Level Menu	2nd/3rd Level Menu	Description
	OFF	<ul style="list-style-type: none"> · Activating MPRT will affect:

MPRT	ON		<table><tr><th>Affected Function</th><th>Function Status</th></tr><tr><td>» Response Time » Brightness</td><td>Unable to select</td></tr><tr><td>» Adaptive-Sync » HDCR</td><td>Set to OFF</td></tr></table> <p>· MPRT is available when the refresh rate is over 85Hz.</p>	Affected Function	Function Status	» Response Time » Brightness	Unable to select	» Adaptive-Sync » HDCR	Set to OFF
Affected Function	Function Status								
» Response Time » Brightness	Unable to select								
» Adaptive-Sync » HDCR	Set to OFF								
Refresh Rate	Location	Left Top	· Location is adjustable in OSD Menu. Press the OK Button to confirm and apply your Refresh Rate Location. · This monitor follows and works at the Operating System's preset Screen Refresh Rate.						
		Right Top							
		Left Bottom							
		Right Bottom							
	OFF								
ON									
Alarm Clock	Location	Left Top	· After setting the time, press the OK Button to activate the timer. · Users have to manually restore their preset Alarm Clock after any AC power loss and reconnection.						
		Right Top							
		Left Bottom							
		Right Bottom							
	OFF								
	15:00	00:01 ~ 99:59							
	30:00								
	45:00								
	60:00								
None									

Screen Assistance		<ul style="list-style-type: none">· Users can adjust Screen Assistance in any mode.			
Adaptive-Sync	OFF	<ul style="list-style-type: none">· Adaptive-Sync prevents screen tearing.			
	ON	<ul style="list-style-type: none">· Activating Adaptive-Sync will affect: <table><tr><th>Affected Function</th><th>Function Status</th></tr><tr><td>» MPRT</td><td>Set to OFF</td></tr></table>	Affected Function	Function Status	» MPRT
Affected Function	Function Status				
» MPRT	Set to OFF				

Professional

1st Level Menu	2nd Level Menu	Description								
Pro Mode	User	<ul style="list-style-type: none">· Use the Up or Down Button to select and preview mode effects.· Press the OK Button to confirm and apply your mode type.								
	Anti-Blue									
	Movie									
	Office									
	Eco									
Low Blue Light	OFF	<ul style="list-style-type: none">· Low Blue Light protects your eyes against blue light. When enabled, Low Blue Light adjusts the screen colour temperature to a more yellow glow.· When Pro Mode is set to Anti-Blue, it is mandatory to enable Low Blue Light.								
	ON									
HDCR	OFF	<ul style="list-style-type: none">· HDCR enhances image quality by increasing the contrast of images.· Activating HDCR will affect: <table><tr><th>Affected Function</th><th>Function Status</th></tr><tr><td>» Brightness</td><td>Unable to select</td></tr><tr><td>» MPRT</td><td>Set to OFF</td></tr></table>	Affected Function	Function Status	» Brightness	Unable to select	» MPRT	Set to OFF		
	Affected Function		Function Status							
» Brightness	Unable to select									
» MPRT	Set to OFF									
	ON									
MPRT	OFF	<ul style="list-style-type: none">· Activating MPRT will affect: <table><tr><th>Affected Function</th><th>Function Status</th></tr><tr><td>» Response Time</td><td rowspan="2">Unable to select</td></tr><tr><td>» Brightness</td></tr><tr><td>» Adaptive-Sync</td><td rowspan="2">Set to OFF</td></tr><tr><td>» HDCR</td></tr></table> <ul style="list-style-type: none">· MPRT is available when the refresh rate is over 85Hz.	Affected Function	Function Status	» Response Time	Unable to select	» Brightness	» Adaptive-Sync	Set to OFF	» HDCR
	Affected Function		Function Status							
» Response Time	Unable to select									
» Brightness										
» Adaptive-Sync	Set to OFF									
» HDCR										
	ON									
Image Enhancement	OFF	<ul style="list-style-type: none">· Image Enhancement enhances image edges to improve the image acutance.								
	Weak									
	Medium									
	Strong									
	Strongest									

Image

1st Level Menu	2nd/3rd Level Menu		Description
Brightness	0-100		· Properly adjust Brightness according to the surrounding lighting.
Contrast	0-100		· Properly adjust Contrast to relax your eyes.
Sharpness	0-5		· Sharpness improves the clarity and details of images.
Colour Temperature	Cool		· Use the Up or Down Button to select and preview mode effects. · Press the OK Button to confirm and apply your mode type.
	Normal		
	Warm		
	Customization	R (0-100)	
		G (0-100)	
		B (0-100)	
Screen Size	Auto		· Users can adjust Screen Size in any mode, any resolution and any screen refresh rate.
	4:3		
	16:9		

Input Source

1st Level Menu	2nd Level Menu	Description
HDMI™ 1		· Users can adjust the Input Source in any mode.
HDMI™ 2		
DP		
Auto Scan	OFF	· Users can use the Navi Key to select Input Source at below status: • While “Auto Scan” is set to “OFF” with the monitor at power saving mode; • While the “No Signal” message box is shown on the monitor.
	ON	

Navi Key



1st Level Menu	2nd Level Menu	Description
Up Down Left Right	OFF	· All Navi Key items can be adjusted via OSD Menus.
	Brightness	
	Game Mode	
	Screen Assistance	
	Alarm Clock	
	Input Source	
	Refresh Rate	
	Info. On Screen	
	Night Vision	

Setting

1st Level Menu	2nd Level Menu	Description
Language		<ul style="list-style-type: none"> · Users have to press the OK Button to confirm and apply the Language setting. · Language is an independent setting. Users' language settings will override the factory default. When users set Reset to Yes, Language will not be changed.
	English	
	Français	
	Deutsch	
	Italiano	
	Español	
	■■■	
	Русский	
	Português	
	Bahasa Indonesia	
	Türkçe	
	(More languages coming soon)	
Transparency	0~5	· Users can adjust Transparency in any mode.
OSD Time Out	5~30s	· Users can adjust OSD Time Out in any mode.
Power Button	OFF	· When set to OFF, users can press the power button to turn off the monitor.
	Standby	· When set to Standby, users can press the power button to turn off the panel and backlight.

1st Level Menu	2nd Level Menu	Description
Info. On Screen	OFF	<ul style="list-style-type: none"> The information on the monitor status will be shown on the right side of the screen.
	ON	
HDMI™ CEC	OFF	<ul style="list-style-type: none"> HDMI™ CEC (Consumer Electronics Control) supports Sony PlayStation®, Nintendo® Switch™, Xbox Series X S consoles and various audio-visual devices that are CEC-capable. If HDMI™ CEC is set to ON: <ul style="list-style-type: none"> The monitor will automatically power on when the CEC device is turned on. The CEC device will enter power-saving mode when the monitor is turned off. When Sony PlayStation®, Nintendo® Switch™, or Xbox Series X S console is connected, Game Mode and Pro Mode will be automatically set to default modes and can be adjusted to users' preferred modes later.
	ON	
Reset	YES	<ul style="list-style-type: none"> Users can Reset and restore settings to the original OSD Default in any mode.
	NO	

Specifications

Monitor	G2412F	G2712F
Size	23.8 inch	27 inch
Curvature	Flat	
Panel Type	Rapid IPS	Ultra Rapid IPS
Resolution	1920 x 1080 (FHD)	
Aspect Ratio	16:9	
Brightness (nits)	300 nits (Typ.)	
Contrast Ratio	1000:1	
Refresh Rate	180Hz	
Response Time	<ul style="list-style-type: none"> · 1ms (GTG) · 1ms (MPRT) 	
I/O	<ul style="list-style-type: none"> · DisplayPort x 1 · HDMI™ Connector x 2 · Headphone Jack x 1 	
View Angles	178° (H), 178° (V)	
DCI-P3*/ sRGB	83% / 107%	76% / 96%
Surface Treatment	Anti-glare	
Display Colors	16.7M (6 bits + FRC)	16.7M (8 bits)
Monitor Power Options	20V  2.25A	
External Power Supply**	Model: ADPC2045	
Power Input	100~240Vac, 50~60Hz, 1.5A	
Power Output	20V  2.25A	
Adjustment (Tilt)	-5° ~ 20°	
Kensington Lock	Yes	
VESA Mounting	<ul style="list-style-type: none"> · Plate Type: 100 x 100 mm · Screw Type: M4 x 10 mm • Thread Diameter: 4 mm • Thread Pitch: 0.7 mm • Thread Length: 10 mm 	

Monitor		G2412F	G2712F
Dimension (W x H x D)		540 x 423 x 229 mm	614 x 456x 229 mm
Weight	Net	3.3 Kg	4.2 Kg
	Gross	5.0 Kg	6.1 Kg
Environment	Operating	· Temperature: 0°C ~ 40°C · Humidity: 20% ~ 90%, non-condensing · Altitude: 0 ~ 5000m	
	Storage	· Temperature: -20°C ~ 60°C · Humidity: 10% ~ 90%, non-condensing	

- Based on CIE1976 test standards.
- External Power Supply may vary by country.

Preset Display Modes

Important

All information is subject to change without prior notice.

Standard	Resolution		HDMI™	DP
VGA	640×480	@60Hz	V	V
		@67Hz	V	V
		@72Hz	V	V
		@75Hz	V	V
SVGA	800×600	@56Hz	V	V
		@60Hz	V	V
		@72Hz	V	V
		@75Hz	V	V
XGA	1024×768	@60Hz	V	V
		@70Hz	V	V
		@75Hz	V	V
SXGA	1280×1024	@60Hz	V	V
		@75Hz	V	V
WXGA+	1440×900	@60Hz	V	V
WSXGA+	1680×1050	@60Hz	V	V
Full HD	1920×1080	@60Hz	V	V
		@120Hz	V	V
		@144Hz	V	V
		@180Hz	V	V
Video Timing Resolution	480P		V	V
	720P		V	V
	1080P	@60Hz	V	V
		@120Hz	V	V

Troubleshooting

The power LED is off

- Press the monitor power button again.
- Check if the monitor power cable is properly connected.

No image

- Check if the computer graphics card is properly installed.
- Check if the computer and monitor are connected to electrical outlets and are turned on.
- Check if the monitor signal cable is properly connected.
- The computer may be in Standby mode. Press any key to activate the monitor.

The screen image is not properly sized or centred

- Refer to Preset Display Modes to set the computer to a setting suitable for the monitor to display.

No Plug & Play

- Check if the monitor power cable is properly connected.
- Check if the monitor signal cable is properly connected.
- Check if the computer and graphics card are Plug & Play compatible.

The icons, font or screen are fuzzy, blurry or have colour problems

- Avoid using any video extension cables.
- Adjust brightness and contrast.
- Adjust RGB colour or tune colour temperature.
- Check if the monitor signal cable is properly connected.
- Check for bent pins on the signal cable connector.

The monitor starts flickering or shows waves

- Change the refresh rate to match the capabilities of your monitor.
- Update your graphics card drivers.
- Keep the monitor away from electrical devices that may cause electromagnetic interference (EMI).

Safety Instructions

- Read the safety instructions carefully and thoroughly.
- All cautions and warnings on the device or User Guide should be noted.
- Refer servicing to qualified personnel only.

Power

- Make sure that the power voltage is within its safety range and has been adjusted properly to the value of 100~240V before connecting the device to the power outlet.
- If the power cord comes with a 3-pin plug, do not disable the protective earth pin from the plug. The device must be connected to an earthed main socket outlet.
- Please confirm the power distribution system in the installation site shall provide the circuit breaker rated 120/240V, 20A (maximum).
- Always disconnect the power cord or switch the wall socket off if the device is left unused for a certain time to

achieve zero energy consumption.

- Place the power cord in a way that people are unlikely to step on it. Do not place anything on the power cord.
- If this device comes with an adapter, use only the MSI-provided AC adapter approved for use with this device.

Environment

- To reduce the possibility of heat-related injuries or overheating the device, do not place the device on a soft, unsteady surface or obstruct its air ventilators.
- Use this device only on a hard, flat and steady surface.
- To prevent the device from tipping over, secure the device to a desk, wall or fixed object with an anti-tip fastener that helps to properly support the device and keep it safe in place.
- To prevent fire or shock hazards, keep this device away from humidity and high temperatures.
- Do not leave the device in an unconditioned environment with a storage temperature above 60°C or below -20°C, which may damage the device.
- The maximum operating temperature is around 40°C.
- When cleaning the device, be sure to remove the power plug. Use a piece of soft cloth rather than industrial chemicals to clean the device. Never pour any liquid into the opening; that could damage the device or cause electric shock.
- Always keep strong magnetic or electrical objects away from the device.
- If any of the following situations arise, let the device be checked by service personnel:
 - The power cord or plug is damaged.
 - Liquid has penetrated the device.
 - The device has been exposed to moisture.
 - The device does not work well or you can not get it working according to the User Guide.
 - The device has dropped and damaged.
 - The device has obvious signs of breakage.

TÜV Rheinland Certification

TÜV Rheinland Low Blue Light Certification

Blue light has been shown to cause eye fatigue and discomfort. MSI now offers monitors with TÜV Rheinland Low Blue Light certification to ensure users' eye comfort and well-being. Please follow the instructions below to reduce the symptoms from extended exposure to the screen and blue light.

- Place the screen 20 – 28 inches (50 – 70 cm) away from your eyes and a little below eye level.
- Consciously blinking the eyes now and then will help to reduce eye strain after extended screen time.
- Take breaks for 20 minutes every 2 hours.
- Look away from the screen and gaze at a distant object for at least 20 seconds during breaks.
- Make stretches to relieve body fatigue or pain during breaks.
- Turn on the optional Low Blue Light function.



www.tuv.com.

TÜV Rheinland Flicker Free Certification



www.tuv.com.

- TÜV Rheinland has tested this product to ascertain whether the display produces visible and invisible flicker for the human eye and therefore strains the eyes of users.
- TÜV Rheinland has defined a catalogue of tests, which sets out minimum standards at various frequency ranges. The test catalogue is based on internationally applicable standards or standards common within the industry and exceeds these requirements.
- The product has been tested in the laboratory according to these criteria.
- The keyword "Flicker Free" confirms that the device has no visible and invisible flicker defined in this standard within the range of 0 – 3000 Hz under various brightness settings.
- The display will not support Flicker-Free when Anti Motion Blur/MPRT is enabled. (The availability of Anti Motion Blur/MPRT varies by product.)

Regulatory Notices

CE Conformity

This device complies with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility (2014/30/EU), Low-voltage Directive (2014/35/EU), ErP Directive (2009/125/EC) and RoHS directive (2011/65/EU). This product has been tested and found to comply with the harmonized standards for Information Technology Equipment published under Directives of the Official Journal of the European Union.



FCC STATEMENT

FCC-B Radio Frequency Interference Statement



This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used under the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures listed below:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice 2

Shielded interface cables and AC power cord, if any, must be used to comply with the emission limits.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

MSI Computer Corp

- 901 Canada Court, City of Industry, CA 91748, USA
- (626) 913-0828
- www.msi.com.

WEEE Statement

Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2012/19/EU, products of "electrical and electronic equipment" cannot be discarded as municipal waste anymore and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life.



Chemical Substances Information

In compliance with chemical substances regulations, such as the EU REACH Regulation (Regulation EC No. 1907/2006 of the European Parliament and the Council), MSI provides the information on chemical substances in products at:

<https://csr.msi.com/global/index>.

RoHS Statement

Japan JIS C 0950 Material Declaration

A Japanese regulatory requirement, defined by specification JIS C 0950, mandates that manufacturers provide material declarations for certain categories of electronic products offered for sale after July 1, 2006.

<https://csr.msi.com/global/Japan-JIS-C-0950-Material-Declarations>.

India RoHS

This product complies with the “India E-waste (Management and Handling) Rule 2016” and prohibits the use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

Turkey EEE Regulation

Conforms to the EEE Regulations of the Republic Of Turkey

Ukraine Restriction of Hazardous Substances

The equipment complies with the requirements of the Technical Regulation, approved by the Resolution of Cabinet of the Ministry of Ukraine as of 10 March 2017, № 139, in terms of restrictions for the use of certain dangerous substances in electrical and electronic equipment.

Vietnam RoHS

As of December 1, 2012, all products manufactured by MSI comply with Circular 30/2011/TT-BCT temporarily regulating the permitted limits for many hazardous substances in electronic and electric products.

Green Product Features

- Reduced energy consumption during use and stand-by
- Limited use of substances harmful to the environment and health
- Easily dismantled and recycled
- Reduced use of natural resources by encouraging recycling
- Extended product lifetime through easy upgrades
- Reduced solid waste production through a take-back policy

Environmental Policy

- The product has been designed to enable proper reuse of parts and recycling and should not be thrown away at its end of life.
- Users should contact the local authorized point of collection for recycling and disposing of their end-of-life products.
- Visit the MSI website and locate a nearby distributor for further recycling information.
- Users may also reach us at gpcontdev@msi.com for information regarding proper disposal, take-back, recycling, and disassembly of MSI products.



Warning!

Overuse of screens is likely to affect eyesight.

Recommendations

1. Take a 10-minute break for every 30 minutes of screen time.
2. Children under 2 years of age should have no screen time. For children aged 2 years and over, screen time should be limited to less than one hour per day.

Copyright and Trademarks Notice

Copyright © Micro-Star Int'l Co., Ltd. All rights reserved. The MSI logo used is a registered trademark of Micro-Star Int'l Co., Ltd. All other marks and names mentioned may be trademarks of their respective owners. No warranty as to accuracy or completeness is expressed or implied. MSI reserves the right to make changes to this document without prior notice.


The terms HDMI™, HDMI™ High-Definition Multimedia Interface, HDMI™ Trade dress and the HDMI™ Logos are trademarks or registered trademarks of HDMI™ Licensing Administrator, Inc.



Technical Support


If a problem arises with your product and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please visit <https://www.msi.com/support/> for further guidance.

Documents / Resources

 G Series LCD Monitor G2712F G2712F G2712F	msi G2712F G Series LCD Monitor [pdf] User Guide G2712F G Series LCD Monitor, G2712F, G Series LCD Monitor, LCD Monitor, Monitor
--	---

References

-  [MSI - Redirect](#)
-  [csr](#)

-  [csr](#)
-  [Support | MSI Global](#)
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.