


myFIRSTECH
DL-CH12 Cherokee
TIP Start



myFirstech DL-CH12 Cherokee TIP Start Instruction Manual

[Home](#) » [myFirstech](#) » myFirstech DL-CH12 Cherokee TIP Start Instruction Manual 

Contents

- 1 myFirstech DL-CH12 Cherokee TIP Start
- 2 FIRMWARE
- 3 FACILITY
- 4 MODULE PROGRAMMING PROCEDURE – TIP-START
- 5 TAKE OVER PROCEDURE – TIP-START – TO THE VEHICLE OWNER
- 6 Documents / Resources
 - 6.1 References



myFirstech DL-CH12 Cherokee TIP Start



- FT-DAS Required for manual transmission.
- BOTH Red & Red/White MUST be connected with high current application.

Jumper Setting			
Parking Light	<input type="checkbox"/>	<input type="checkbox"/>	(+)Door Trigger In
Accessory	<input type="checkbox"/>	<input type="checkbox"/>	(-)Door Trigger In
Ignition (Default)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	(Default)
Trunk	<input type="checkbox"/>	<input type="checkbox"/>	Starter
Starter	<input type="checkbox"/>	<input type="checkbox"/>	Ignition
Parking Light (Default)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Accessory (Default)

CM7000/7200



Cut loop for A/T




CM-900S/900AS

CM900AS/900S Jumper



START
ACC
IGN1



- LED programming error codes Module
- LED flashes RED during programming 1x – CAN error 2x
- Key code not learned 3x – No ON 4x
- Without immobilizer, check CAN/key 5x – VIN error, check
- CAN wiring 6x – See error 4x 7x
- KLON error 8x – No ON, check connection

WARNING: READ BEFORE REMOTE STARTING THE VEHICLE











IMPORTANT










All vehicle doors must be closed and locked before the remote start sequence. Failure to comply will result in a remote starter malfunction.

MODULE PROGRAMMING PROCEDURE – TIP-START

NOTE

I **IMPORTANT:** The hood must be closed.

- 1  Close driver door.
Re-open driver door to wake up data bus.
- 2  Press UNLOCK on OEM remote.
- 3  Wait, LED will flash BLUE once [1x]. If LED does not flash BLUE, repeat step 2.
- 4  Insert key into ignition.
- 5  Wait, LED will flash BLUE twice [2x].
- 6  Turn key to ON position.
- 7  Wait, LED will turn solid RED.
If LED flashes BLUE rapidly, proceed to step 13.
- 8  Turn key to OFF position.
- 9  Remove key.
- 10  Repeat steps 4 to 9, eight times [8x].

- 11  Turn key to ON position.
- 12  Wait, LED will flash BLUE rapidly.
- 13  Turn key to OFF position.
- 14  **WARNING:**
Disconnect power last.
Disconnect module from vehicle.
- 15  Connect module to computer
and proceed with extended
programming.
- 16  **WARNING:** Do not press module
programming button.
Connect power first.
Connect module to vehicle.
- 17  Turn key to ON position.
- 18  Wait, LED will turn solid BLUE
for 2 seconds.
- 19  Turn key to OFF position.
- 20 **Module Programming
Procedure completed.**

TAKE OVER PROCEDURE – TIP-START – TO THE VEHICLE OWNER

NOTE

All vehicle doors must be closed and locked before the remote start sequence.

1. Press UNLOCK on the after-market remote.



TIME RESTRICTION COMING UP !

2. TIME RESTRICTIN Within 45 SECONDS from the previous step: Open vehicle door. Enter vehicle. Close the vehicle door.




3. Insert key into the ignition. Turn the key to the ON position. Press and release the BRAKE pedal.



4. Take-over procedure completed. Failure to follow the procedure within the time restriction will result in vehicle engine shutdown.

Documents / Resources

	myFirstech DL-CH12 Cherokee TIP Start [pdf] Instruction Manual FTI-CDP1-CH12, DL-CH12, DL-CH12 Cherokee TIP Start, DL-CH12, Cherokee TIP Start, TIP Start, Start
---	---

References

- [User Manual](#)

[Manuals+](#). [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.