myQ X SW513 Print Management Solution



myQ X SW513 Print Management Solution Instructions

Home » MyQ X » myQ X SW513 Print Management Solution Instructions ™



Contents

- 1 myQ X SW513 Print Management Solution
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 Mayco Stoneware Dry (SD) Mixing **Instructions**
- 5 Documents / Resources
 - **5.1 References**



myQ X SW513 Print Management Solution



Product Information

Specifications

• Product Name: Mayco Stoneware Dry (SD)

• Recommended Specific Gravity: 1.47-1.51

• Firing Temperature: Cone 5-10 (2167F-2345F / 1186C-1285C)

Product Usage Instructions

Mixing Instructions:

- 1. Always wear a NIOSH-approved respirator when handling dry glazes.
- 2. Gently tumble the unopened bag to redistribute materials. Sieving is not necessary.
- 3. Mix one 10 lb bag of dry material into at least 10 pints of water. Stir thoroughly.
- 4. Add additional water until the desired specific gravity is reached. Specific gravity preference will vary between studios, persons, and practices.
- 5. Our recommended specific gravity is in the range of 1.47-1.51. Adjust for different dipping times or layering practices.

Application Instructions:

- 1. Stir well before use.
- 2. Immerse the ware for 1-2 seconds.
- 3. Allow the glaze to dry before applying additional coats if desired.
- 4. When using Stoneware Dry Crystal glazes, pour the glaze over your piece using a cup or ladle.
- 5. While the glaze is wet, use a fan brush to evenly distribute the crystals; avoid heavy crystal loading on the

bottom third of your piece.

Firing Instructions:

- Fire to preferred temperature, cone 5-10 (2167F-2345F/1186C-1285C).
- Testing is recommended as factors such as clay body, the thickness of application, the firing process, and temperature will affect the fired results.

FAQ

• Q: Can I mix the dry material with less water than recommended?

A: It is best to follow the recommended water-to-material ratio to achieve the desired specific gravity for optimal results.

Q: How long should I wait for the glaze to dry before applying additional coats?

A: Allow the glaze to dry completely before applying additional coats to prevent uneven application and bubbling during firing.

Mayco Stoneware Dry (SD) Mixing Instructions

- Always wear a NIOSH-approved respirator when handling dry glazes.
- Gently tumble the unopened bag to redistribute materials. Sieving is not necessary.
- Mix one 10 lb bag of dry material into at least 10 pints of water. Stir thoroughly.
- Add additional water until the desired specific gravity is reached. Specific gravity preference will vary between studios, persons, and practices.
- Our recommended specific gravity is in the range of 1.47-1.51. This is for a 1 second dip time, you may want to mix to a lower specific gravity if you layer glazes or tend to dip longer.
- Stir well before use. Immerse the ware for 1-2 seconds. Allow the glaze to dry before applying additional coats if desired.
- When applying Stoneware Dry Crystal glazes, use a cup or ladle to pour the glaze over your piece. While the glaze is wet, you may use a fan brush to evenly distribute the crystals; avoid heavy crystal loading on the bottom third of your piece.
- Fire to preferred temperature, cone 5-10 (2167F-2345F / 1186C-1285C). Testing is recommended. The choice
 of clay body, thickness of application, firing process and temperature will affect the fired results.

Documents / Resources



myQ X SW513 Print Management Solution [pdf] Instructions

SW513, SD513, SW513 Print Management Solution, SW513, Print Management Solution, Management Solution, Solution

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.