

naxa NSH-6000 Smart Doorbell with WiFi User Manual

Home » NAXA » naxa NSH-6000 Smart Doorbell with WiFi User Manual



naxa NSH-6000 Smart Doorbell with WiFi

Contents

- 1 DOWNLOAD SMART LIFE APP
- **2 REGISTERING AN ACCOUNT**
- **3 LOGGING IN TO AN ACCOUNT**
- **4 VERIFYING VIA TEXT OR**

EMAIL

- **5 FORGOT YOUR PASSWORD**
- **6 HOME MANAGEMENT**
- **7 ADDING DEVICES**
- **8 OPERATING DEVICES**
- 9 SPECIFICATIONS
- **10 FCC NOTICE**
- 11 SUPPORT
- 12 Documents / Resources
- 13 Related Posts

DOWNLOAD SMART LIFE APP


Begin by downloading the SMART LIFE APP. To do so, either search for "Smart Life" in any app store on your device, or simply scan the QR code shown below (FIG. 2-1).

SMART LIFE QR CODE



REGISTERING AN ACCOUNT

- 1. After downloading the SMART LIFE APP, open the app and you will see the home screen shown below (FIG. 3-1)
- 2. If you do not already have an account, select "Register" to register a new one.
- 3. Read over the privacy policy carefully and select "Agree" or "Disagree to continue (FIG. 3-2).





HOME SCREEN FIG. 3-1

PRIVACY POLICY FIG. 3-2

- 4. When registering for a new account, the system will automatically identify the country/region you are currently in (FIG. 4-1).
- 5. You will be asked to enter your mobile phone number or email. After entering the requested information, select "Continue" and a verification code will be sent to the entered mobile number or email address. Next, enter the verification code on the screen (FIG. 4-2).





REGISTER SCREEN FIG. 4-1


VERIFICATION CODE FIG. 4-2

6. Then, enter a password and select "DONE to complete registration.

LOGGING IN TO AN ACCOUNT

If you already have a pre-existing SMART LIFE account, select -Log In" on the home screen and you will be directed to the log in screen shown below (FIG. 5-1).

- 1. The system will automatically identify the country/region you are located in; however, you may also choose to manually input your country/region.
- 2. Enter your registered mobile number or email address and password to log in to your account.




LOG IN SCREEN FIG. 5-1

NOTE: Third Party Social Log In (China Only) If you haved already installed WeChat onto your mobile phone, click the WeChat icon in Social Log In and proceed through the authorization page to log in.

VERIFYING VIA TEXT OR EMAIL

If you do not remember your log in information, you may also access your account by verifying via text message or email.

- 1. Select "Verify via SMS" from the log in screen (FIG. 6-1).
- 2. Enter your registered mobile number or email address into the verification screen and select "Continue" (FIG. 6-2).






LOG IN SCREEN FIG. 6-1 VERIFY VIA SMS FIG. 6-2

3. Input the verification code that is sent to your mobile number or email ad-dress to access your account.

FORGOT YOUR PASSWORD

If you forgot your password, you can reset your password by following the password retrieval procedure.

- 1. Select "Forgot Password" from the log in screen (FIG. 7-1).
- 2. Enter your registered mobile number or email address into the Forgot Pass-word screen and select "Continue".
- 3. Input the verification code that is sent to your mobile number or email ad-dress to access your account.
- 4. Input a new password into the screen and select "Done" to set new pass-word (FIG. 7-2).







LOG IN SCREEN FIG. 7-1

VERIFY VIA SMS FIG. 7-2

HOME MANAGEMENT

- 1. When logged in, select "Activate Smart Living" to go to the "Add Home" page (Fig. 8-1).
- 2. Manually set the "Name" as needed. Next, select "Location" to go to the map. Then, move the household icon manually to change the address. Finally, select "OK" to confirm the address (FIG. 8-2).







ADD HOME FIG. 8-1

HOME MAP FIG. 8-2

- 3. Select "Add Room" to add a room (FIG. 9-1). Then, Click "OK in the top right corner of the screen to complete room settings.
- 4. Room settings can be changed anytime by selecting "My Home" (FIG. 9-2).







ADD ROOM FIG. 9-1 MY HOME SCREEN FIG. 9-2

Select the drop-down arrow in the top left corner of the "My Home" screen to add a home and manage existing homes (FIGS. 10-1 and 10-2).

One account can manage multiple homes at a time. The user can operate a device in a home by selecting it in the home's menu.






MY HOME SCREEN FIG. 10-1

HOME MANAGEMENT FIG. 10-2

Select a home to access the "Home Settings" (FIG. 11-1). In the "Home Settings" screen you have access to a wide variety of features, such as:

- 1. The ability to combine and classify administrative access of different individuals to devices. All devices and smart scenarios in a home for home members without having to complete the sharing settings each time.
- 2. Allow other home members to enjoy control of the home's smart devices, but with old the ability to modify, add, or delete a device.
- 3. Add/Delete rooms in a home and manage all room settings for a home in one place.




HOME SETTINGS FIG. 11-1

ADDING DEVICES

Select "Add Device" on the My Home page, or select the "+" in the top right hand corner of the screen, to proceed to the "All Devices" page (FIG. 12-1).

Devices can be managed, added, or deleted as needed from the "All Devices" Page (FIG. 12-2).






MY HOME SCREEN FIG. 12-1

DEVICES SCREEN FIG. 12-2


- 1. From the "Add Device" screen, select "Next Step" (Fig. 13-1).
- 2. Insert the password for your wireless router (This device is only for 2.4GHz wifi networks). Then, select "Confirm" (FIG. 13-2).



ADD DEVICE SCREEN FIG. 13-1

CONNECTING WIFI FIG. 13-2


- 3. When the "Scan with the camera" screen appears, select "Continue" (Fig. 14-1).
- 4. Align the QR code with the camera lens of your device at a distance be-tween 20-30 cm away, until you hear a humming sound. Then select" Heard the beep" (FIG. 14-2).



SCAN WITH CAMERA FIG. 14-1

ALIGNING QR CODE FIG. 14-2

5. Connect to the internet, see images below, in order to change your device's name and/or place the device in specific rooms of your home (FIGS. 15-1 and 15-2).




CONNECTING INTERNET FIG. 15-1

DEVICE ADDED FIG. 15-2


OPERATING DEVICES


Once your device has been set up through the SMART LIFE APP, You can access the devices in your home and take full advantage of the APP features shown below (FIG. 16-1).



DEVICE FEATURES FIG. 16-1

For more information on your device, select "..." in the top right hand corner of the screen (FIG. 17-1). From here, you can set up your device according to your personal preferences (FIG. 17-2).





DEVICE SCREEN FIG. 17-1

DEVICE SETTINGS FIG. 17-2

Remove Device

SPECIFICATIONS

Chip Processor: H13518E V200 Sensor Type: 1/2.7" CMOS, PIR Video Compression: H.264

Resolution: 2MP/1080P (1920 x 1080) Viewing Angle: 135-Degree Wide Angle View Infrared Night Vision: Infrared LED 850nm

Memory Card: Up to 64GB WiFi: Only 2.4GHz, 802.11b/g/n

Support: Android/10S Battery: Two 18650 Battery

FCC NOTICE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. **Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may

cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

SUPPORT

If you have problems with your device, please consult the instructions in this manual, Please also visit us on the web at www.naxa.com to get up to the minute news, alerts, and documentation for your device. For additional assis-tance, please contact Naxa Technical Support.

Naxa Technical Support

2320 East 49th St. Vernon, CA 90058 (866) 411-6292 http://www.naxa.com/supportcenter/



Documents / Resources



naxa NSH-6000 Smart Doorbell with WiFi [pdf] User Manual

SD10, 2A3JG-SD10, 2A3JGSD10, NSH-6000 Smart Doorbell with WiFi, NSH-6000, Smart Doorbell with WiFi, Smart Doorbell, WiFi Doorbell, Doorbell

Manuals+,