


NEBULA Cosmos Max User Guide


Home » **NEBULA** » **NEBULA** Cosmos Max User Guide

NEBULA Cosmos Max




Contents [hide 1 Charge Your Projector 2 Prepare Remote Control 3 Power On / Off 4 Adjust The Focus 5 Control Buttons 6 Download Nebula Connect App 7 Chromecast™ 8 Play Video From HDMI / USB Devices 9 Important Safety Instructions 10 Notice 11 Documents / Resources 11.1 References 12 Related Posts

Charge Your Projector




Prepare Remote Control

1. Slide down to open the battery compartment.




2. Insert new batteries, matching the polarity (+ / -) as indicated.



Power On / Off

Press POWER to power on. Press and hold POWER. A menu pops up. Select Power Off to turn off the projector.


When the projector is in standby mode, press POWER to turn on / off the projector.




Adjust The Focus

Press the button on the remote control to adjust focus.





Control Buttons




Remote Control: Nebula RC

Model: D0413

Download Nebula Connect App

1. Download the Nebula Connect app from the App Store (iOS devices) or Google Play (Android devices) to control your projector.

- 2. Enable Bluetooth on your smartphone.
- 3. Open the **Nebula Connect** app, and follow the on-screen instructions to complete the connection setup.




Chromecast™

Wirelessly cast movies, games, and music from your phone to Nebula Cosmos Max.


- 1. Play a video clip on your phone and then tap the cast icon on the video screen.
- 2. Select the device "D2150" you want to cast to.
- This projector will mirror the screen of the connected phone or computer.




Make sure Nebula Cosmos Max and your phone are connected to the same wireless network.



Play Video From HDMI / USB Devices







The HDMI port and USB port cannot be used to simultaneously stream video and audio content.

Important Safety Instructions

- Due to the enclosure material, the product must only be connected to a USB 2.0 or higher.
- The adapter should be installed near the equipment and must be easily accessible.
- Do not use the device in an environment where the temperature is too high or too low. Never expose the device to strong sunshine or wet environments.
- The ideal temperature range for this product and its accessories is 41 °F 95°F / 5°C 35°C.
- When charging, place the device in an environment with a temperature that ranges between 41 °F 77°F / 5°C 25°C as well as good ventilation.
- Only use the charger provided by the manufacturer. Using unauthorized chargers may cause danger and violate the projector's guarantee.
- This charger is for indoor use only.
- The charger type is HKA 1807 9095-6C with output voltage/ current of DC19V/9.47A. The plug of the adapter
 is considered as the disconnect device. Once unplugged, the charger is considered as disconnected from the
 power source.
- Possibly hazardous optical radiation emitted from this product, do not stare at operating beam. Maybe harmful
 to the eyes.

Notice



This product complies with the radio interference requirements of the European Community.

Declaration of Conformity

Hereby, Anker Innovations Limited. declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. For the Declaration of Conformity, visit the website: uk.seenebula.com.

RF exposure information for D21 50: The Maximum Permissible Exposure (MPE) level has been calculated based on a distance of d=20 cm between the device and the human body. To maintain compliance with RF exposure requirements, use products that maintain a 20cm distance between the device and human body. Bluetooth BT Maximum output power: 8.96 dBm(EIRP); Bluetooth Operating BT Frequency band: 2402~2480 MHz;

Wi-Fi Max Output Power: 19.67 dBm (EIRP for 2.4G); 19.62 dBm (EIRP for 5G);

Wi-Fi Frequency Band: 2412~2472 MHz (2.4G); 5150~5250 MHz, 5725~5850 MHz (5G).

5150~5250 MHz can be used indoor only.

	AT	BE	BG	HR	CY	CZ	DK
	EE	FI	FR	DE	EL	HU	IE
	IT	LV	LT	LU	MT	NL	PL
	PT	RO	SK	SI	ES	SE	UK

Anker Innovations Deutschland GmbH I Georg-Muche-Strasse 3, 80807 Munich, Germany

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

X

This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.

This product complies with the radio interference requirements of the United Kingdom Declaration of Conformity.

Hereby, Anker Innovations Limited declares that the product type D2150 is in compliance with Radio Equipment Regulations 2017.

The full text of the UK declaration of conformity is available at the following internet address: https://uk.seenebula.com

Anker Technology (UK) Ltd I Suite B, Fairgate House, 205 Kings Road, Tyseley, Birmingham, 811 2AA, United Kingdom

FCC Notice

This device complies with the FCC rules, Part 1 5. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

The following importer is the responsible party.

Company Name: Fantasia Trading LLC

Address: 5350 Ontario Mills Pkwy, Suite 100, Ontario, CA 91764

Telephone: 1-800-988-7973



HIGH-DEFINITION MULTIMEDIA INTERFACE

HDMI, and HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI licensing LLC in the United States and other countries.

DOLBY
AUDIC Manufactured under license

AUDIC Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, Pro Logic, and the double-D symbol are trademarks of Dolby Laboratories.

To get a full user manual, you can get it from the Nebula Connect APP or website: www.seenebula.com/downloads

For FAQs and more information, please visit

uk.seenebula.com



NEBULA

Documents / Resources



NEBULA Cosmos Max [pdf] User Guide Cosmos Max

References

• Nebula Manual Page

Manuals+, home privacy