



**NPQCM13-100  
Retro Fit Watts  
Kwik Change Filter  
Systems**



## neo-Pure NPQCM13-100 Retro Fit Watts Kwik Change Filter Systems Owner's Manual

[Home](#) » [neo PURE](#) » neo-Pure NPQCM13-100 Retro Fit Watts Kwik Change Filter Systems Owner's Manual 

### Contents

- [1 neo-Pure NPQCM13-100 Retro Fit Watts Kwik Change Filter Systems](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Frequently Asked Questions](#)
- [5 HOW TO RETRO FIT WATTS KWIK CHANGE FILTER SYSTEMS](#)
- [6 HOW TO USE QUICK CONNECT / PUSH TO FIT FITTINGS](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)
- [8 Related Posts](#)



**neo-Pure NPQCM13-100 Retro Fit Watts Kwik Change Filter Systems**



## Specifications

- Product Name: Neo-Pure Branded NPQCM13-50 Replacement Membrane
- Compatible with: Watts Kwik Change WQCM11-50 RO Membrane
- Design: Slightly different design from Watts membrane

## Product Usage Instructions

### Replacing Watts Membrane with Neo-Pure Membrane:

1. Remove the plug from the elbow at the bottom of the new Neo-Pure NPQCM13-50 membrane.
2. Remove the old RO membrane from the third head on the manifold.
3. Disconnect the red drain line tube from the back of the manifold.
4. Place the plug in the outlet where the red drain line was removed from.
5. Connect the orange tube to the elbow at the bottom of the new membrane with the flow restrictor union on the other end.
6. Cut off the end of the existing drain line to remove the old flow restrictor.
7. Connect the drain line to the outlet side of the new flow restrictor.
8. Check for leaks once the system is fully assembled.

## **Filling and Testing:**

1. After replacing all filters on the manifold, turn the water back on and allow the tank to fill.
2. Empty the tank and check for any leaks before regular use.

## **Using Quick Connect / Push to Fit Fittings:**

### **Installation:**

1. Cut tubing square, remove burrs and sharp edges, and ensure the outside diameter is free of scratches.
2. Push the tube into the fitting all the way to the tube stop. (Measure 3/4 up a tube and make a line. Push tubing in so that the line is even or below the collet).
3. Pull to check if it is secure and test the system for leaks before use.

### **Disconnection:**


Ensure the system is off and depressurized, then push the collet square against the...



## **Frequently Asked Questions**

- **Q: How often should I replace the Neo-Pure membrane?**
  - A: The Neo-Pure membrane should be replaced according to the manufacturer's recommendations, typically every 1-2 years depending on usage.
- **Q: Can I use the Neo-Pure membrane with other RO systems?**
  - A: The Neo-Pure membrane is specifically designed as a replacement for the Watts Kwik Change WQCM11-50 RO Membrane. It is recommended to use it as intended for optimal performance.

## **HOW TO RETRO FIT WATTS KWIK CHANGE FILTER SYSTEMS**

The Neo-Pure RO-Pure membrane is a replacement for the Watts Kwik Change WQCM11-50 RO Membrane. This guide will show you how to effectively replace the Watts membrane with the Neo-Pure Branded NPQCM13-50 replacement membrane. The Neo-Pure has a slightly different design and the primary reason for the installation steps. Subsequent replacements will be quick and easy. The different design takes the drain line out of the canister to eliminate the chance of waste stream bypass happening inside the membrane housing and ruining the quality of the RO water. Additionally, the flow restrictor on most RO systems never gets replaced and will shorten the life of the membrane over time. As the flow restrictor does its job, microscopic debris rejected by the membrane will slowly accumulate and then each new membrane replacement lasts less and less time due to not having adequate flow rate to drain. Each new Neo-Pure membrane comes with a new flow restrictor so shortened membrane life is never a concern or potential from this issue. To install your first Neo-Pure membrane, it will require the drain line from the back of the Kwik Change RO to simply be re-routed to the flow restrictor union on the bottom of the Neo-Pure membrane. Follow these simple instructions:



- 1  Remove the old RO membrane from the third head on the manifold
- 2  Remove the red drain line tube from the back of the manifold (see how to use quick connect style connections on the next)



- 3 Remove the plug from the elbow at the bottom of your new Neo-Pure NPQCM13-

50



- 4 Place the plug in the outlet where the red drain line was removed from



- 5 Connect the orange tube to the elbow at the bottom of your new membrane with the flow restrictor union on the other end



- 6 Cut off the end of the existing drain line to remove the old flow restrictor



- 7 Connect the drain line to the outlet side of new flow restrictor
- 8 Always check for leaks once the system is fully

Once all filters are replaced on the manifold, turn the water back on and allow the tank to fill. Then empty the tank and the system is ready to go.

## HOW TO USE QUICK CONNECT / PUSH TO FIT FITTINGS

### Install



Cut tubing Square – Remove burrs and sharp edges. Ensure the outside diameter is free of scratches. Push the tube into the fitting all the way to tube stop. (Measure 3/4" up tube and make a line.



Push tubing in so that line is even or below the collet) Pull to check it is secure and test the system for leaks before use

### To Disconnect:



Ensure the system is off and depressurized, push the collet square against the

## Documents / Resources



[neo-Pure NPQCM13-100 Retro Fit Watts Kwik Change Filter Systems](#) [pdf] Owner's Manual NPQCM13-100, NPQCM13-100 Retro Fit Watts Kwik Change Filter Systems, Retro Fit Watts Kwik Change Filter Systems, Watts Kwik Change Filter Systems, Kwik Change Filter Systems, Filter Systems, Systems

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.