NETGEAR EAX11 WiFi Mesh Extender





NETGEAR EAX11 WiFi Mesh Extender User Guide

Home » NETGEAR » NETGEAR EAX11 WiFi Mesh Extender User Guide 🖫



Contents

- 1 NETGEAR EAX11 WiFi Mesh
- **Extender**
- **2 Product Information**
- 3 Let's get started
- **4 Overview**
- **5 Troubleshooting And Support**
- **6 Regulatory And Legal**
- 7 Documents / Resources
 - 7.1 References

NETGEAR®

NETGEAR EAX11 WiFi Mesh Extender



Product Information

Specifications

• Mobile App: Nighthawk

• WiFi Network: NETGEAR_EXT

• LED Indicators: Power LED, Router Link LED, Client Link LED, WPS LED

• Buttons: WPS button, Reset button

• Port: Ethernet port

FAQ

- Q: Can I use the extender with any router?
 - **A:** The extender is compatible with most routers but for optimal performance, it is recommended to use it with a NETGEAR router.
- Q: How do I reset the extender to factory settings?
 - A: Press and hold the Reset button on the extender for 10 seconds to restore it to factory settings.

Let's get started

On your mobile phone, scan the QR code to download the Nighthawk app




• If you used the Nighthawk app before, go to the dashboard and tap the top left menu, then SET UP A NEW NIGHTHAWK SYSTEM.

Connect your phone to the extender WiFi




- Plug in your extender.
- Connect your mobile phone to the NETGEAR_EXT WiFi network.
- Open the Nighthawk app and follow the step-by-step instructions to set up your extender.

Do more with the app



• Check out everything you can do on the Nighthawk app! Run a speed test, see all the connected devices, and more.

Overview



- A WPS button
- B Reset button
- C Ethernet port







4. WPS LED

Troubleshooting And Support

Troubleshooting

• If you need setup help, visit netgear.com/extenderhelp for more information.

Support And Community

 Get your questions answered and access the latest downloads at <u>netgear.com/support</u>, and check out our NETGEAR Community at <u>community.netgear.com</u>.

Regulatory And Legal

For regulatory compliance information including the EU Declaration of Conformity, visit netgear.com/about/regulatory/. See the regulatory compliance document before connecting the power supply. For NETGEAR's Privacy Policy, visit netgear.com/about/privacy-policy. By using this device, you are agreeing to NETGEAR's Terms and Conditions at netgear.com/about/terms-and-conditions. If you do not agree, return the device to your place of purchase within your return period.

Applicable to 6 GHz devices only: Only use the device indoors. The operation of 6 GHz devices is prohibited on oil platforms, cars, trains, boats, and aircraft, except that operation of this device is permitted in large aircraft while flying above 10,000 feet. Operation of transmitters in the 5.925-7.125 GHz band is prohibited for control of or communications with unmanned aircraft systems.

NETGEAR, Inc.

• 350 East Plumeria Drive San Jose, CA 95134, USA

NETGEAR INTERNATIONAL LTD

• Floor 6, Penrose Two, Penrose Dock, Cork, T23 YY09, Ireland

© NETGEAR, Inc., NETGEAR and the NETGEAR Logo are trademarks of NETGEAR, Inc. Any non-NETGEAR trademarks are used for reference purposes only.



201-31387-01

Documents / Resources



NETGEAR EAX11 WiFi Mesh Extender [pdf] User Guide EAX11, EAX11 WiFi Mesh Extender, WiFi Mesh Extender, Mesh Extender, Extender

References

- N English NETGEAR Communities
- N NETGEAR Terms and Conditions | NETGEAR
- N NETGEAR Support | NETGEAR
- Download Center | Downloads and Documentation | NETGEAR
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.