



NETPRISMA LCUK54-WWD Module User Manual

[Home](#) » [NETPRISMA](#) » NETPRISMA LCUK54-WWD Module User Manual 



LCUK54-WWD
Hardware Design
LTE-A Series
Version: 1.0.0
Date: 2024-04-01
Status: Preliminary

Contents

- [1 LCUK54-WWD Module](#)
- [2 Introduction](#)
- [3 Product Overview](#)
- [4 Operating Characteristics](#)
- [5 Application Interfaces](#)
- [6 RF Specifications](#)
- [7 Electrical Characteristics and Reliability](#)
- [8 Mechanical Information and Packaging](#)
- [9 Appendix References](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)

LCUK54-WWD Module

Our aim is to provide timely and comprehensive services to our customers. If you require any assistance, please contact our headquarters:

NetPrisma US INC.

100 N HOWARD ST STE R, SPOKANE, WA, 99201 Email: Info@netprisma.us

Or our local offices. For more information, please visit: <https://www.netprisma.us/sales-support/>.

For technical support, or to report documentation errors, please visit: <https://www.netprisma.us/tech-support/>.
Or email us at: support@netprisma.us.

Legal Notices

We offer information as a service to you. The provided information is based on your requirements and we make every effort to ensure its quality. You agree that you are responsible for using independent analysis and evaluation in designing intended products, and we provide reference designs for illustrative purposes only. Before using any hardware, software or service guided by this document, please read this notice carefully. Even though we employ commercially reasonable efforts to provide the best possible experience, you hereby acknowledge and agree that this document and related services hereunder are provided to you on an “as available” basis. We may revise or restate this document from time to time at our sole discretion without any prior notice to you.

Use and Disclosure Restrictions

License Agreements

Documents and information provided by us shall be kept confidential, unless specific permission is granted. They shall not be accessed or used for any purpose except as expressly provided herein.

Copyright

Our and third-party products hereunder may contain copyrighted material. Such copyrighted material shall not be copied, reproduced, distributed, merged, published, translated, or modified without prior written consent. We and the third party have exclusive rights over copyrighted material. No license shall be granted or conveyed under any patents, copyrights, trademarks, or service mark rights. To avoid ambiguities, purchasing in any form cannot be deemed as granting a license other than the normal non-exclusive, royalty-free license to use the material. We reserve the right to take legal action for noncompliance with abovementioned requirements, unauthorized use, or other illegal or malicious use of the material.

Trademarks

Except as otherwise set forth herein, nothing in this document shall be construed as conferring any rights to use any trademark, trade name or name, abbreviation, or counterfeit product thereof owned by NetPrisma or any third party in advertising, publicity, or other aspects.

Third-Party Rights

This document may refer to hardware, software and/or documentation owned by one or more third parties (“third-party materials”). Use of such third-party materials shall be governed by all restrictions and obligations applicable thereto.

We make no warranty or representation, either express or implied, regarding the third-party materials, including but not limited to any implied or statutory, warranties of merchantability or fitness for a particular purpose, quiet enjoyment, system integration, information accuracy, and non-infringement of any third-party intellectual property rights with regard to the licensed technology or use thereof. Nothing herein constitutes a representation or warranty by us to either develop, enhance, modify, distribute, market, sell, offer for sale, or otherwise maintain production of any our products or any other hardware, software, device, tool, information, or product. We moreover disclaim any and all warranties arising from the course of dealing or usage of trade.

Privacy Policy

To implement module functionality, certain device data are uploaded to NetPrisma’s or third-party’s servers, including carriers, chipset suppliers or customer-designated servers. NetPrisma, strictly abiding by the relevant laws and regulations, shall retain, use, disclose or otherwise process relevant data for the purpose of performing the service only or as permitted by applicable laws. Before data interaction with third parties, please be informed of their privacy and data security policy.

Disclaimer

- a) We acknowledge no liability for any injury or damage arising from the reliance upon the information.
- b) We shall bear no liability resulting from any inaccuracies or omissions, or from the use of the information contained herein.
- c) While we have made every effort to ensure that the functions and features under development are free from errors, it is possible that they could contain errors, inaccuracies, and omissions. Unless otherwise provided by valid agreement, we make no warranties of any kind, either implied or express, and exclude all liability for any loss or damage suffered in connection with the use of features and functions under development, to the maximum extent permitted by law, regardless of whether such loss or damage may have been foreseeable.
- d) We are not responsible for the accessibility, safety, accuracy, availability, legality, or completeness of information, advertising, commercial offers, products, services, and materials on third-party websites and third-party resources.

Copyright © NetPrisma US 2024. All rights reserved.

Revision History

Version	Date	Description
–	2024-04-01	Creation of the document
1.0.0	2024-04-01	Preliminary

Introduction

This document defines LCUK54-WWD module and describes its air and hardware interfaces which are connected to your applications.

This document can help you quickly understand the interface specifications, electrical and mechanical details as well as other related information of the module. Besides, reference designs will be offered to exemplify diverse applications of the modules. With this hardware design coupled with application notes and user guides, you can use the module to design and set up mobile applications easily.

1.1. Reference Standard

The module complies with the following standards:

- PCI Express M.2 Specification Revision 4.0
- Universal Serial Bus Specification, Revision 4.0
- ISO/IEC 7816-3
- MIPI Alliance Specification for RF Front-End Control Interface Version 2.0
- 3GPP TS 27.007 and 3GPP TS 27.005
- 3GPP TS 34.121-1 and 3GPP TS 36.521-1

1.2. Special Marks

Table 1: Special Marks

Mark	Definition
*	Unless otherwise specified, an asterisk (*) after a function, feature, interface, pin name, command, a rgument, and so on indicates that it is under development and currently not supported; and the asteri sk (*) after a model indicates that the model sample is currently unavailable.
[...]	Brackets ([...]) used after a pin enclosing a range of numbers indicate all pins of the same type. For e xample, SDIO_DATA[0:3] refers to all four SDIO pins: SDIO_DATA0, SDIO_DATA1, SDIO_DATA2, an d SDIO_DATA3.

Product Overview

2.1. Frequency Bands and Functions

LCUK54-WWD is an LTE-A/UMTS/HSPA+ wireless communication module with diversity receiver. It provides data connectivity on LTE-FDD, LTE-TDD, DC-HSDPA, HSPA+, HSDPA, HSUPA and WCDMA networks. It is standard WWAN M.2 Key-B module. For more details, see PCI Express M.2 Specification Revision 4.0.

It supports embedded operating systems such as Windows, Linux and Android, and also provides GNSS 1 to meet specific application demands.

The following table shows the frequency bands and GNSS functions of the module. For details about CA combinations, you can see document [1].

Table 2: Frequency Bands and GNSS Function

Mode	Frequency Band
LTE-FDD (with Rx-diversity)	B1/B2/B3/B4/B5/B7/B8/B12/B13/B14/B17/B18/B19/B20/B25/B26 /B28/B29 2/B30/B32 2/B66/B71
LTE-TDD (with Rx-diversity)	B34/B38/B39/B40*/B41/B42/B43/B46 2/B48 (CBRS)
WCDMA (with Rx-diversity)	B1/B2/B3/B4/B5/B6/B8/B19

***Note** :B40 not for FCC/IC

2.2. Key Features

Table 3: Key Features

Feature	Details
Function Interface	PCI Express M.2 Interface
Power Supply	<ul style="list-style-type: none"> Supply voltage: 3.135–4.4 V Typical supply voltage: 3.3 V
(U)SIM Interfaces	<ul style="list-style-type: none"> Compliant with <i>ISO/IEC 7816-3</i> and ETSI and IMT-2000 requirements Supports (U)SIM card: 1.8/3.0 V Supports Dual SIM Single Standby (one eSIM and one USIM interface)

- GNSS function is optional.
- LTE-FDD B29/B32 and LTE-TDD B46 support Rx only and is only for secondary component carrier.

eSIM	Optional eSIM function
USB Interface	<ul style="list-style-type: none"> Reserves USB 3.0 interface Compliant with USB 3.0 and 2.0 specifications, with maximum transmission rates up to 5 Gbps on USB 3.0 and 480 Mbps on USB 2.0 Used for AT command communication, data transmission, firmware upgrade (USB 2.0 only), software debugging and GNSS NMEA sentence output Supports USB serial drivers: <ul style="list-style-type: none"> Windows 10/11 Linux 2.6–6.x Android 4.x–13.x
PCM Interface* (Reserved)	<ul style="list-style-type: none"> Used for audio function through an external codec Supports 16-bit linear data format Supports long and short frame synchronization Supports master and slave modes, but must be in master mode in long frame synchronization
PCIe Interface (Reserved)	<ul style="list-style-type: none"> Compliant with <i>PCI Express Base Specification Revision 2.0</i> Supports one PCIe interface, up to 5 Gbps/lane Used for data transmission RC mode only

Rx-diversity	LTE/WCDMA
Antenna Interfaces	<ul style="list-style-type: none"> • Main antenna connector and diversity/GNSS antenna connector • 50 Ω impedance
Transmitting Power	<ul style="list-style-type: none"> • WCDMA: Class 3 (23 dBm \pm2 dB) • LTE B7/B38/40/B41: Class 3 (23 dBm \pm1 dB) • LTE B30: Class 3 (22 dBm \pm1 dB) • LTE B42/B43/B48: Class 3 (21 dBm \pm1 dB) • LTE other bands: Class 3 (23.5 dBm \pm1 dB)
LTE Features	<ul style="list-style-type: none"> • Supports 3GPP Rel-12 LTE-FDD and LTE-TDD • LTE-FDD: Max. 300 Mbps (DL)/50 Mbps (UL) • LTE-TDD: Max. 226 Mbps (DL)/28 Mbps (UL) • Supports CA category: up to DL CA Cat 6 • Supports 1.4/3/5/10/15/20 MHz RF bandwidth • Supported modulations: <ul style="list-style-type: none"> – Downlink: QPSK, 16QAM and 64QAM modulations – Uplink: QPSK and 16QAM modulations
UMTS Features	<ul style="list-style-type: none"> • Supports 3GPP Rel-9 DC-HSDPA, HSPA+, HSDPA, HSUPA and WCDMA • Supported modulations: <ul style="list-style-type: none"> – Downlink: BPSK, QPSK, 16QAM and 64QAM modulations – Uplink: BPSK, QPSK • Maximum transmission data rates 3: <ul style="list-style-type: none"> – DC-HSDPA: 42 Mbps (DL) – HSUPA: 5.76 Mbps (UL) – WCDMA: 384 kbps (DL)/384 kbps (UL)
GNSS Features 3	<ul style="list-style-type: none"> • Supports GPS, GLONASS, BDS, Galileo and QZSS • Data update rate: 1 Hz by default
AT Commands	<ul style="list-style-type: none"> • Compliant with <i>3GPP TS 27.007</i> and <i>3GPP TS 27.005</i> • Enhanced AT commands

3 GNSS function is optional.

Internet Protocol Features	Supports QMI/MBIM/NITZ/HTTP/HTTPS
Firmware Upgrade	<ul style="list-style-type: none"> • USB 2.0 • DFOTA
SMS	<ul style="list-style-type: none"> • Point-to-point MO and MT • Text and PDU modes • SMS cell broadcast • SMS storage: ME by default
Physical Characteristics	<ul style="list-style-type: none"> • M.2 Key-B • Size: 30.0 mm × 42.0 mm × 2.3 mm • Weight: approx. 6.2 g
Temperature Ranges	<ul style="list-style-type: none"> • Operating temperature range 4: -25 to +75 °C • Extended temperature range 5: -40 to +85 °C • Storage temperature range: -40 to +90 °C
RoHS	All hardware components are fully compliant with EU RoHS directive

2.3. Functional Diagram

The following figure shows a functional diagram of LCUK54-WWD

- Power management
- Baseband
- LPDDR2 SDRAM + NAND flash
- Radio frequency
- M.2 Key-B interface

4 To meet the normal operating temperature range requirements, it is necessary to ensure effective thermal dissipation, e.g., by adding passive or active heat sinks, heat pipes, vapor chambers. Within the temperature range of -10 °C to +55 °C the mentioned RF performance margins higher than 3GPP specifications can be guaranteed. When temperature goes beyond temperature range of -10 °C to +55 °C, a few RF performances of module may be slightly off 3GPP specifications.

5 To meet the extended operating temperature range requirements, it is necessary to ensure effective thermal dissipation, e.g., by adding passive or active heat sinks, heat pipes, vapor chambers. Within this range, the module remains the ability to establish and maintain functions such as SMS, without any unrecoverable malfunction. Radio spectrum and radio network are not influenced, while one or more specifications, such as Pout, may undergo a reduction in value, exceeding the specified tolerances of 3GPP. When the temperature returns to the normal operating temperature level, the module will meet 3GPP specifications again.




Figure 1: Functional Diagram

2.4. Pin Assignment

The following figure shows the pin assignment of the module.




Figure 2: Pin Assignment

NOTE

Before the module turns on, ensure the pins DPR and USIM_DET are not pulled high to avoid current sink damaging the module. For more details, contact NetPrisma Technical Support.

2.5. Pin Definitions

Table 4: Parameter Definition

Parameter	Description
AI	Analog Input
AO	Analog Output
AIO	Analog Input/Output
DI	Digital Input
DO	Digital Output
DIO	Digital Input/Output
OD	Open Drain
PI	Power Input
PO	Power Output
PU	Pull Up
PD	Pull Down

DC characteristics include power domain and rated current.

Table 5: Pin Description

Pin No.	Pin Name	I/O	Description	DC Characteristics	Comment
1	CONFIG_3	DO	Not connected internally		
2	VCC	PI	Power supply for the module	Vmin = 3.135 V Vnom = 3.3 V Vmax = 4.4 V	
3	GND		Ground		
4	VCC	PI	Power supply for the module	Refer to Pin 2	
5	GND		Ground		
6	FULL_CARD_POWER_OFF#	DI, PD	Turn on/off the module High level: turn on Low level: turn off	VIHmax = 4.4 V VILmin = 1.19 V VILmax = 0.2 V	Internally pulled down with a 100 kΩ resistor.
7	USB_DP	AIO	USB differential data (+)		Require differential impedance of 90 Ω. A test point must be reserved.
8	W_DISABLE1#	DI	Airplane mode control Active LOW	1.8/3.3 V	Internally pulled up to 1.8 V with a 100 kΩ resistor.
9	USB_DM	AIO	USB differential data (-)		Require differential impedance of 90 Ω. A test point must be reserved.

10	WWAN_LED#	OD	RF status LED indicator Active LOW	VCC	
11	GND		Ground		
12	Notch		Notch		
13	Notch		Notch		
14	Notch		Notch		
15	Notch		Notch		
16	Notch		Notch		
17	Notch		Notch		
18	Notch		Notch		

19	Notch		Notch		
20	RESERVED		Reserved for PCM* clock		
21	CONFIG_0	DO	Connected to GND internally		
22	RESERVED		Reserved for PCM* data input		
23	WAKE_ON_WAN#	OD	Wake up the host Active LOW	1.8/3.3 V	Externally pull up to 1.8 V or 3.3 V.
24	RESERVED		Reserved for PCM* data output		
25	DPR	DI, PU	Dynamic power reduction Active LOW	1.8 V	High level by default.
26	W_DISABLE2#*		Reserved for GNSS control		Internally pulled up to 1.8 V with a 100 kΩ resistor.
27	GND		Ground		
28	RESERVED		Reserved for PCM* data frame sync		
29	RESERVED		Reserved for USB 3.0 super-speed transmit (-)		
30	USIM_RST	DO	(U)SIM card reset	USIM_VDD	
31	RESERVED		Reserved for USB 3.0 super-speed transmit (+)		
32	USIM_CLK	DO	(U)SIM card clock	USIM_VDD	
33	GND		Ground		
34	USIM_DATA	DIO	(U)SIM card data	USIM_VDD	Internally pulled up to 1.8 V with a 10 kΩ resistor.
35	RESERVED		Reserved for USB 3.0 super-speed receive (-)		

36	USIM_VDD	PO	(U)SIM card power supply	High-voltage: $V_{min} = 3.05\text{ V}$ $V_{nom} = 2.85\text{ V}$ $V_{max} = 2.7\text{ V}$ Low-voltage: $V_{min} = 1.95\text{ V}$	
----	----------	----	--------------------------	--	--

				$V_{nom} = 1.8\text{ V}$ $V_{max} = 1.65\text{ V}$	
37	RESERVED		Reserved for USB 3.0 super-speed receive (+)		
38	NC		NC		
39	GND		Ground		
40	NC		NC		
41	RESERVED		Reserved for PCIe transmit (-)		
42	NC		NC		
43	RESERVED		Reserved for PCIe transmit (+)		
44	NC		NC		
45	GND		Ground		
46	NC		NC		
47	RESERVED		Reserved for PCIe receive (-)		
48	NC		NC		
49	RESERVED		Reserved for PCIe receive (+)		
50	RESERVED		Reserved for PCIe RC reset		
51	GND		Ground		
52	RESERVED		Reserved for PCIe clock request		

53	RESERVED		Reserved for PCIe reference clock (-)	
54	RESERVED		Reserved for PCIe wake up	
55	RESERVED		Reserved for PCIe reference clock (+)	
56	RFFE_CLK* 6	DO	Used for external MIPI IC control	1.8 V
57	GND		Ground	
58	RFFE_DATA* 6	DIO	Used for external MIPI IC control	1.8 V
59	ANTCTL0*	DO	Antenna GPIO control	1.8 V
60	WLAN_PA_EN	DI	Self-protection of LNA control	1.8 V
61	ANTCTL1*	DO	Antenna GPIO control	1.8 V
62	COEX_RXD*	DI	LTE/WLAN coexistence receive	1.8 V
63	ANTCTL2*	DO	Antenna GPIO control	1.8 V
64	COEX_TXD*	DO	LTE/WLAN coexistence transmit	1.8 V

6 If RFFE_CLK and RFFE_DATA are required, contact NetPrisma Technical Support for more details.

65	ANTCTL3*	DO	Antenna GPIO control	1.8 V	
66	USIM_DET	DI	(U)SIM card hot-plug detect	1.8 V	
67	RESET#	DI	Reset the module Active LOW	1.8 V	Internally pulled up to 1.8 V with a 10 kΩ resistor. A Test point is recommended to be reserved if unused.
68	NC		NC		
69	CONFIG_1	DO	Connected to GND internally		
70	VCC	PI	Power supply for the module	Refer to Pin 2	
71	GND		Ground		
72	VCC	PI	Power supply for the module	Refer to Pin 2	
73	GND		Ground		
74	VCC	PI	Power supply for the module	Refer to Pin 2	
75	CONFIG_2	DO	Not connected internally		

NOTE

Keep all RESERVED, NC and unused pins unconnected. All GND pins should be connected to ground.

Operating Characteristics

3.1. Operating Modes

The table below summarizes different operating modes of the modules.

Table 6: Overview of Operating Modes

Mode	Details	
	Idle	Software is active. The module has registered on the <u>network, and it is ready to send and receive data.</u>
Full Functionality Mode	Data	Network is connected. In this mode, the power consumption is decided by network setting and data transmission rate.
Minimum Functionality Mode	AT+CFUN=0 sets the module to a minimum functionality mode without removing the power supply. In this mode, both RF function and (U)SIM card are invalid.	
Airplane Mode	AT+CFUN=4 or driving W_DISABLE1# pin low will set the module to airplane mode. In this mode, the RF function is invalid.	
Sleep Mode	The module keeps receiving paging messages, SMS and TCP/UDP data from the network with its power consumption reduced to the minimal level.	
Power Down Mode	In this mode, the power management unit shuts down the power supply. Software is inactive, all application interfaces are inaccessible and the operating voltage (connected to VCC) remains applied.	

For more details, see document [2].

3.2. Sleep Mode

In sleep mode, DRX of the module is able to reduce the power consumption to an ultra-low level, and DRX cycle index values are broadcasted by the wireless network. The figure below shows the relationship between the DRX run time and the power consumption in sleep mode. The longer the DRX cycle is, the lower the power consumption will be.




Figure 3: DRX Run Time and Power Consumption in Sleep Mode

NOTE

DRX cycle values are transmitted over the wireless network.

The following part of this chapter describes the power saving procedure and sleep mode entrance of the module. If the host supports USB Suspend/Resume and remote wakeup function, the following two conditions must be met simultaneously to bring the module into sleep mode.

- Execute AT+QSClk=1 to enable the sleep mode. For more details, see document [2].
- The host's USB bus, which is connected to the module's USB interface, enters suspend state.

The following figure shows the connection between the module and the host.




Figure 4: Sleep Mode Application with USB Remote Wakeup Function

The module will wake up when the host sends data to the module through USB interface.

3.3. Airplane Mode

Execution of AT+CFUN=4 or driving W_DISABLE1# pin low will set the module to airplane mode. For more details, see Chapter 4.3.1.

3.4. Communication Interface with Host

The module supports communication with the host through USB interface. USB 2.0 must be reserved for firmware upgrade. See the USB mode features as below:

USB Mode:

- Supports all USB 2.0 features
- Supports MBIM/QMI/AT

3.5. Power Supply

3.5.1. Power Supply Pins

Table 7: Pin Definition of VCC and GND Pins

Pin No.	Pin Name	I/O	Description	DC Characteristics
2, 4, 70, 72, 74	VCC	PI	Power supply for the module	Vmin = 3.135 V Vnom = 3.3 V Vmax = 4.4 V
3, 5, 11, 27, 33, 39, 45, 51, 57, 71, 73	GND		Ground	

3.5.2. Reference Design for Power Supply

Power design is vital to the module, as the performance of the module largely depends on the power source. Ensure the continuous current capability of the power supply is 2 A at least and the peak current capability of the power supply is 3 A at least.

The following figure shows a reference design for +5 V input power supply based on DC-DC converter.

The typical output of the power supply is about 3.3 V.




Figure 5: Reference Circuit for Power Supply

NOTE

To avoid corrupting the data in the internal flash, do not cut off the power supply before the module is completely turned off by pulling down FULL_CARD_POWER_OFF# pin for more than 1 s, and do not cut off power supply directly when the module is working.

3.5.3. Voltage Stability Requirements

The power supply of the module ranges from 3.135 V to 4.4 V. Please ensure that the input voltage never drops below 3.135 V, otherwise the module will be powered down automatically. The voltage ripple of the input power supply should be less than 100 mV. The following figure shows the maximum voltage drop during burst transmission in 3G/4G networks.




Figure 6: Power Supply Limits During Burst Transmission

To decrease the voltage drop, two bypass capacitors of about 220 μF with low ESR ($\text{ESR} = 0.7 \Omega$) should be used. To avoid disturbing the power supply, two multi-layer ceramic chip capacitor (MLCC) arrays also should be used due to their ultra-low ESR. It is recommended to use eight ceramic capacitors (1 μF , 100 nF, 33 pF, 10 pF) to compose the MLCC arrays, and to place these capacitors close to VCC pins. The width of VCC trace should be not less than 2.5 mm. In principle, the longer the VCC trace is, the wider it should be.

In addition, to guarantee the stability of the power supply, it is recommended to use a TVS with working peak reverse voltage of 5.1 V and a dissipation power higher than 0.5 W. The following figure shows a reference circuit of the VCC.




Figure 7: Reference Circuit for VCC

3.5.4. Power Supply Voltage Monitoring

You can use AT+CBC to monitor the voltage value of VCC. For more details, see document [2].

3.6. Turn On


FULL_CARD_POWER_OFF# is used to turn on/off the module. This input signal is 3.3 V tolerant and can be driven by either 1.8 V or 3.3 V GPIO.

When FULL_CARD_POWER_OFF# is de-asserted (driven high, ≥ 1.19 V), the module will be turned on.

Table 8: Pin Definition of FULL_CARD_POWER_OFF#

Pin No.	Pin Name	I/O	Description	Comment
6	FULL_CARD_POWER_OFF#	DI, PD	Turn on/off the module High level: turn on Low level: turn off	Internally pulled down with a 100 kΩ resistor.

It is recommended to use a host GPIO to control FULL_CARD_POWER_OFF#. A simple reference circuit is illustrated in the following figure.



NOTE: The voltage of pin 6 should be not less than 1.19 V when it is at high level.

Figure 8: Turn on the Module Using Host GPIO

The turn-on timing is illustrated in the following figure.




Figure 9: Turn-on Timing

Table 9: Turn-on Timing of the Module

Symbol	Min.	Typ.	Max.	Comment
T1	100 ms	—	—	The turn-on timing of the module (Time of T1 is from RESET# high to FULL_CARD_POWER_OFF# high).
T2	—	13.7 s	—	The system booting timing of the module.

NOTE

1. RESET# is automatically pulled up as soon as the module is turned on. RESET# is not allowed to be pulled down by host during the power-up process.
2. When the FULL_CARD_POWER_OFF# signal is low, please avoid any leakage current entering the module's DPR pin from the host.

3.7. Turn Off

If the module is turned off using a host GPIO, when VCC is supplied with power, pulling down FULL_CARD_POWER_OFF# pin (≤ 0.2 V) will turn off the module normally. The turn-off timing is illustrated in the following figure.




Figure 10: Turn-off Timing

Table 10: Turn-off Timing of the Module

Symbol	Min.	Typ.	Max.	Comment
T1	1 s	—	—	The turn-off timing of the module.

3.8. RESET#

The RESET# pin serves to reset the module. Triggering the RESET# signal will lead to loss of all data from the modem and removal of system drivers. It will also lead to disconnection of the modem from the network.

Table 11: Pin Definition of RESET#

Pin No.	Pin Name	I/O	Description	Comment
67	RESET#	DI	Reset the module Active low	Internally pulled up to 1.8 V with a 100 kΩ resistor. A Test point is recommended to be reserved if unused.

The module can be reset by pulling down the RESET# pin for a minimum duration of 200 ms. An open collector (OC)/drain driver or a button can be used to control the RESET# pin.




Figure 11: Reference Circuit for RESET# with Open Collector Driving Circuit

The reset timing is illustrated in the following figure.




Figure 12: Reset Timing

Table 12: Reset Timing of the Module

Symbol	Min.	Typ.	Max.	Comment
T1	0 ms	100 ms	–	It is recommended to pull down RESET# for about 100 ms before driving FULL_CARD_POWER_OFF# low.
T2	200 ms	–	–	Driving RESET# low for at least 200 ms can reset the module.
T3	–	50 ms	–	Set up by the host, 50 ms by default.

NOTE

When the FULL_CARD_POWER_OFF# signal is low, please avoid any leakage current entering the module's DPR pin from the host.

Application Interfaces

The physical connections and signal levels of the module comply with the PCI Express M.2 specification. This chapter mainly describes the definition and application of the following interfaces/pins of the module:

- (U)SIM interfaces
- USB interface
- Control and indication interfaces
- Antenna Tuner Control Interface*
- Configuration pins

4.1. (U)SIM Interfaces

The (U)SIM interface circuitry meets ETSI and IMT-2000 requirements and ISO/IEC 7816-3. Both Class B (3.0 V) and Class C (1.8 V) (U)SIM cards are supported, and Dual SIM Single Standby function is supported. The module has dual SIM (one eSIM and one (U)SIM interface).

4.1.1. Pin definition of (U)SIM Interfaces

Table 13: Pin Definition of (U)SIM Interfaces

Pin No.	Pin Name	I/O	Description	Comment
36	USIM_VDD	PO	(U)SIM card power supply	
34	USIM_DATA	DIO	(U)SIM card data	Internally pulled up to 1.8 V with a 10 kΩ resistor.
32	USIM_CLK	DO	(U)SIM card clock	
30	USIM_RST	DO	(U)SIM card reset	
66	USIM_DET	DI	(U)SIM card hot-plug detect	

4.1.2. Normally Closed (U)SIM Card Connector

With a normally closed (U)SIM card connector, USIM_DET pin is normally shorted to ground when there is no (U)SIM card inserted. (U)SIM card detection by high level is applicable to this type of connector. Once (U)SIM hot-plug is enabled by executing AT+QSIMDET=1,1, insertion of a (U)SIM card will drive USIM_DET from low to high level, and the removal of it will drive USIM_DET from high to low level.

- When the (U)SIM card is absent, CD is shorted to ground and USIM_DET is at low level.
- When the (U)SIM card is present, CD is open from ground and USIM_DET is at high level.

The following figure shows a reference design of (U)SIM interface with a normally closed (U)SIM card connector.




Figure 13: Reference Circuit for Normally Closed (U)SIM Card Connector

4.1.3. Normally Open (U)SIM Card Connector

With a normally open (U)SIM card connector, CD1 and CD2 of the connector are disconnected when there is no (U)SIM card inserted. (U)SIM card detection by low level is applicable to this type of connector. Once (U)SIM hot-plug is enabled by executing AT+QSIMDET=1,0, insertion of a (U)SIM card will drive USIM_DET from high to low level, and the removal of it will drive USIM_DET from low to high level.

- When the (U)SIM card is absent, CD1 is open from CD2 and USIM_DET is at high level.
- When the (U)SIM card is inserted, CD1 is shorted to ground and USIM_DET is at low level.

The following figure shows a reference design of (U)SIM interface with a normally open (U)SIM card connector.




Figure 14: Reference Circuit for Normally Open (U)SIM Card Connector

NOTE

1. If the (U)SIM card detection function is not needed, please keep USIM_DET unconnected.
2. If the (U)SIM card detection function is required, note that a pull-up resistor should not be added to the USIM_DET signal.

4.1.4. (U)SIM Design Notices

To enhance the reliability and availability of the (U)SIM card in applications, please follow the criteria below in (U)SIM circuit design.

- Place the (U)SIM card connector as close to the module as possible. Keep the trace length less than 200 mm.
- Keep (U)SIM card signals away from RF and VCC traces.

- Ensure the ground between the module and the (U)SIM card connector is short and wide. Keep the trace width of ground and USIM_VDD not less than 0.2 mm to maintain the same electric potential. Keep the trace width of USIM_DATA, USIM_CLK, USIM_RST and USIM_DET not less than 0.1mm.
- To avoid cross-talk between USIM_DATA and USIM_CLK, keep them away from each other and shield them with surrounded ground.
- To offer better ESD protection, add a TVS array of which the parasitic capacitance should be not higher than 20 pF. Add 22 Ω resistors in series between the module and the (U)SIM card connector to suppress EMI such as spurious transmission. The 33 pF capacitors are used to filter out RF interference. Additionally, keep the (U)SIM peripheral circuit close to the (U)SIM card connector.
- For USIM_DATA, a 20 k Ω pull-up resistor is optional to be added near the (U)SIM card connector.
- The (U)SIM card connector should be placed near the M.2 socket, because a long trace may lead to waveform distortion, which affects the signal quality.

4.2. USB Interface

The module provides one integrated Universal Serial Bus (USB) interface which complies with USB 2.0 specifications and supports high-speed (480 Mbps) and full-speed (12 Mbps) modes on USB 2.0. The USB interface is used for AT command communication, data transmission, firmware upgrade (USB 2.0 only), software debugging, GNSS NMEA sentence output.

Table 14: Pin Definition of USB Interface

Pin No.	Pin Name	I/O	Description	Comment
7	USB_DP	AIO	USB differential data (+)	Require differential impedance of 90 Ω . Test points must be reserved.
9	USB_DM	AIO	USB differential data (-)	

For more details about the USB 2.0 specifications, please visit <http://www.usb.org/home>. The following figure presents a reference circuit for the USB interface.




Figure 15: Reference Circuit for USB Interface

To ensure the signal integrity of USB 2.0 data traces, R1, R2, R3 and R4 must be placed close to the module, and the stubs must be minimized in PCB layout. Please follow the principles below when designing the USB interface to meet 2.0 specifications:

- Route the USB signal traces as differential pairs with ground surrounded. The impedance of differential trace of

USB 2.0 is 90 Ω .

- For USB 2.0, the trace length should be less than 120 mm, and the differential data pair matching should be less than 2 mm.
- Do not route signal traces under crystals, oscillators, magnetic devices, PCIe, other high-speed and RF signal traces. Route the USB differential traces in inner-layer of the PCB, and surround the traces with ground on that layer and with ground planes above and below.
- Junction capacitance of the ESD protection components might cause influences on USB data traces, so you should pay attention to the selection of the components. Typically, the stray capacitance should be less than 2.0 pF for USB 2.0.
- Keep the ESD protection components as close to the USB connector as possible.
- If possible, reserve 0 Ω resistor on USB_DP and USB_DM traces respectively.

NOTE

LCUK54-WWD reserves USB 3.0 interface.

4.3. Control and Indication Interfaces

Table 15: Pin Definition of Control and Indication Interfaces

Pin No.	Pin Name	I/O	Description	Comment
8	W_DISABLE1#	DI	Airplane mode control Active LOW	Internally pulled up to 1.8 V with a 100 k Ω resistor.
10	WWAN_LED#	OD	RF status indication LED A ctive LOW	
23	WAKE_ON_WAN#	OD	Wake up the host Active L OW	Externally pull up to 1.8 V or 3.3 V.
25	DPR	DI, PU	Dynamic power reduction	High level by default.

			Active LOW	
26	W_DISABLE2#*		Reserved for GNSS control	Internally pulled up to 1.8 V with a 100 k Ω resistor.
60	WLAN_PA_EN	DI	Self-protection of LNA control	

4.3.1. W_DISABLE1#

The module provides a W_DISABLE1# pin to disable or enable airplane mode through hardware operation. W_DISABLE1# is pulled up by default. Driving it low will configure the module into airplane mode. In airplane mode, the RF function will be disabled.

The RF function can also be enabled or disabled through AT commands. The following table shows the AT command and corresponding RF function status of the module.

Table 16: RF Function Status

W_DISABLE1# Logic Level	AT Command	RF Function Status	Operating Mode
	AT+CFUN=1	Enabled	Full functionality mode
High	AT+CFUN=0	Disabled	Minimum functionality mode
	AT+CFUN=4	Disabled	Airplane mode
Low	AT+CFUN=0 AT+CFUN=1 AT+ CFUN=4	Disabled	Airplane mode

4.3.2. W_DISABLE2#

The module provides a W_DISABLE2# pin to disable or enable the GNSS function. The W_DISABLE2# pin is pulled up by default. Driving it low will disable the GNSS function.

The GNSS function can also be controlled through AT commands. The combination of W_DISABLE2# pin and AT commands controls the GNSS function.

Table 17: GNSS Function Status

W_DISABLE2# Logic Level	AT Command	GNSS Function Status
	AT+QGPS=1	Enable
High		
	AT+QGSEND	Disable
	AT+QGPS=1	
Low		Disable
	AT+QGSEND	

For details about AT commands mentioned above, see document [2].

A simple voltage-level translator based on diodes is used on W_DISABLE1# pin and W_DISABLE2# pin which are pulled up to a 1.8 V voltage inside the module. The control signals (GPIO) of the host device could be at 1.8 V or 3.3 V voltage level. W_DISABLE1# and W_DISABLE2# are active low signals. A reference circuit of the two pins is shown below.




Figure 16: Reference Circuit of W_DISABLE1# and W_DISABLE2#

4.3.3. WWAN_LED#

The WWAN_LED# signal is used to indicate RF status of the module, and its sink current is up to 10 mA. To reduce power consumption of the LED, a current-limited resistor must be placed in series with the LED, as illustrated in the figure below. The LED is ON when the WWAN_LED# signal is at low level.




Figure 17: WWAN_LED# Reference Circuit

Table 18: Network Status Indications of WWAN_LED#


WWAN_LED# Logic Level	Description
Low (LED On)	RF function is turned on.
High (LED Off)	RF function is turned off if any of the following occurs: <ul style="list-style-type: none">• The (U)SIM card is not powered.• W_DISABLE1# is at low level (airplane mode enabled).• AT+CFUN=4 and AT+CFUN=0 (RF function disabled).

4.3.4. WAKE_ON_WAN#

The WAKE_ON_WAN# is an open drain pin, which requires a pull-up resistor on the host. When a URC returns, a one-second low level pulse signal will be outputted to wake up the host.

Table 19: State of the WAKE_ON_WAN#

WAKE_ON_WAN# State	Module Operation Status
Output a one-second pulse signal at low level	SMS/Data is incoming (to wake up the host)
Always at high level	Idle/Sleep



NOTE: The voltage level on VCC_IO_HOST depends on the host side due to the open drain in pin 23.


Figure 18: Reference Circuit of WAKE_ON_WAN#

4.3.5. DPR

The module provides a DPR (Dynamic Power Reduction) signal for body SAR (Specific Absorption Rate) detection. The signal is sent by a host system proximity sensor to the module to provide an input trigger which will reduce the output power in the radio transmission.

Table 20: Function of the DPR Signal

DPR Level	Function
High/Floating	Max. transmitting power will not back off
Low	Max. transmitting power will back off by executing AT+QCFG="SAR_DSI"



Note: Host's GPIO could be a 1.8 V or 3.3 V voltage level.

Figure 19: DPR Signal Reference Circuit Design

NOTE

See document [2] for more details about AT+QCFG="SAR_DSI".

4.3.6. WLAN_PA_EN

- In LTE mode, WLAN_PA_EN is set to 0 (low level) by default.
- When WLAN_PA_EN is set to 1 (high level), the LNA will be in self-protection mode.

Table 21: Pin definition of WLAN_PA_EN

Pin No.	Pin Name	I/O	Description
60	WLAN_PA_EN	DI	Self-protection of LNA control

4.4. Cellular/WLAN COEX Interface*

The module provides the cellular/WLAN COEX interface.
The following table shows the pin definition of this interface.
Table 22: Pin Definition of Cellular/WLAN COEX Interface

Pin No.	Pin Name	I/O	Description
62	COEX_RXD	DI	LTE/WLAN coexistence receive
64	COEX_TXD	DO	LTE/WLAN coexistence transmit

NOTE

Please note that COEX_RXD and COEX_TXD cannot be used as general UART.

4.5. Configuration Pins


Table 23: List of Configuration Pins

Config_0 (Pin 21)	Config_1 (Pin 69)	Config_2 (Pin 75)	Config_3 (Pin 1)	Module Type and Main Host Interface	Port Configuration
GND	GND	NC	NC	WWAN–USB 3.0	2

Table 24: Pin Definition of Configuration Pins

Pin No.	Pin Name	I/O	Description
21	CONFIG_0	DO	Connected to GND internally
69	CONFIG_1	DO	Connected to GND internally
75	CONFIG_2	DO	Not connected internally
1	CONFIG_3	DO	Not connected internally

The following figure shows a reference circuit for these four pins.



NOTE: The voltage level VCC_IO_HOST depends on the host side, and could be a 1.8 V or 3.3 V voltage level.

Figure 20: Recommended Circuit of Configuration Pins

RF Specifications

Appropriate antenna type and design should be used with matched antenna parameters according to specific application. It is required to perform a comprehensive functional test for the RF design before mass production of terminal products. The entire content of this chapter is provided for illustration only. Analysis, evaluation and determination are still necessary when designing target products.

5.1. Cellular Network

5.1.1. Antenna Interface & Frequency Bands

The module provides a main antenna connector and a diversity/GNSS antenna connector, which are used to resist the fall of signals caused by high-speed movement and multipath effect. The impedance of antenna interfaces is 50 Ω.

Table 25: Antenna Connector Definition

Antenna Connector	I/O	Description	Comment
ANT_MAIN	AIO	Main antenna interface: • LTE: TRX • <u>WCDMA: TRX</u>	
		RX-Diversity/GNSS antenna interface: • LTE: DRX • WCDMA: DRX • GNSS: L1	50 Ω impedance
ANT_DRX/GNSS	AI		

Table 26: Frequency Bands

3GPP Band	Transmit	Receive	Unit
WCDMA B1	1920–1980	2110–2170	MHz
WCDMA B2	1850–1910	1930–1990	MHz
WCDMA B3	1710–1785	1805–1880	MHz
WCDMA B4	1710–1755	2110–2155	MHz
WCDMA B5	824–849	869–894	MHz
WCDMA B6	830–840	875–885	MHz
WCDMA B8	880–915	925–960	MHz
WCDAM B19	830–845	875–890	MHz
LTE-FDD B1	1920–1980	2110–2170	MHz
LTE-FDD B2	1850–1910	1930–1990	MHz

LTE-FDD B3	1710–1785	1805–1880	MHz
LTE-FDD B4	1710–1755	2110–2155	MHz
LTE-FDD B5	824–849	869–894	MHz
LTE-FDD B7	2500–2570	2620–2690	MHz
LTE-FDD B8	880–915	925–960	MHz
LTE-FDD B12	699–716	729–746	MHz
LTE-FDD B13	777–787	746–756	MHz
LTE-FDD B14	788–798	758–768	MHz
LTE-FDD B17	704–716	734–746	MHz
LTE-FDD B18	815–830	860–875	MHz
LTE-FDD B19	830–845	875–890	MHz
LTE-FDD B20	832–862	791–821	MHz
LTE-FDD B25	1850–1915	1930–1995	MHz

LTE-FDD B26	814–849	859–894	MHz
LTE-FDD B28	703–748	758–803	MHz
LTE-FDD B29 7	–	717–728	MHz
LTE-FDD B30	2305–2315	2350–2360	MHz
LTE-FDD B32 7	–	1452–1496	MHz
LTE-FDD B66	1710–1780	2110–2200	MHz
LTE-FDD B71	663-698	617-652	MHZ
LTE-TDD B34	2010-2025	2010-2025	MHZ
LTE-TDD B38	2570–2620	2570–2620	MHz
LTE-TDD B39	1880–1920	1880–1920	MHz
LTE-TDD B40	2300–2400	2300–2400	MHz
LTE-TDD B41	2496–2690	2496–2690	MHz
LTE-TDD B42	3400–3600	3400–3600	MHz
LTE-TDD B43	3600–3800	3600–3800	MHz
LTE-TDD B46 7	–	5150–5925	MHz

7 LTE-FDD B29/B32 and LTE-TDD B46 support Rx only and is only for secondary component carrier.

LTE-TDD B48	3550–3700	3550–3700	MHz
-------------	-----------	-----------	-----

5.1.2. Antenna Tuner Control Interfaces*

ANTCTL [0:3] and RFFE interfaces are used for antenna tuner control and should be routed to an appropriate antenna control circuit.

5.1.2.1. Antenna Tuner Control Interface through GPIOs

Table 27: Pin Definition of Antenna Tuner Control Interface through GPIOs

Pin No.	Pin Name	I/O	Description	Comment
59	ANTCTL0	DO		1.8 V
61	ANTCTL1	DO		1.8 V
			Antenna GPIO control	
63	ANTCTL2	DO		1.8 V
65	ANTCTL3	DO		1.8 V

5.1.2.2. Antenna Tuner Control Interface through RFFE

Table 28: Pin Definition of Antenna Tuner Control Interface through RFFE

Pin No.	Pin Name	I/O	Description	Comment
56	RFFE_CLK	DO	Used for external MIPI IC control	1.8 V
58	RFFE_DATA	DIO	Used for external MIPI IC control	1.8 V

NOTE

If RFFE_CLK and RFFE_DATA are required, please contact NetPrisma for more details.

5.1.3. Tx Power

Table 29: Conducted RF Output Power

Frequency Band	Modulation	Max.	Min.	Comment
WCDMA B1	BPSK	23 dBm \pm 2 dB	< -50 dBm	
WCDMA B2	BPSK	23 dBm \pm 2 dB	< -50 dBm	
WCDMA B3	BPSK	23 dBm \pm 2 dB	< -50 dBm	

WCDMA B4	BPSK	23 dBm \pm 2 dB	< -50 dBm	
WCDMA B5	BPSK	23 dBm \pm 2 dB	< -50 dBm	
WCDMA B6	BPSK	23 dBm \pm 2 dB	< -50 dBm	
WCDMA B8	BPSK	23 dBm \pm 2 dB	< -50 dBm	
WCDMA B19	BPSK	23 dBm \pm 2 dB	< -50 dBm	
LTE-FDD B1	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB

LTE-FDD B2	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B3	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B4	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B5	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B7	QPSK	23 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B8	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B12	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B13	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B14	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B17	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B18	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B19	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B20	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B25	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B26	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B28	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B30	QPSK	22 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B66	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-FDD B71	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-TDD B34	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-TDD B38	QPSK	23 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-TDD B39	QPSK	23.5 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB

LTE-TDD B40	QPSK	23 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
-------------	------	-------------------	-----------	-------------

LTE-TDD B41	QPSK	23 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-TDD B42	QPSK	21 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-TDD B43	QPSK	21 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB
LTE-TDD B48	QPSK	21 dBm \pm 1 dB	< -40 dBm	10 MHz, 1RB

5.1.4. Rx Sensitivity

Table 30: Rx Sensitivity

Frequency Band	SIMO (dBm) 8	3GPP (SIMO) (dBm)	Comment 9
WCDMA B1	-111.5	-106.7	
WCDMA B2	-111	-104.7	
WCDMA B3	-111	-103.7	
WCDMA B4	-111	-106.7	
WCDMA B5	-113	-104.7	
WCDMA B6	-113	-106.7	
WCDMA B8	-113.5	-103.7	
WCDMA B19	-113	-106.7	
LTE-FDD B1	-100	-96.3	10 MHz
LTE-FDD B2	-100	-94.3	10 MHz
LTE-FDD B3	-100	-93.3	10 MHz
LTE-FDD B4	-99	-96.3	10 MHz
LTE-FDD B5	-101	-94.3	10 MHz
LTE-FDD B7	-98.5	-94.3	10 MHz
LTE-FDD B8	-101	-93.3	10 MHz
LTE-FDD B12	-101	-93.3	10 MHz
LTE-FDD B13	-101	-93.3	10 MHz
LTE-FDD B14	-101	-93.3	10 MHz
LTE-FDD B17	-101	-93.3	10 MHz
LTE-FDD B18	-101	-96.3	10 MHz

8 SIMO is a smart antenna technology that uses a single antenna at the transmitter side and multiple antennas at the receiver side, which can improve Rx performance.

9 The RB configuration follows 3GPP specification.

LTE-FDD B19	-101	-96.3	10 MHz
LTE-FDD B20	-100.5	-93.3	10 MHz
LTE-FDD B25	-99.5	-92.8	10 MHz
LTE-FDD B26	-100.5	-93.8	10 MHz
LTE-FDD B28	-100.5	-94.8	10 MHz
LTE-FDD B29 10	-101	-93.3	10 MHz
LTE-FDD B30	-98	-95.3	10 MHz
LTE-FDD B32 10	-99.5	-96.3	10 MHz
LTE-FDD B66	-99	-95.8	10 MHz
LTE-FDD B71	-100.5	-94.3	10 MHz
LTE-TDD B34	-100	-96.3	10 MHz
LTE-TDD B38	-99.5	-96.3	10 MHz
LTE-TDD B39	-99.5	-96.3	10 MHz
LTE-TDD B40	-98.5	-96.3	10 MHz
LTE-TDD B41	-98.5	-94.3	10 MHz
LTE-TDD B42	-100	-95.0	10 MHz
LTE-TDD B43	-100	-95.0	10 MHz
LTE-TDD B46 10	-95	-88.5	20 MHz
LTE-TDD B48	-99.5	-95.0	10 MHz

5.2. GNSS 11

5.2.1. Antenna Interface & Frequency Bands

The module includes a fully integrated global navigation satellite system solution.

The module supports standard NMEA 0183 protocol, and outputs NMEA sentences at 1 Hz data update rate via

USB interface by default.

By default, the module GNSS engine is switched off. It is to be switched on via AT command. For more details, see document [3].

10 The test results are based on CA_2A-29A, CA_20A-32A and CA_46A-66A. LTE-FDD B29/B32 and LTE-TDD B46 support Rx only and are only for secondary component carrier.

11 GNSS function is optional.

Table 31: GNSS Frequency

Type	Frequency	Unit
GPS/Galileo	1575.42 \pm 1.023	MHz
GLONASS	1601.65 \pm 4.15	MHz
BDS	1561.098 \pm 2.046	MHz
QZSS	1575.42 \pm 1.023	MHz

5.2.2. GNSS Performance

Table 32: GNSS Performance

Parameter	Description	Condition	Typ.	Unit
	Acquisition	Autonomous	-146	dBm
Sensitivity	Reacquisition	Autonomous	-158	dBm
	Tracking	Autonomous	-158	dBm
	Cold start	Autonomous	35	s
	@ open sky	XTRA start	13	s
	Warm start	Autonomous	23	s
TTF	@ open sky	XTRA start	3	s
	Hot start	Autonomous	2	s
	@ open sky	XTRA start	2	s

Accuracy	CEP-50	Autonomous @ open sky	2	m
----------	--------	--------------------------	---	---

NOTE

1. Tracking sensitivity: the minimum GNSS signal power at which the module can maintain lock (keep positioning for at least 3 minutes continuously).
2. Reacquisition sensitivity: the minimum GNSS signal power required for the module to maintain lock within 3 minutes after loss of lock.
3. Acquisition sensitivity: the minimum GNSS signal power at which the module can fix position successfully within 3 minutes after executing cold start command.

5.3. Antenna Design Requirements

Table 33: Antenna Requirements

Type	Requirements
Main Antenna (WCDMA/LTE Tx/Rx)	<ul style="list-style-type: none"> • VSWR: ≤ 2 • Efficiency: $>30\%$ • Max Input Power: 50 W • Input Impedance: $50\ \Omega$ • Cable Insertion Loss: <ul style="list-style-type: none"> – $< 1\text{ dB}$: LB ($<1\text{ GHz}$) – $< 1.5\text{ dB}$: MB (1–2.3 GHz) – $< 2\text{ dB}$: LB ($> 2.3\text{ GHz}$)
Diversity/GNSS Antenna (WCDMA/LTE/GNSS Rx)	

NOTE

It is recommended to use a passive GNSS antenna when LTE B13 or B14 is supported, as the use of active antenna may generate harmonics which will affect the GNSS performance.

5.4. Antenna Connectors

5.4.1. Antenna Connector Location

The antenna connector locations are shown below.



Figure 21: Antenna Connectors on LCUK54-WWD

5.4.2. Antenna Connector Specifications

The module is mounted with standard 2 mm × 2 mm receptacle antenna connectors for convenient antenna connection. The antenna connector's PN is I-PEX 20449-001E, and the connector dimensions are illustrated as below:




Figure 22: Dimensions of the Receptacle (Unit: mm)

Table 34: Major Specifications of the RF Connectors

Item	Specification
Nominal Frequency Range	DC to 6 GHz
Nominal Impedance	50 Ω
Temperature Rating	-40 to +85 °C
Voltage Standing Wave Ratio (VSWR)	Meet the requirements of: Max. 1.3 (DC–3 GHz) Max. 1.45 (3–6 GHz)

5.4.3. Antenna Connector Installation

The receptacle RF connector used in conjunction with the module will accept two types of mated plugs that will meet a maximum height of 1.2 mm using a \varnothing 0.81 mm coaxial cable or a maximum height of 1.45 mm utilizing a \varnothing 1.13 mm coaxial cable.

The following figure shows the dimensions of mated plugs using \varnothing 0.81 mm/ \varnothing 1.13 mm coaxial cables:




Figure 23: Dimensions of Mated Plugs (\varnothing 0.81/ \varnothing 1.13 mm Coaxial Cables)

The following figure illustrates the connection between the receptacle RF connector on the module and the mated plugs using a \varnothing 0.81 mm coaxial cable.




Figure 24: Space Factor of Mated Connectors (\varnothing 0.81 mm Coaxial Cables) (Unit: mm)

The following figure illustrates the connection between the receptacle RF connector on the module and the mated plugs using a \varnothing 1.13 mm coaxial cable.




Figure 25: Space Factor of Mated Connectors (Ø 1.13 mm Coaxial Cables) (Unit: mm)

5.4.4. Recommended RF Connector Installation

5.4.4.1. Assemble Coaxial Cable Plug Manually

The illustration for plugging in a coaxial cable plug is shown below, $\theta = 90^\circ$ is acceptable, while $\theta \neq 90^\circ$ is not.




Figure 26: Plug in a Coaxial Cable Plug

The illustration of pulling out the coaxial cable plug is shown below, $\theta = 90^\circ$ is acceptable, while $\theta \neq 90^\circ$ is not.




Figure 27: Pull out a Coaxial Cable Plug

5.4.4.2. Assemble Coaxial Cable Plug with Jig

The pictures of installing the coaxial cable plug with a jig is shown below, $\theta = 90^\circ$ is acceptable, while $\theta \neq 90^\circ$ is not.




Figure 28: Install the Coaxial Cable Plug with Jig

5.4.5. Recommended Manufacturers of RF Connector and Cable

RF connectors and cables by I-PEX are recommended. For more details, visit <https://www.i-pex.com>.

Electrical Characteristics and Reliability

6.1. Absolute Maximum Ratings

Absolute maximum ratings for power supply of the module are listed in the following table.

Table 35: Absolute Maximum Ratings

Parameter	Min.	Typ.	Max.	Unit
VCC	-0.3	3.3	4.7	V

6.2. Power Supply Ratings

The typical input voltage of the module is 3.3 V.

Table 36: Power Supply Ratings

Parameter	Description	Condition	Min.	Typ.	Max.	Unit
VCC	Power supply for the module	The actual input voltages must be kept between the minimum and maximum values.	3.135	3.3	4.4	V
Voltage Ripple	—	—	—	30	100	mV

6.3. Power Consumption

Table 37: Power Consumption (3.7 V Power Supply)

Parameter	Condition	Typ.	Unit
Power-off	Power off	70	μA
Sleep State	AT+CFUN=0 (USB 2.0 Suspend)	1.67	mA

	AT+CFUN=4 (USB 2.0 Suspend)	2.28	mA
	WCDMA PF = 64 (USB 2.0 Suspend)	3.64	mA
	LTE-FDD PF = 64 (USB 2.0 Suspend)	3.88	mA
	LTE-TDD PF = 64 (USB 2.0 Suspend)	3.90	mA
	WCDMA PF = 64	13.39	mA
Idle State	LTE-FDD PF = 64	13.85	mA
	LTE-TDD PF = 64	13.61	mA
	WCDMA B1 HSDPA CH10700 @ 22.3 dBm	748	mA
	WCDMA B1 HSUPA CH10700 @ 22.3 dBm	660	mA
	WCDMA B2 HSDPA CH9800 @ 22.1 dBm	640	mA
	WCDMA B2 HSUPA CH9800 @ 22.3dBm	660	mA
	WCDMA B3 HSDPA CH1338 @ 22.2 dBm	670	mA
	WCDMA B3 HSUPA CH1338 @ 22.4 dBm	680	mA
	WCDMA B4 HSDPA CH1638 @22.2 dBm	670	mA
WCDMA Data Trans mission (GNSS Off)	WCDMA B4 HSUPA CH1638 @ 22.4 dBm	670	mA
	WCDMA B5 HSDPA CH4407 @22.5 dBm	600	mA
	WCDMA B5 HSUPA CH4407 @ 22.5 dBm	615	mA
	WCDMA B6 HSDPA CH4400 @ 22.5 dBm	600	mA
	WCDMA B6 HSUPA CH4400 @ 22.5 dBm	625	mA
	WCDMA B8 HSDPA CH3012 @22.4 dBm	650	mA

	WCDMA B8 HSUPA CH3012 @ 22.4 dBm	650	mA
	WCDMA B19 HSDPA CH738 @ 22.3 dBm	640	mA
	WCDMA B19 HSUPA CH738 @ 22.6 dBm	600	mA
	LTE-FDD B1 CH300 @ 23.7 dBm	840	mA
	LTE-FDD B2 CH900 @ 23.9 dBm	810	mA
LTE Data Transmission (GNSS Off)	LTE-FDD B3 CH1575 @ 23.7dBm	810	mA
	LTE-FDD B4 CH2175 @ 23.6 dBm	830	mA
	LTE-FDD B5 CH2525 @ 23.8 dBm	760	mA
	LTE-FDD B7 CH3100 @ 23.22 dBm	950	mA

	LTE-FDD B8 CH3625 @ 23.7 dBm	770	mA
	LTE-FDD B12 CH5095 @ 23.6 dBm	710	mA
	LTE-FDD B13 CH5230 @ 23.5 dBm	700	mA
	LTE-FDD B14 CH5330 @ 23.5 dBm	660	mA
	LTE-FDD B17 CH5790 @ 23.6 dBm	700	mA
	LTE-FDD B18 CH5925 @ 23.6 dBm	750	mA
	LTE-FDD B19 CH6075 @ 23.6 dBm	780	mA
	LTE-FDD B20 CH6300 @ 23.6 dBm	700	mA
	LTE-FDD B25 CH8365 @ 24 dBm	820	mA
	LTE-FDD B26 CH8865 @ 23.6 dBm	840	mA
	LTE-FDD B28 CH9360 @ 23.4 dBm	710	mA
	LTE-FDD B30 CH9820 @ 22.3 dBm	1100	mA
	LTE-FDD B66 CH66886 @ 23.6 dBm	840	mA

	LTE-FDD B71 CH68786 @23.7 dBm	790	mA
	LTE-TDD B34 CH36275 @ 23.4 dBm	400	mA
	LTE-TDD B38 CH38000 @ 23.3 dBm	500	mA
	LTE-TDD B39 CH38450 @ 23.5 dBm	400	mA
	LTE-TDD B40 CH39150 @ 23.2 dBm	450	mA
	LTE-TDD B41 CH40740 @ 23.3 dBm	500	mA
	LTE-TDD B42 CH42590 @ 21.5 dBm	380	mA
	LTE-TDD B43 CH44590 @ 21.5 dBm	360	mA
	LTE-TDD B48 CH55990 @ 21.5 dBm	360	mA
	WCDMA B1 CH10700 @ 23.2 dBm	780	mA
	WCDMA B2 CH9800 @23.3 dBm	690	mA
	WCDMA B3 CH1338 @ 23.2 dBm	720	mA
WCDMA	WCDMA B4 CH1638 @ 23.2 dBm	700	mA
	WCDMA B5 CH4407 @ 23.2 dBm	660	mA
	WCDMA B6 CH4400 @23.3 dBm	650	mA
	WCDMA B8 CH3012 @ 23.4 dBm	690	mA

WCDMA B19 CH738 @23.3 dBm	640	mA
---------------------------	-----	----

NOTE

1. Power consumption test is carried out under 3.7 V, 25 °C with 5G-M2 EVB, and with thermal dissipation measures.
2. For more details about power consumption, please contact NetPrisma Technical Support to obtain the power consumption test report of the modules.

6.4. Digital I/O Characteristics

Table 38: (U)SIM High/Low-voltage I/O Requirements

Parameter	Description	Min.	Max.	Unit
VIH	High-level input voltage	$0.7 \times \text{USIM_VDD}$	$\text{USIM_VDD} + 0.3$	V
VIL	Low-level input voltage	-0.3	$0.2 \times \text{USIM_VDD}$	V
VOH	High-level output voltage	$0.8 \times \text{USIM_VDD}$	–	V
VOL	Low-level output voltage	–	0.4	V

Table 39: 1.8 V Digital I/O Requirements

Parameter	Description	Min.	Max.	Unit
VIH	High-level input voltage	1.65	2.1	V
VIL	Low-level input voltage	-0.3	0.54	V
VOH	High-level output voltage	1.3	–	V
VOL	Low-level output voltage	–	0.4	V

Table 40: 3.3 V Digital I/O Requirements

Parameter	Description	Min.	Max.	Unit
3.3 V	Power Domain	3.135	3.464	V
VIH	High-level input voltage	2.0	3.6	V
VIL	Low-level input voltage	-0.5	0.8	V

6.5. ESD Protection

Static electricity occurs naturally and it may damage the module. Therefore, applying proper ESD countermeasures and handling methods is imperative. For example, wear anti-static gloves during the development, production, assembly and testing of the module; add ESD protection components to the ESD sensitive interfaces and points in the product design.

Table 41: Electrostatic Discharge Characteristics (Temperature: 25–30 °C, Humidity: 40 ±5 %)

Tested Interface	Contact Discharge	Air Discharge	Unit
VCC, GND	±5	±10	kV
Antenna Interfaces	±4	±8	kV
Other Interfaces	±0.5	±1	kV

6.6. Operating and Storage Temperatures

Table 42: Operating and Storage Temperatures

Parameter	Min.	Typ.	Max.	Unit
Operating Temperature Range 12	-25	+25	+75	°C
Extended Temperature Range 13	-40	–	+85	°C
Storage Temperature Range	-40	–	+90	°C

12 To meet the normal operating temperature range requirements, it is necessary to ensure effective thermal dissipation, e.g., by adding passive or active heat sinks, heat pipes, vapor chambers. Within the temperature range of -10 °C to +55 °C the mentioned RF performance margins higher than 3GPP specifications can be guaranteed. When temperature goes beyond temperature range of -10 °C to +55 °C, a few RF performances of module may be slightly off 3GPP specifications. 13 To meet the extended operating temperature range requirements, it is necessary to ensure effective thermal dissipation, e.g., by adding passive or active heat sinks, heat pipes, vapor chambers. Within this range, the module remains the ability to establish and maintain functions such as SMS, without any unrecoverable malfunction. Radio spectrum and radio network are not influenced, while one or more specifications, such as Pout, may undergo a reduction in value, exceeding the specified tolerances of 3GPP. When the temperature returns to the normal operating temperature level, the module will meet 3GPP specifications again.

6.7. Thermal Dissipation




Figure 29: Distribution of Heat Source Chips Inside the Module

The module offers the best performance when all internal IC chips are working within their operating temperatures. When the IC chip reaches or exceeds the maximum junction temperature, the module may still work but the performance and function (such as RF output power and data rate) will be affected to a certain extent. Therefore, the thermal design should be maximally optimized to ensure all internal IC chips always work within the recommended operating temperature range.

The following principles for thermal consideration are provided for reference:

- Keep the module away from heat sources on your PCB, especially high-power components such as processor, power amplifier, and power supply.
- Maintain the integrity of the PCB copper layer and drill as many thermal vias as possible.
- Expose the copper in the PCB area where module is mounted.
- Apply a soft thermal pad with appropriate thickness and high thermal conductivity between the module and the PCB to conduct heat.
- Follow the principles below when the heatsink is necessary:
 - Do not place large size components in the area where the module is mounted on your PCB to reserve enough place for heatsink installation.
 - Attach the heatsink to the shielding cover of the module; In general, the base plate area of the heatsink should be larger than the module area to cover the module completely.
 - Choose the heatsink with adequate fins to dissipate heat.
 - Choose a TIM (Thermal Interface Material) with high thermal conductivity, good softness and good wettability and place it between the heatsink and the module.
 - Fasten the heatsink with four screws to ensure that it is in close contact with the module to prevent the heatsink from falling off during the drop, vibration test, or transportation.




Figure 30: Placement and Fixing of the Heatsink

Table 43: Maximum Operating Temperature for Main Chips (Unit: °C)

Baseband Chip	MCP	PMU	WTR	MMPA	PA	APT
85	85	85	85	100	85	85

6.8. Notification

Please follow the principles below in the module application.

6.8.1. Coating

If a conformal coating is necessary for the module, do NOT use any coating material that may chemically react with the PCB or shielding cover, and prevent the coating material from flowing into the module.

6.8.2. Cleaning

Avoid using ultrasonic technology for module cleaning since it can damage crystals inside the module.

6.8.3. Module Installation

The module needs to be fixed firmly to avoid poor contact caused by shaking. When installing the module, it is recommended to be mounted on the socket with a screw as shown below.




Figure 31: Installation Schematic

Mechanical Information and Packaging

This chapter mainly describes mechanical dimensions and packaging specifications of LCUK54-WWD. All dimensions are measured in mm, and the tolerances are ± 0.15 mm unless otherwise specified.

7.1. Mechanical Dimensions




Figure 32: Mechanical Dimensions (Unit: mm)

7.2. Top and Bottom Views



Figure 33: Top and Bottom Views

NOTE

Images above are for illustration purpose only and may differ from the actual modules. For authentic appearance and label, please refer to the module received from NetPrisma.

7.3. M.2 Connector

The module adopts a standard PCI Express M.2 connector which compiles with the directives and standards listed in PCI Express M.2 Specification.

7.4. Storage Conditions

The storage requirements are shown below.

1. Recommended Storage Condition: the temperature should be 23 ± 5 °C and the relative humidity should be 35–60 %.
2. Shelf life: 12 months in Recommended Storage Condition.

NOTE

Pay attention to ESD protection, such as wearing anti-static gloves, when touching the modules.

7.5. Packaging Specification

This chapter outlines the key packaging parameters and processes. All figures below are for reference purposes only, as the actual appearance and structure of packaging materials may vary in delivery.

The modules are packed in a blister tray packaging as specified in the sub-chapters below.

7.5.1. Blister Tray

Blister tray dimensions are illustrated in the following figure:






Figure 34: Blister Tray Dimension Drawing (Unit: mm)

7.5.2. Packaging Process


Each blister tray packs 15 modules. Stack 10 trays with modules, and place 1 empty tray on top.



Fasten the 11 trays and place them into a conductive bag and fasten it.



Pack the conductive bag with blister trays into a mini box. 1 mini box can pack 150 modules.



Place the 4 packaged mini boxes into 1 carton and seal it. 1 carton can pack 600 modules.




Figure 35: Packaging Process

Appendix References

Table 44: Related Documents

Document Name

- [1] NetPrisma_LCUK54-WWD_CA_Feature
- [2] NetPrisma_LCUK54-WWD_AT_Commands_Manual
- [3] NetPrisma_LCUK54-WRD_GNSS_Application_Note
- [4] NetPrisma_LCUK54-WWD_RF_Application_Note

Table 45: Terms and Abbreviations

Abbreviation	Description
APT	Average Power Tracking
AT	Attention
BB	Baseband
bps	Bit(s) per second
BPSK	Binary Phase Shift Keying
CA	Carrier Aggregation Certificate Authority
CBRS	Citizen Broadband Radio Service
COEX	Coexistence
DC-HSDPA	Dual-carrier High Speed Downlink Package Access
DFOTA	Delta Firmware Upgrade Over-The-Air
DL	Downlink
DPR	Dynamic Power Reduction
DRX	Discontinuous Reception
ESD	Electrostatic Discharge
eSIM	embedded Subscriber Identity Module
ESR	Equivalent Series Resistance
FDD	Frequency Division Duplex

FTP	File Transfer Protocol
HSDPA	High Speed Downlink Packet Access
HSPA+	High Speed Packet Access

HSUPA	High Speed Uplink Packet Access
HTTP	Hypertext Transfer Protocol
HTTPS	Hypertext Transfer Protocol Secure
IC	Integrated Circuit
kbps	Kilobits per second
LAA	License Assisted Access
LDO	Low-dropout Regulator
LED	Light Emitting Diode
LPDDR2	Low Power Double Data Rate 2
LTE	Long Term Evolution
LwM2M	Lightweight M2M
MBIM	Mobile Broadband Interface Model
Mbps	Megabits per second
MCP	Multiple Chip Package
ME	Mobile Equipment
MFBI	Multi-Frequency Band Indicator
MIPI	Mobile Industry Processor Interface
MIMO	Multiple-Input Multiple-Output
MLCC	Multi-layer Ceramic Capacitor
MMPA	Multimode Multiband Power Amplifier
MO	Mobile Originated

MT	Mobile Terminated
NAND	NON-AND
NC	Not Connected
NITZ	Network Identity and Time Zone / Network Informed Time Zone.
NMEA	NMEA (National Marine Electronics Association) 0183 Interface Standard

PA	Power Amplifier
PC	Personal Computer
PCB	Printed Circuit Board
PCIe	Peripheral Component Interconnect Express
PCM	Pulse Code Modulation
PDA	Personal Digital Assistant
PDU	Protocol Data Unit
PING	Packet Internet Groper
PMU	Power Management Unit
POS	Point of Sale
QAM	Quadrature Amplitude Modulation
LNA	Low-Noise Amplifier
QMI	Qualcomm MSM (Mobile Station Modems) Interface
QPSK	Quadrature Phase Shift Keying
RB	Resource Block

RF	Radio Frequency
RFFE	RF Front-End
RoHS	Restriction of Hazardous Substances
Rx	Receive
SAR	Specific Absorption Rate
SDRAM	Synchronous Dynamic Random-Access Memory
SIMO	Single Input Multiple Output
SMS	Short Message Service
TCP	Transmission Control Protocol
TDD	Time Division Duplex
TRX	Transmit & Receive
TVS	Transient Voltage Suppressor
Tx	Transmit
UART	Universal Asynchronous Receiver/Transmitter
UDP	User Datagram Protocol

UL	Uplink
UMTS	Universal Mobile Telecommunications System
URC	Unsolicited Result Code
USB	Universal Serial Bus
(U)SIM	(Universal) Subscriber Identity Module
VIH	High-level Input Voltage
VIHmax	Maximum High-level Input Voltage
VIHmin	Minimum High-level Input Voltage
VIL	Low-level Input Voltage
VILmax	Maximum Low-level Input Voltage
Vmax	Maximum Voltage
Vmin	Minimum Voltage
Vnom	Nominal Voltage
VOH	High-level Output Voltage
VOL	Low-level Output Voltage
WCDMA	Wideband Code Division Multiple Access
WTR	Wafer-scale RF transceiver
WWAN	Wireless Wide Area Network

9.1 FCC

9.1.1. Important Notice to OEM integrators

1. This module is limited to OEM installation ONLY.
2. This module is limited to installation in mobile or fixed applications, according to Part 2.1091(b).
3. The separate approval is required for all other operating configurations, including portable configurations with

respect to Part 2.1093 and different antenna configurations.

4. For FCC Part 15.31 (h) and (k): The host manufacturer is responsible for additional testing to verify compliance as a composite system. When testing the host device for compliance with Part 15 Subpart B, the host manufacturer is required to show compliance with Part 15 Subpart B while the transmitter module(s) are installed and operating. The modules should be transmitting and the evaluation should confirm that the module's intentional emissions are compliant (i.e. fundamental and out of band emissions). The host manufacturer must verify that there are no additional unintentional emissions other than what is permitted in Part 15 Subpart B or emissions are complaint with the transmitter(s) rule(s).
The Grantee will provide guidance to the host manufacturer for Part 15 B requirements if needed.

9.1.2. Important Note

notice that any deviation(s) from the defined parameters of the antenna trace, as described by the instructions, require that the host product manufacturer must notify to XXXX that they wish to change the antenna trace design. In this case, a Class II permissive change application is required to be filed by the USI, or the host manufacturer can take responsibility through the change in FCC ID (new application) procedure followed by a Class II permissive change application.

9.1.3. End Product Labeling

When the module is installed in the host device, the FCC/IC ID label must be visible through a window on the final device or it must be visible when an access panel, door or cover is easily re-moved. If not, a second label must be placed on the outside of the final device that contains the following text: "Contains FCC ID: 2BEY3LCUK54WWDA" "Contains IC: 32052-LCUK54WWDA " The FCC ID/IC ID can be used only when all FCC/IC compliance requirements are met.

9.1.4. Antenna Installation

1. The antenna must be installed such that 20 cm is maintained between the antenna and users,
2. The transmitter module may not be co-located with any other transmitter or antenna.
3. Only antennas of the same type and with equal or less gains as shown below may be used with this module.
Other types of antennas and/or higher gain antennas may require additional authorization for operation.

Band	MAX Gain (dBi)
WCDMA B2	8.00
WCDMA B4	5.00
WCDMA B5	9.42
LTE B2	8.50
LTE B4	5.50
LTE B5	9.91
LTE B7	9.00
LTE B12	9.20
LTE B13	9.66
LTE B14	9.73
LTE B17	9.24
LTE B25	8.50
LTE B26(814-824)	9.86
LTE B26(824-849)	9.91
LTE B30	0.98
LTE B38	9.00
LTE B41	9.00
LTE B42	8.00
LTE B43	1.00
LTE B48	1.00
LTE B66	5.50
LTE B71	8.98

In the event that these conditions cannot be met (for example certain laptop configurations or colocation with another transmitter), then the FCC/IC authorization is no longer considered valid and the FCC ID/IC ID cannot be

used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC/IC authorization.

9.1.5. Manual Information to the End User

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module. The end user manual shall include all required regulatory information/warning as show in this manual.

9.1.6. Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

9.1.7. List of applicable FCC rules

This module has been tested and found to comply with part 22, part 24, part 27 and part 90 requirements for Modular Approval.

The modular transmitter is only FCC authorized for the specific rule parts (i.e., FCC transmitter rules) listed on the grant, and that the host product manufacturer is responsible for compliance to any other FCC rules that apply to the host not covered by the modular transmitter grant of certification. If the grantee markets their product as being Part 15 Subpart B compliant (when it also contains unintentional-radiator digital circuitry), then the grantee shall provide a notice stating that the final host product still requires Part 15 Subpart B compliance testing with the modular transmitter installed.

9.1.8. This device is intended only for OEM integrators under the following conditions:(For module device use)

1. The antenna must be installed such that 20 cm is maintained between the antenna and users, and
2. The transmitter module may not be co-located with any other transmitter or antenna.

As long as 2 conditions above are met, further transmitter test will not be required. However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements required with this module installed.

9.1.9. Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

9.2. IC

9.2.1. Industry Canada Statement

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device

9.2.2. Radiation Exposure Statement

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

9.2.4. This device is intended only for OEM integrators under the following conditions: (For module device use)

- 1) The antenna must be installed such that 20 cm is maintained between the antenna and users, and
- 2) The transmitter module may not be co-located with any other transmitter or antenna.

As long as 2 conditions above are met, further transmitter test will not be required. However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements required with this module installed.

9.2.6. IMPORTANT NOTE:

In the event that these conditions can not be met (for example certain laptop configurations or colocation with another transmitter), then the Canada authorization is no longer considered valid and the IC ID can not be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate Canada authorization.

9.2.8. End Product Labeling

This transmitter module is authorized only for use in device where the antenna may be installed such that 20 cm may be maintained between the antenna and users. The final end product must be labeled in a visible area with the following: "Contains IC: 32052-LCUK54WWDA".

9.2.10. Manual Information To the End User

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module.

The end user manual shall include all required regulatory information/warning as show in this manual.

9.2.12 Antenna Requirements

The following antennae were approved with the prototype:

This radio transmitter [32052-LCUK54WWDA] has been approved by innovation, Science and development Economic Canada to operate with the types of antennas listed below, with the maximum allowable gain indicated. The types of antennas not included in this list that have a gain of any type listed are strictly prohibited for use with this device.

Band	Description	MAX Gain (dBi)
WCDMA B2	PIFA Antenna	3.87
WCDMA B4		3.91
WCDMA B5		3.32
LTE B2		3.87
LTE B4		3.91
LTE B5		3.32
LTE B7		3.16
LTE B12		3.19
LTE B13		3.28
LTE B14		3.25
LTE B17		3.19
LTE B25		3.87
LTE B26(824-849)		3.32
LTE B30		0.98
LTE B38		3.07
LTE B41		3.16
LTE B42		2.35
LTE B43		1.94
LTE B48		1.00
LTE B66		3.91
LTE B71		3.07

LCUK54-WWD_Hardware_Design



Documents / Resources



[NETPRISMA LCUK54-WWD Module](#) [pdf] User Manual
2BEY3LCUK54WWDA, lcuk54wwda, LCUK54-WWD Module, LCUK54-WWD, Module

References

- [IPEX Connectors Home | I-PEX](#)
- [IPEX Connectors Home | I-PEX](#)
- [NetPrisma Inc Sales Support | NetPrisma Inc](#)
- [NetPrisma Inc Tech Support | NetPrisma Inc](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.