

NGP 5100 Seal for Mullion Application Installation Guide

Home » NGP » NGP 5100 Seal for Mullion Application Installation Guide





5100 Seal for Mullion Application




Contents

- 1 Installation **Instructions**
- 2 Documents / **Resources**
 - 2.1 References

Installation Instructions

- 1. Clean mullion surface of all dust, dirt, oil, grease, etc.
- 2. Surface temperature of the mullion must be above 50°F for the adhesive on this seal to bond properly.
- 3. Cut the seal to the proper length.

4. Remove protective backing 1 to 2 feet at a time and adhere the seal to the center of the mullion face that the doors close against.



- 5. Firmly press down along the entire length of the seal to bond the adhesive to the mullion. DO NOT remove and relocate. DO NOT stretch the seal when installing.
- 6. Adjust the position of the RIM Exit Device strikes as required for proper latching of the devices.





POSITIVE PRESSURE TESTED GASKETING MATERIALS FOR FIRE DOORS
FOR APPLICATION TO HOLLOW-METAL-TYPE FIRE DOORS
RATED UP TO 3 HOURS AND WOOD-TYPE FIRE DOORS
RATED UP TO 1 1/2 HOURS.
CATEGORY J



Documents / Resources



NGP 5100 Seal for Mullion Application [pdf] Installation Guide 5100 Seal for Mullion Application, 5100, Seal for Mullion Application, Mullion Application, Application

References

- Mational Guard Products
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.