

niceboy ION Office K30 Keyboard User Manual

Home » niceboy ion » niceboy ION Office K30 Keyboard User Manual



Contents

- 1 niceboy ION Office K30 Keyboard
- **2 PACKAGE CONTENTS**
- **3 INSTALLATION**
- **4 PAIRING (BLUETOOTH**

INTERFACE)

- **5 MULTIMEDIA SHORTCUTS (FN)**
- **6 TECHNICAL SPECIFICATIONS**
- **7 FURTHER INFORMATION**
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts



niceboy ION Office K30 Keyboard



PACKAGE CONTENTS

- Niceboy IG0
- Manual
- USB dongle

INSTALLATION

Just connect the keyboard to your computer using the 2.4 gHz USB dongle, case via Bluetooth interface. In case the keyboard is not recognized, please check if the USB driver is up to date on your computer (please check with your PC/laptop manufacturer to make sure it is up to date).

PAIRING (BLUETOOTH INTERFACE)

- 1. Slide the power switch to (ON Bluetooth part rear side), the blue indicator will light up, long press the ,, 1" key (3 seconds). The Bluetooth keyboard will start pairing, during this process the indicator will flash at a frequency of approx. 0.25 seconds.
- 2. Switch on the device and select the settings icon on the device. Click on this icon to display a list of system preferences.
- 3. Click on the Bluetooth icon to search for nearby devices
- 4. Please find the "Niceboy IGO" device in the Bluetooth device list. Click on this name to connect the keyboard to the device.
- 5. Your keyboard is ready for use.
- 6. By long pressing ,, 2" for 3 seconds, the keyboard will start preparing to pair with the device. The red indicator will fiash at a frequency of 0.25 seconds.
- 7. Long press ,, 3" for 3 seconds to prepare the keypad for pairing with the device. The red indicator will flash at a frequency of 0.25 seconds.
- 8. Please follow steps 2-4 to pair other devices via Bluetooth interface.

PAIRING (2.4 GH INTERFACE):

Press the "2.4G" button, switch to 2.4G mode, then long press the "2.4G" button for 3 seconds to make the keyboard enter the pairing state. The blue light will flash for a few seconds and then go out to indicate successful code assignment.

MULTIMEDIA SHORTCUTS (FN)

Key	iOS	Fn + iOS	Android	Fn + Android	Windows	Fn + Windows
A	Home	Esc	Home	Esc	Browser	Esc
.	Reduction of brightness	F1	Reduction of brightness	F1	Reduction of brightness	F1
*	Increasing of brightness	F2	Increasing of brightness	F2	Increasing of brightness	F2
	Select all	F3	Select all	F3	Select all	F3
	Сору	F4	Сору	F4	Сору	F4
(+	Paste	F5	Paste	F5	Paste	F5
*	Clipping	F6	Clipping	F6	Clipping	F6
I	Previous	F7	Previous	F7	Previous	F7
▶II	Play/pause	F8	Play/pause	F8	Play/pause	F8
▶ ▶I	Next	F9	Next	F9	Next	F9
•	Mute	F10	Mute	F10	Mute	F10
4 -	Wolume down	F11	Wolume down	F11	Wolume down	F11
	Wolume up	F12	Wolume up	F12	Wolume up	F12
	Lock screen	Del	Lock screen	Del	Lock screen	Del

TECHNICAL SPECIFICATIONS

• Voltage: 3.7 V, 180 mAh

• DC input voltage: 5.0V/ 100 mA

• Keypad size: 427 x 122 x (6.8-12) mm

Number of keys: 110
Switch: chocolate
Battery life: 80 hours
Bluetooth range: ~10 m

• Compatible operating systems: iOS, Android, Windows

• Connectivity: 2.4GHz, BTS.0, USB C

Multimedia buttons: Yes
Bluetooth version: 5.1
Standby current: ~1 mA
Sleep current: ~S0uA

• Sleep time (Bluetooth mode): 20 minutes

- Sleep time (2.4G mode): 20 minutes
- Wake-up method: wake up the keyboard by pressing any button

FURTHER INFORMATION

- This package contains small parts that may be hazardous to children. Therefore, keep the product out of their reach.
- Do not use the keyboard in places where the temperature is too low or high (0 °C or less/ 45 °C or more) or the humidity is too high (20% or less/ 90% or more).
- Do not store the keyboard in places where the temperature is too low or high (-20 °C or more/ 60 °C or more) or the humidity is too high (90% or more).
- Protect the product from rain, moisture and liquids and do not attempt to disassemble it.
- This product complies with all essential requirements of the EU directives.
- Protect the equipment from sharp objects and falls from height.
- Battery improper handling (long charging time, short circuit, breaking against another object, etc.) may cause fire, overheating or battery discharge.
- Improper handling (long charging time, short-circuit, breakage by another object, etc.) can cause, for example, fire, overheating or battery discharge.
- The standard warranty period for the battery or batteries is 24 months. However, the warranty does not cover a drop in capacity caused by normal use. The standard battery life is six months, but can be extended by proper handling and care of the battery or accumulator.
- The battery or accumulator that may be included in the product is covered by the six-month lifetime as it is a consumable.
- In the case of radio equipment that intentionally transmits radio waves, the instructions and safety information shall include information on all frequency bands in which the radio equipment operates and the maximum radio frequency power emitted in the frequency band in which the radio equipment operates.
- This product complies with all the essential requirements of the EU Directives.

The manual can be downloaded electronically at www.niceboy.eu in the support section. Niceboy s.r.o. hereby declares that the Niceboy K30 radio type is in Directive 2014/53/EU, 2014/30/EU and 2011/65/EU. Declaration of Conformity is available on this website: https://niceboy.eu/cs/declaration/office-k30 INFORMATION FOR USERS ON THE DISPOSAL OF ELECTRICAL AND ELECTRONIC EQUIPMENT (HOUSEHOLDS)

The symbol on the product or in the accompanying documentation means that used electrical or electronic products must not be disposed of with municipal waste. In order to dispose of the product correctly, please take it to the designated collection points where it will be accepted free of charge. Proper disposal of this product will help conserve valuable natural resources and help prevent potential negative environmental and human health impacts that could result from improper waste disposal. For further details, contact your local authority or nearest collection point. Fines may be imposed for improper disposal of this type of waste in accordance with national regulations.

Information for users on the disposal of electrical and electronic equipment (corporate and business use). For proper disposal of electrical and electronic equipment for business and enterprise use, please consult the

manufacturer or importer of this product. The latter will provide you with information on how to dispose of the product and, depending on the date of marketing of the electrical equipment, will tell you who is obliged to finance the disposal of this electrical equipment. Information on disposal in other countries outside the European Union. The above symbol is only valid in European Union countries. For proper disposal of electrical and electronic equipment, please ask your authorities or equipment dealer for detailed information.

MANUFACTURER:

NICEBOY s.r.o., 5. kvetna 1746/22, Nusle, 140 00, Prague 4, Czech Republic, ID: 29416 876. Made in China.



Documents / Resources

niceboy ION Office K30 Keyboard [pdf] User Manual 3227767, 3227773, Office K30 Keyboard, Office K30, K30 Keyboard, Office K9board, Keyboard, K30

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.