



NIGHTHAWK LAX20 4 Stream LTE WiFi Router User Guide

[Home](#) » [NIGHTHAWK](#) » NIGHTHAWK LAX20 4 Stream LTE WiFi Router User Guide 

NIGHTHAWK®

Contents

- [1 NIGHTHAWK LAX20 4 Stream LTE WiFi Router](#)
- [2 Quick Start](#)
- [3 Contents](#)
- [4 Overview](#)
- [5 Regulatory and Legal](#)
- [6 Federal Communication Commission Interference Statement](#)
- [7 Industry Canada statement:](#)
- [8 Radiation Exposure Statement:](#)
- [9 Documents / Resources](#)
- [10 Related Posts](#)

NIGHTHAWK LAX20 4 Stream LTE WiFi Router




Quick Start



1. Download

On your mobile phone, download the Nighthawk app, available on Google Play and the Apple App Store, or go to nighthawk-app.com.



2. Install



Open the Nighthawk app and follow the step-by-step instructions to set up your router.



3. Explore


Check out everything you can do on the Nighthawk app! Run a speed test, pause the Internet, see all the connected devices, and more.

Contents




1. Router
2. Antenna x 2
3. Ethernet Cable
4. Power Adapter (varies by region)

Overview



1. Power LED
2. Internet LED
3. 2.4 GHz WiFi LED
4. 5 GHz WiFi LED
5. Ethernet Ports 1–4 LEDs
6. USB 2.0 LED



- A :WiFi On/Off Button with LED
B: WPS Button with LED
C :Nano SIM Slot
D :USB 2.0 Port
E: ethernet Ports 1–4
F :WAN Port
G: Power Connector
H :Power On/Off Button
I :Reset Button

Support and Community

Visit netgear.com/support to get your questions answered and access the latest downloads.

You can also check out our NETGEAR Community for helpful advice at community.netgear.com.

Regulatory and Legal

- (If this product is sold in Canada, you can access this document in Canadian French at <http://downloadcenter.netgear.com/other/>.)
- For regulatory compliance information including the EU Declaration of Conformity, visit <https://www.netgear.com/about/regulatory/>.
- See the regulatory compliance document before connecting the power supply.
- For NETGEAR's Privacy Policy, visit <https://www.netgear.com/about/privacy-policy>.
- By using this device, you are agreeing to NETGEAR's Terms and Conditions at <https://www.netgear.com/about/terms-and-conditions>. If you do not agree, return the device to your place of purchase within your return period.
- © NETGEAR, Inc., NETGEAR and the NETGEAR Logo are trademarks of NETGEAR, Inc. Any non-NETGEAR trademarks are used for reference purposes only.

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

For operation within 5.15 ~ 5.25GHz / 5.47 ~ 5.725GHz frequency range, it is restricted to the indoor environment.

This device meets all the other requirements specified in Part 15E, Section 15.407 of the FCC Rules.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 26cm between the radiator & your body.

Industry Canada statement:

This device complies with RSS-247 of the ISED's license-exempt RSS. Operation is subject to the industry Canada Rules. Operation is subject to the following two conditions

1. This device may not cause harmful interference, and) This device may not cause
2. this device must accept any interference received, including interference THAT MAY CAUSE UNDESIRE
OPERATION


Caution :

- (i) the device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;
- (ii) the maximum antenna gain permitted for devices in the bands 5250-5350 MHz and 5470-5725 MHz shall be such that the equipment still complies with the e.i.r.p. limit;
- (iii) the maximum antenna gain permitted for devices in the band 5725-5850 MHz shall be such that the equipment still complies with the e.i.r.p. limits specified for point-to-point and non-point-to-point operation as appropriate; and
- (iv) the worst-case tilt angle(s) necessary to remain compliant with the e.i.r.p. elevation mask requirement set forth in Section 6.2.2(3) shall be clearly indicated.
- (v) Users should also be advised that high-power radars are allocated as primary users (i.e. priority users) of the bands 5250-5350 MHz and 5650-5850 MHz and that these radars could cause interference and/or damage to LE-LAN devices.

Radiation Exposure Statement:

This equipment complies with ISSED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Documents / Resources

	NIGHTHAWK LAX20 4 Stream LTE WiFi Router [pdf] User Guide 20100482, PY320100482, LAX20, 4 Stream LTE WiFi Router
---	---