

Ningyuanda K10 Network Camera



Ningyuanda K10 Network Camera User Manual

[Home](#) » [Ningyuanda](#) » Ningyuanda K10 Network Camera User Manual 

Contents

- 1 [Ningyuanda K10 Network Camera](#)
- 2 [Specifications](#)
- 3 [FAQs](#)
- 4 [Network Camera User Manual](#)
- 5 [Device function explanation](#)
- 6 [Add device](#)
- 7 [AP mode](#)
- 8 [Matters needing attention](#)
- 9 [FCC Warning Statement](#)
- 10 [Documents / Resources](#)
 - 10.1 [References](#)
- 11 [Related Posts](#)

Ningyuanda

Ningyuanda K10 Network Camera



Specifications

- Model: V720APP V720
- Network Camera User Manual

FAQs

Q: How can I reset the device?

A: Long press the Reset button to reset the device.

Q: How do I connect to WiFi?

A: Select or enter the WiFi account and password you want to use.

Network Camera User Manual

Thank you for purchasing this product. Please read this manual carefully before using it and keep it in a safe place.

Client downloading

Please scan the lower (right) QR code, download and install the “v720” app, or search for “V720” in the mobile

phone application store to download and install.



Device function explanation



Add device

1. According to the following diagram, insert the device into the power supply and the blue indicator light will flash slowly. Long press the Reset button to reset the device and the blue indicator light will flash quickly.



2. Open the "V720" app, wait for the discovery of a new device pop-up window, and click to bind the device. (If there is no new device pop-up window, please click the "+" in the upper right corner of the homepage to add a device)

NEW Device



AP

Bind Device

3. Select or enter the WiFi account you want to use and fill in the password

Please select the WIFI used by the device

The device does not currently support WIFI in the 5G band

Please enter your WIFI account [connect](#)

Please enter your WIFI password 

4. Wait for the device to be bound successfully.

Installation guide



Add complete

AP mode


1. According to the following diagram, insert the device into the power supply and the blue indicator light will flash slowly. Long press the Reset.



2. The mobile phone turns on the WIFI and connects to the WIFI hotspot starting with “NAX_”.



3. Return to the “v720” app and refresh the dropdown list, when the device displays that means the short-range mode connection is successful.



Matters needing attention

- 1. The applicable working temperature of this product is -10°C~50°C. Please do not use this product in an environment where the temperature is too high or too low.
- 2. This product is a precision electronic product. Please do not use this product in an environment that is

excessively wet or may cause water to

- To better use this product please avoid the front and side of the lens close to the glass, white wall, and other reflective objects, in order to avoid the picture being bright near and dark in the distance or whitish.
- Please ensure that this product is installed within the range of Wi-Fi signal coverage, and placed as far as possible in a location with a better Wi-Fi signal, and try to install it far away from the microwave oven or other locations that may affect the signal.


FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation. RF Exposure StatementTo maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body. This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter.

Documents / Resources

	Ningyuanda K10 Network Camera [pdf] User Manual K10, K10 Network Camera, Network Camera, Camera
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.