



Ninm Lab Real Tape Bluetooth Transmitter User Manual

[Home](#) » [NINM Lab](#) » Ninm Lab Real Tape Bluetooth Transmitter User Manual 

Contents

- [1 Ninm Lab Real Tape Bluetooth Transmitter](#)
- [2 Specification](#)
- [3 User Manual Real tape bluetooth transmitter](#)
- [4 Bluetooth Mode Operation:](#)
- [5 FCC Radiation Exposure Statement](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

Ninm Lab

Ninm Lab Real Tape Bluetooth Transmitter




Specification

Frequency Response Range: 2402-2480MHz

- Transmission distance: 10M
- Playtime:13 hours
- Charging Voltage: 5V/1A
- Charging Time: 3 hours

User Manual Real tape bluetooth transmitter



How to operate:

1. Press and hold the button to power on/off.
2. The blue/red indicator flashes quickly while the product searching for Bluetooth that could be paired.
3. Turn on the Bluetooth in your device settings and select "BW Cassette" to pair.
4. Insert the product into the cassette player and press PLAY
5. Select music on your device and enjoy the music.

Bluetooth Mode Operation:

- Blue and red light flashing means it's in pairing mode
- Blue light is constantly on when there is a call coming.
- Blue light flashes slowly when it playing music.

How to accept/ reject/ end a call

- Accepting a call – Press the "on/off button.
- Rejecting a call Press and hold the "on/off button.
- Ending a call – Press the "on/off button.
- If there is an enclosed cassette slot in your car, please don't use this
- cassette to operate the phone calls.

Charging Mode:

- Red light is constantly on when product is charging.
- Product is fully charged, then the red light automatically switches of.
- When the power is low, red / blue light flashes quickly.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful inteference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.


Waning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Documents / Resources

	<p>Ninm Lab Real Tape Bluetooth Transmitter [pdf] User Manual REALTAPE, 2A9E5-REALTAPE, 2A9E5REALTAPE, Real Tape Bluetooth Transmitter, Real Tape Transmitter, Bluetooth Transmitter, Transmitter</p>
---	---