



NITHO MLT-ADOB ADONIS Bluetooth Wireless Controller User Guide

[Home](#) » [NiTHO](#) » NITHO MLT-ADOB ADONIS Bluetooth Wireless Controller User Guide 

NiTHO

ADONIS

WIRELESS CONTROLLER



Model: MLT-ADOB
QUICK START GUIDE

Contents

1 SPECIFICATIONS

2 FEATURES

3 FUNCTION

4 Documents / Resources

4.1 References

SPECIFICATIONS

THANK YOU FOR BUYING NITHO **ADONIS**.

WE WOULD LIKE TO INTRODUCE ITS SPECIFICATIONS:

- A. Full compatibility with PS3®, PS4®, PC, iOS® and Android®
- B. It's equipped with the latest motion sensing technology
- C. The built-in three-axis gyroscope and three-axis accelerator can detect an omnidirectional dynamic information including Roll, Pitch and Yaw
- D. It's also featured with a dual-point capacitive sensing touchpad
- E. 3.5mm headset jack enables the audio chat
- F. The frontal lightbar indicates the different players and connection, glowing or lighting in different colours
- G. High performance analog triggers



FEATURES

1. Buttons List:

N (Home), Share, Option, ↑, ↓, ←, →, ×, ○, △, L1, L2, L3, R1, R2, R3, VRL, VRR, RESET.

2. Supports : any version of PS4® and PS3® Console, Android® above v6.0, iOS above v13.3 and Windows 10/11

3. **ADONIS** keeps connected up to 10 meter`s distance from the console

4. It`s equipped with a 6-axis sensor catching the controller`s movements


5. RGB LED lightbar

6. It supports the dual-point capacitive sensing touchpad

7. Equipped with 3.5mm stereo headset jack that enables the in-game chat

FUNCTION

• PS4® CONTROLLER`S FUNCTIONS



• SIX-AXIS DETAILS

X-AXIS acceleration directions: left→right, right→left

Y-AXIS acceleration directions: front→back, back→front

Z-AXIS acceleration directions: up→down, down→up

• SENSOR CALIBRATION

– Sensor calibration is automatic

• SLEEP MODE

– **ADONIS** switches to Sleep mode if it fails to connect with PS4®, PS3®, PC, iOS® and Android® or if it doesn't receive any input for 30 minutes

• WIRELESS CONNECTION

1. Connect the USB data cable to **ADONIS** and to the console

2. Press & Hold the “N” button, then the LED bar will light in single color

Note:

– To establish the connection between **ADONIS** and the console, it is required a USB to Micro-B data cable

– After the first pairing, the data cable is no longer needed for any further pairing

- **WIRELESS PC, IOS® AND ANDROID® CONNECTION**


1. Activate the search mode on the Bluetooth® options on your device
2. Press & Hold the “N” button + “SHARE” , for few seconds untill the LED front bar starts to quickly blink
3. Press on your device “ Pair” to successfully connect the controller

- **ADONIS TEST MODE ON PC**

Follow the below instructions for the testing keys in Windows® 10


Connect **ADONIS** to your computer through the Micro-B data cable, then follow the route:

PC → Start → Control Panel→ Device and Printer



Then:

Double click on “Wireless Controller”→ Properties



- **BUTTONS LAYOUT PS4®-PS3®-PC CORRESPONDENCE**

PS4®/ PS3®	PC
□	1
×	2
L1	3
O	4
△	5
R1	6
L2	7
R2	8
SHARE	9
OPTION	10
L3	11
R3	12
PS	13
T-PAD	14



SERVICE & SUPPORT

For any question and support request, contact us on
support@nitho.com or visit our website www.nitho.com
 NITHO GmbH – Victoriastrasse 3b – 86150 Augsburg – Germany



SUPPORT@NITHO.COM



WWW.NITHO.COM



NITHOGAMES



NITHOGAMES



[NITHO MLT-ADOB ADONIS Bluetooth Wireless Controller](#) [pdf] User Guide
MLT-ADOB ADONIS Bluetooth Wireless Controller, MLT-ADOB, ADONIS Bluetooth Wireless C
ontroller, Bluetooth Wireless Controller, Wireless Controller, Controller

References

- [N NITHO - Play Hard - Video Games Accessories](#)
- [User Manual](#)