



NiTHO MLT-ADOB-CMO WIRELESS CONTROLLER User Guide

[Home](#) » [NiTHO](#) » NiTHO MLT-ADOB-CMO WIRELESS CONTROLLER User Guide 

Contents

- [1 NiTHO MLT-ADOB-CMO WIRELESS CONTROLLER User Guide](#)
- [2 SPECIFICATIONS](#)
- [3 FEATURES](#)
- [4 FUNCTION](#)
- [5 SIX-AXIS DETAILS](#)
- [6 SENSOR CALIBRATION](#)
- [7 SLEEP MODE](#)
- [8 · LIGHTBAR INDICATION](#)
- [9 · WIRELESS CONNECTION](#)
- [10 Note:](#)
- [11 ADONIS TEST MODE ON PC](#)
- [12 Then:](#)
- [13 BUTTONS LAYOUT PS4®-PC CORRESPONDENCE](#)
- [14 Read More About This Manual & Download PDF:](#)
- [15 Documents / Resources](#)
- [16 Related Posts](#)

NiTHO MLT-ADOB-CMO WIRELESS CONTROLLER User Guide



SPECIFICATIONS

THANK YOU FOR BUYING NITHO adonis. WE WOULD LIKE TO INTRODUCE ITS SPECIFICATIONS:

- A Full compatibility with PS4® console
- B It's equipped with the latest motion sensing technology
- C The built-in three-axis gyroscope and three-axis accelerator can detect an omnidirectional dynamic information including Roll, Pitch and Yaw
- D It's also featured with a dual-point capacitive sensing touchpad
- E 3.5mm headset jack enables the audio chat
- F The frontal lightbar indicates the different players and connection, glowing or lighting in different colours
- G High performance analog triggers



FEATURES

1. Buttons List:


N (Home), Share, Option, ↑, ↓, ←, →, ×, ○, △, L1,

L2, L3, R1, R2, R3, VRL, VRR, RESET

2. Supports any version of PS4® Console
3. adonis keeps connected up to 10 meter`s distance from the consol
4. It`s equipped with a 6-axis sensor catching the controller`s movements
5. RGB LED lightba
6. It supports the dual-point capacitive sensing touchpad
7. Equipped with 3.5mm stereo headset jack that enables the in-game chat

FUNCTION

- PS4® CONTROLLER`S FUNCTIONS



SIX-AXIS DETAILS

X-AXIS acceleration directions: eft→right, right→left

Y-AXIS acceleration directions: front→back, back→front

Z-AXIS acceleration directions: up→down, down→up

SENSOR CALIBRATION

– Sensor calibration is automatic

SLEEP MODE

– adonis switches to Sleep mode if it fails to connect with PS4® console or if it doesn't receive any input for 30 minutes

· LIGHTBAR INDICATION

- Charging mode (in use): Blue Light
- Charging mode (in stand-by): Orange Light
- Charging mode (not in use): Breathing Light

- Stand-by: Orange light
- Fully charged: Light off
- User`s connection mode:
 Player 1: Blue light Player 2: Red light Player 3: Green light
 Player 4: Pink light – Lost connection mode: White light

· WIRELESS CONNECTION

1. Connect the USB data cable to adonis and to the console
2. Press & Hold the “N” button, then the LED bar will light in single color

Note:

- To establish the connection between adonis and the console, it is required a USB to Micro-B data cable
- After the first pairing, the data cable is no longer needed for any further pairing

ADONIS TEST MODE ON PC

Follow the below instructions for the testing keys in Windows® 10


Connect adonis to your computer through the Micro-B data cable, then follow the route:

PC → Start → Control Panel→ Device and Printer



Then:

Double click on “Wireless Controller”→ Properties



BUTTONS LAYOUT PS4®-PC CORRESPONDENCE

PS4®	PC
□	1
×	2
○	3
△	4
L1	5
R1	6
L2	7
R2	8
SHARE	9
OPTION	10
L3	11
R3	12
PS	13
T-PAD	14

Read More About This Manual & Download PDF:

Documents / Resources



[NITHO MLT-ADOB-CMO WIRELESS CONTROLLER](#) [pdf] User Guide
MLT-ADOB-CMO WIRELESS CONTROLLER, WIRELESS CONTROLLER, CONTROLLER