



noise wrb-sw-colorfitpulse-std-blk_blk ColorFit Pulse Smartwatch User Guide

[Home](#) » [Noise](#) » noise wrb-sw-colorfitpulse-std-blk_blk ColorFit Pulse Smartwatch User Guide 

Contents

- 1 noise -wrb-sw-colorfitpulse-std-blk_blk -ColorFit -Pulse- Smartwatch
- 2 What's in the box
- 3 Table of Content
- 4 Setup
- 5 Pair the Watch
- 6 Watch Features
- 7 Setting
- 8 QR CODE
- 9 Find Phone
- 10 Quick Settings
- 11 Device Information and Tips
- 12 Tips
- 13 Safety Instructions
- 14 Customer Support
- 15 Documents / Resources
- 16 Related Posts

noise

noise -wrb-sw-colorfitpulse-std-blk_blk -ColorFit -Pulse- Smartwatch



What's in the box



Charging cable x 1



ColorFit Pulse Smartwatch x 1




Table of Content

Get Started

- What's in the box
- Watch overview
- Charge the Watch
- Turn the Watch On and Off
- Watch Navigation:

- Screen Navigation
- Button

Set-Up

- App setup
- Pair the Watch
- General Device Information and Tips
- Regulatory Information
- Disposal and Recycling Information
- Maintenance Instructions
- Safety Instructions
- Customer Support


Charging the ColorFit Pulse Smart Watch

Before using your ColorFit Pulse for the first time, charge the battery to its full capacity. Use the charging cable provided with the watch to charge. On a full charge, ColorFit Pulse can last up to 10 days.

Note: The battery life and time to fully charge ur device may vary as per usage and other y factors.

To charge ColorFit Pulse

Plug the USB cable into a power adaptor. Plug the power adaptor into an electrical socket. (Power adaptor not included) Place the magnetic charger on the magnetic charging points of the watch. While your watch is charging, the screen will show the time, day, battery percentage and charging progress. Once the battery is fully charged, remove it from the charging dock

**Power On**


Press and hold the side button for a few seconds to turn on watch.

Power Off

Long press the side button. Select power off and confirm.

Waking Up the Watch

To preserve battery, the watch screen turns off when not in use. To turn the screen back on, you can wake up the watch by: Pressing the side button Turning on the wrist sense



Watch Navigation

The ColorFit Pulse Smart Watch has a TFT Colour touch screen. Navigate the watch by tapping on the screen, swiping side to side, up and down, pressing the side button.


Home Screen Navigation

The home screen is the watch face. From the home screen:

- Swipe right to access quick setting.
- Swipe left to go to main menu.
- Swipe up to check your records.
- Swipe down to check your message notifications.

Button Navigation

- Press the side button to turn on the watch display.



Setup

Before pairing, make sure that your smartphone and smartwatch are next to each other. The app will ask for personal information such as height, weight and sex to calculate your stride length, distance covered, calorie burn rate and metabolic rate. When you set up your account, your name and profile picture will be visible to other users.

- Turn on Bluetooth and the location on your mobile device.
- In your smartphone, download the NoiseFit app from the Play Store or the App Store and install it.
- Create an account or log in using an existing account.

Note: Ensure that your smartphone is running on Android 4.4+ or iOS 10+ and is connected to mobile data or a Wi-Fi network.



Pair the Watch

- Open the NoiseFit app and allow the
- Bluetooth and GPS positioning to be turned on.
- Feed-in your personal information and health goals in the app.
- Go to Add Device page in the app, select the device type and link the watch.



Watch Features

Sports Mode


You can browse through the sports mode and choose the sports of your choice to track your progress.

Sleep

You can view your most recent sleep record and a display of your sleep quality in various sleep stages in the watch and the NoiseFit app. The feature will record the user's sleep states (light sleep, deep sleep and REM cycles) awake time, wake time and sleep time.

Records

You can view your most recent sports modes records on the watch, including detailed data like steps, distance, calories and duration. You can also view the exercise records in the app.





BT Music

You can control your favorite songs and podcasts that play from your phone, right on your wrist as long as the watch is connected with the NoiseFit app in your phone. You can play/pause music, go to next/previous track and increase/decrease volume.

Blood oxygen

ColorFit Pulse supports viewing of the highest and lowest values of Blood Oxygen level of the day and the measurement data throughout the day. To measure your blood oxygen level real-time, go to the Blood Oxygen monitor and let it measure. Note: Make sure your arms and wrists are still and there is no space between your watch and the wrist.



Alarm


You can set alarms in the NoiseFit app and they'll sync with the watch. You can add up to 5 alarms.

Stopwatch

A stopwatch can be set on the watch. You can also set lap times in the stopwatch.

Weather

ColorFit Pulse supports three-day weather viewing of your location. You can turn on the weather viewing feature and let the app identify your location. You can view today's current weather and for the next two days. Open the Weather app on your watch see the weather of your current location.



Setting

Dial

You can switch between different watch faces in the watch, choose and download cloud-based or create your own watch faces in the NoiseFit app.

Raise to wrist awake



Turn on the feature to turn on the watch screen every time you lift the watch to your eye level.

QR CODE

Scan the QR code with your smartphone to download the NoiseFit app from Play or App store

System Settings

- Reboot
- Reset
- Power off
- About
- Know about your smartwatch from this feature.



Find Phone


You can make your phone ring using the watch when the watch is connected to the app. Click the icon to stop the ringing.

Quick Settings

You can swipe from the watch's home screen to gain Quick Settings access.

- Heart rate
- Brightness
- DND
- Find phone

Give your screen a personalized style by changing or customizing the watch face from the NoiseFit app or the watch. n the Watch Touch and hold the home screen. Swipe and choose from the watch faces. In the App Go to watch faces, select the watch face of your choice and tap save to change the watch face.



Device Information and Tips

Device Information

The colorful Pulse Watch contains the following:

- TFT display
- Blood oxygen monitor
- Stress monitor
- 5ATM waterproof
- 8 sports modes
- 9 mm straps

The colorful Pulse smartwatch stores your activity data for up to 10 days in between the time you sync your watch to the NoiseFit app. Activity data includes your steps, distance, calories, active minutes, heart rate, sleep duration and workout data. We recommend syncing the watch to the App daily.

Tips

How do I update my ColorFit Pulse?

You can update your ColorFit Pulse via the NoiseFit app. Go to My Profile and select Check for updates.

How do I find my watch's current firmware version??

You can find the watch's current firmware on the watch. Go to Settings on the NoiseFit app. Select Device information, choose to Check for updates, and update if any update is available. How do I save battery? Follow these simple steps to save ColorFit Pulse battery. Minimize the screen brightness and Limit the notification you receive from the NoiseFit app.

How does the watch estimate how many calories have been burned?

ColorFit Pulse estimates how many calories you've burned based on the physical data you entered when you set up your account.

How do I change my activity goals?

You can do it through the NoiseFit app. Go to My Profile. Go to Setup and select My Objectives. Change your goals and confirm.

How do I log my weight?

You can log in your weight the first time you setup your NoiseFit app. However, you can update the weight later via NoiseFit app. Go to My Profile, select Personal Information and change or update your weight. You can update birthday, height, country and email id as well.

Disposal and Recycling Information

Electrical and electronic devices may not be disposed of with domestic waste. Consumers are obliged by law to return the electrical and electronic devices at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. By recycling, reusing the materials or other forms of utilizing old devices, you are making an important contribution to protecting our environment.

Safety Instructions


- Do not disassemble the battery on your own.
- Do not expose ColorFit Pulse to extremely high or low temperatures.

- The excessive temperature during charging could cause heat, smoke, fire or deformation of the battery or even explosion.
- Charge the battery in a cool, ventilated room.
- Do not open, crush, bend, deform, puncture or shred secondary cells or batteries. In the event of a battery break or leak, prevent battery liquid contact with skin or eyes. If this happens, immediately flush the areas with water (DO NOT RUB THE EYE) or seek medical help.
- Keep the batteries out of children's reach and in a safe place to prevent danger.
- Do not place the batteries in the water.
- Do not short-circuit. Short-circuiting may damage the battery. Short-circuiting can occur when a metallic object, such as coins, causes the direct connection of positive and negative terminals of the battery.
- Do not use your product in a sauna or steam room.
- Do not dispose of batteries in the fire as that may cause an explosion. Dispose of used batteries in accordance with your local regulations. Do not dispose it as household waste.
- Use only the charging cable supplied to charge the battery. Do not charge for more than 24 hours.
- Do not attempt to repair or maintain the watch yourself, service and maintenance should be performed by authorised technicians only. Any device failure should be referred to our after-sales service personnel.
- To prevent device damage, accessory damage and device failure, always protect the device against strong impact or shock.

Customer Support

If you experience any problems with the watch, it may be fixed by restarting your watch. Please get in touch with our Customer Care Team at +91 88-82-132-132 or just drop an email at support@nexxbase.com For more information, visit us online at www.gonoise.com

Documents / Resources

	noise wrb-sw-colorfitpulse-std-blk_blk ColorFit Pulse Smartwatch [pdf] User Guide wrb-sw-colorfitpulse-std-blk_blk, ColorFit Pulse Smartwatch, wrb-sw-colorfitpulse-std-blk_blk ColorFit Pulse Smartwatch
---	---