



NOISEAWARE NA3N301 Indoor Noise Sensor User Guide

[Home](#) » [NOISEAWARE](#) » NOISEAWARE NA3N301 Indoor Noise Sensor User Guide 



NOISEAWARE

NOISEAWARE INSTALLATION AND MONITORING GUIDE

Contents

- [1 Get started](#)
- [2 We are here to help](#)
- [3 Indoor Noise Sensor installation](#)
- [4 Outdoor Noise Sensor installation](#)
- [5 NoiseAware Sensor specifications](#)
- [6 Sensor installation information](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)

Get started

1. Download the NoiseAware app from app.noiseaware.io. or from the Apple Store® or Google Play store.

 	
https://apps.apple.com/us/app/noiseaware/id1436213179?ls=1	https://play.google.com/store/a

2. Set up an Indoor Noise Sensor first, following the instructions in the app.
3. Install any additional Indoor or Outdoor Noise Sensors in the app.

We are here to help



help.noiseaware.io




(888) 787-8750



support@noiseaware.

Indoor Noise Sensor installation


You will need



Flathead screwdriver



Active WiFi connection



NoiseAware app and login




Log into the app and follow the on-screen steps to set up your NoiseAware Indoor Sensor.

WARNING: Risk of Electric Shock. Mount only to outlets that can be switched off by a circuit breaker. Use caution and disconnect power before installation or removal. Local regulations in Canada prohibit securing this device to an outlet with a screw.

WARNING: When removing outlet cover screw, cover may fall across plug pins or outlet may become displaced. Use only with duplex outlets with a compatible screw and secure the sensor in place with the included screw whenever possible.

Outdoor Noise Sensor installation



Phillips® screwdriver



Online Indoor Noise Sensor



NoiseAware app and login



Log into the app and follow the on-screen steps to set up your NoiseAware Outdoor Sensor.

WARNING: Indoor Noise Sensors must be installed before Outdoor Noise Sensors! If there isn't an Indoor Sensor online at the property, install one before proceeding with Outdoor Sensor setup.

WARNING: If the Outdoor Noise Sensor is not automatically detected during setup, it can be set up manually by entering the sensor's MAC address. The MAC address is printed on a label by the batteries as well as a separate label in the box.. Manual setup may take longer if the sensors have not yet

successfully established a connection.

NoiseAware Sensor specifications

Generation: 3.1 Generation (Gen3.1)

Model: NA3N301 (Indoor) / NA3N302 (Outdoor)

US Patent: # 9,959,737

Detailed product specifications are available at www.noiseaware.io/product-specifications



<https://noiseaware.io/product-specification>



Class II: This symbol indicates that the device is double insulated and does not rely on a connection to electrical earth (ground).

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC and IC RF (Radio Frequency) exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum separation distance of 20 centimeters between the device/antenna and the user's head/body.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device is not intended for use by children or by persons with reduced physical or mental capabilities unless supervised by a party responsible for their safety. Children should be supervised around the devices and should never play with them.

Copyright © NoiseAware, Inc. All rights reserved. NoiseAware is a registered trademark of: NoiseAware Inc., Inc. 3106 Commerce St #100, Dallas, TX 75226.


Sensor installation information

Date of Installation:
Name of Property and Zone:
WiFi Network and Password:
Noise Thresholds:
Users Receiving Noise Alerts:
Comments:

Our mission is to prevent noise pollution with innovative technology and remarkable customer service.
Thank you for being a valuable NoiseAware customer.



Documents / Resources

	NOISEAWARE NA3N301 Indoor Noise Sensor [pdf] User Guide NA3N301, 2AQIP-NA3N301, 2AQIPNA3N301, NA3N302, NA3N301 Indoor Noise Sensor, NA3N301, Indoor Noise Sensor
---	---

References

- [🌐 NoiseAware Mobile App](#)
- [🕒 NoiseAware – Rest Easy](#)
- [🌐 NoiseAware – Rest Easy](#)

