



numskull 2022-V5 Multi Format Steering Wheel Instruction Manual

[Home](#) » [numskull](#) » numskull 2022-V5 Multi Format Steering Wheel Instruction Manual 

Contents

- 1 numskull 2022-V5 Multi Format Steering Wheel Instruction Manual
- 2 195mm×135mm
- 3 Before the first use
- 4 Features
- 5 Default buttons configuration
- 6 Installation Set up the wheel on PS4
- 7 Set up the wheel on XBOX SERIES X/S & XBOX ONE
- 8 Set up the wheel on PC
- 9 Set up the wheel on SWITCH
- 10 Programming procedures
- 11 Sensitivity adjustment
- 12 Precautions of uses
- 13 IMPORTANT NOTICE:
- 14 Contact and Customer Support
- 15 Respect the environment
- 16 Read More About This Manual & Download PDF:
- 17 Documents / Resources
 - 17.1 References


numskull 2022-V5 Multi Format Steering Wheel Instruction Manual



195mm×135mm



TABLE

Type	PS4	XBOX SERIES X/S XBOX ONE/PC DC-Input)	SWITCH	PC (Direct Input)
12 3 4	 <u>Q</u> A	XA B Y	BA Y X	12 3 4
Actions	R1 11 R2 L2 R3 L3	RBLB RT LT Right stick (click) Left stick (click)	RL ZR ZL Right stick (click) Left stick (click)	65 8 7 12 11
D-Pad	updown left right	updown left right	updown left right	updown left right
Functions	OPTIONS SHARE	MENU VIEW	+ -	109
Steering wheel	Left analog stick	Left analog stick	Left analog stick	X-axis
Left paddle Right paddle	L1 R1	LB RB	ZL ZR	78
Left pedal Right pedal	12 R2	LT RT	B Y	Y-axis -Y axis +
Mode	HOME	XBOX button	HOME	13

Before the first use

Thank you for purchasing the NEXT GEN STEERING WHEEL & PEDALS. Before using the wheel, please read this instruction manual carefully and keep it for future reference.

Features

- This Steering wheel is compatible with XBOX SERIES X/S, PS4, XBOX ONE, PC, and SWITCH
- It is compatible with all the racing games on those platforms
- An official controller is required to use the wheel on XBOX SERIES X/S, PS4, XBOX ONE
- Compatible with all PC games (X-Input and Direct Input)

- 180-degree steering rotation
- Steering sensitivity control (3 positions)
- 6 programmable buttons for tailor-made button configuration for use with different racing games
- Fully analog driving control for a more realistic driving experience
- Spring-loaded acceleration and brake control pedals
- Connection to the console through USB port
- The cable connector design for pedals prevents accidental disconnection of the cable
- Super strong and long-lasting suction cups for stabilizing

Default buttons configuration

The default buttons configuration is preset according to the GRAN TURISMO buttons configuration.

Installation Set up the wheel on PS4

1. Make sure that the PS4 is turned off.
2. Plug the wheel cable into a USB port on the console.
3. Plug the cable from the pedals into the wheel
4. Plug an official PS4 controller into the USB port located on the wheel, and use the provided cable. Important the controller must be switched off. Now turn on the console.
5. The Red LED of the wheel stays lit, Press the HOME button on the wheel to connect it to the console. The wheel is now ready.

Set up the wheel on XBOX SERIES X/S & XBOX ONE

1. Make sure that the XBOX is turned off.
2. Plug the wheel cable into a USB port on the console.
3. Plug the cable from the pedals into the steering wheel.
4. Plug an official XBOX controller into the USB port located on the wheel, and use the provided cable. IMPORTANT: the controller must be switched off.
5. Turn on the console using the power button on the XBOX.
6. The red LED of the wheel stays lit. Press the HOME button on the wheel to connect it to the console.
10. The steering wheel is now ready to use.

Set up the wheel on PC

1. Turn on the PC.
2. Plug the cable from the pedals into the steering wheel
3. Connect the USB cable of the wheel to any of the USB ports of the PC. A Windows utility starts automatically to install the device. At the end of that operation, the LED, n 1 remains on, the wheel is now ready to use.

IMPORTANT: The steering wheel uses the X-Input protocol by default, so it is compatible with the latest games. Some older games use the Direct Input protocol. To switch to Direct Input mode, press and hold the Home/Mode button for 3 seconds, the LED will flash to indicate the change. This mode will then be used by default. You can switch from one mode to another at any time by holding down the Home/-Mode button for 3 seconds.

Set up the wheel on SWITCH

IMPORTANT: Before connection, turn on the console and go to System Settings / Controllers and Sensors / Pro Controller Wired Communication. Check that On is selected.

1. Make sure that the SWITCH is turned off.
2. Plug the wheel cable into a USB port on the console.
3. Plug the cable on the pedals into the steering wheel.
4. Turn on the console.
5. The red LED of the wheel stays lit, and the steering wheel is now ready to use.

Programming procedures

IMPORTANT: The RACING WHEEL is identified as a “game controller” in the commands menu of the games. If you wish to modify the button configuration in the game, go to the “game controller” section, not to the “steering wheel” section.

- You can also use the programming function “on-the-go” on the Steering wheel. It enables you to create the configuration you want without going into the Options menu of the game, but that configuration will not be saved. This wheel has a built-in program function: you can assign a new function to some buttons to make your own driving comfortable and experience. Six Keys can be programmed
- Left pedal
- Right pedal
- Left paddle shifter
- Right paddle shifter
- L3
- R3 Programming procedure
- Press simultaneously the OPTIONS and SHARE buttons for 3 seconds. The LED will be lit in green.
- Then press any of the 6 programmable keys (listed above) to set up a new function. The LED will flash green.
- Finally, press the button that you would like to reassign to the programmable button (O, X, Y, A, L1, R1, L2, R2). The LED turns off, the key is now programmed.
- Repeat the above steps to program other buttons if necessary. Reset one programmed key
- Press simultaneously the OPTIONS and SHARE buttons for 3 seconds. The LED will be lit in green.
- Then press on the programmed key that you would like to reset. The LED will flash green.
- Press again on the same key. The LED turns off, the key is now reset to default. Reset all the programmed keys
- Press simultaneously the OPTIONS and SHARE buttons for 3 seconds. The LED will be lit in green.
- Press again simultaneously on the OPTIONS and SHARE buttons for 4 seconds. The LED turns off, all keys are now reset to default. You can also unplug the wheel for resetting the configuration. You can now play GRAN TURISMO or any other racing games that use the default button configuration. For other games, you have 2 options to make the right button configuration:
- You can either go to the Options/Controllers menu in the game and create your own configuration. The advantage is that you can save it for later gaming sessions.

Sensitivity adjustment

The sensitivity control is designed for a better steering control adapted to the different types of racing game environments, such as Off-Road, Grand Prix racing, etc. To adjust the sensitivity, press OPTIONS & SHARE simultaneously for 3 seconds, and the LED turns lit in green. Then release the keys. Press on SHARE again to reset the current sensitivity. Then, press several times on SHARE to select the expected sensitivity. The LED will flash in green to indicate the different options:

- Medium sensitivity: the LED flashes in green regularly. The steering angle is small, good for quick turns in racing games
- High sensitivity: the LED flashes in green quickly. The steering angle is very small, good for very quick turns, corner turning, etc.
- Low sensitivity: the LED flashes in green slowly. The steering angle is normal, adapted to most the racing games

To validate your choice, press the UP button of the D-PAD (central button of the wheel).

Precautions of uses

- Do not use this product for other purposes than the ones described in this document.
- The wheel should not be used in humid places, splashed, or placed near objects filled with liquids, such as vases. After use, keep the wheel in a dry place.
- Never attempt to disassemble or reconstruct it by yourself.
- Do not apply any excessive pressure to the device.
- Stop using this unit immediately if you begin to feel tired or if you experience discomfort or pain in your hands and/or arms while operating the product. If the condition persists, consult a doctor.
- Take breaks every 30 minutes.
- Place the wheel away from direct sunlight, excessive heat, fire, or extreme cold. Exposure to extreme temperatures may damage the body and the internal circuitry of the device.
- Do not let unattended children play with the wheel. Do not allow children to play with cords. This product contains small parts that may cause choking if swallowed. This product is not intended to be used by children under 3 years of age.

IMPORTANT NOTICE:

- THIS WHEEL DOES NOT SUPPORT HEADSET USE.

Contact and Customer Support

Please feel free to contact Numskull for more information about the Next Gen Gaming Steering Wheel and pedals, or other products in our range of peripherals.

Email: hello@numskull.com

Respect the environment




In order to protect the environment, please do not discard electric/electronic devices and appliances with household garbage. Please take them to a recycling collection center.



Read More About This Manual & Download PDF:

Documents / Resources

 <p>Instructions manual</p>	<p>numskull 2022-V5 Multi Format Steering Wheel [pdf] Instruction Manual 2022-V5, 2022-V4, 2022-V5 Multi Format Steering Wheel, Multi Format Steering Wheel, Format Steering Wheel, Steering Wheel, Wheel</p>
---	---

References

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.