


## NXP MCXE247 FRDM MCX E247 Development Platform



## Contents [ [hide](#) ]



- 1 [Get To Know The Frdm-mcxe247 Development Board](#)
- 2 [How To Get Started](#)
- 3 [Customer Support](#)
- 4 [Documents / Resources](#)
  - 4.1 [References](#)



## Get To Know The Frdm-mcxe247 Development Board

NXP's FRDM Development Platform provides you with cost-effective MCU development boards.

Easy I/O access supports expansion board use for fast prototyping and rapid evaluation. Enjoy your FRDM-MCXE247.

-  Arduino® header
-  FRDM header
-  mikro BUS™
-  Pmod™
-  GPIO group 1 header
-  GPIO group 2 header





## How To Get Started

### Setup



1. Connect the FRDM-MCXE247 board to a PC using the USB Type-C® cable

- 2. The board comes preprogrammed with a blinky LED demo
- 3. **Optional:** prepare two dupon wires for SEC tool usage
- 4. Get started at [nxp.com/FRDM-MCXE247/start](https://nxp.com/FRDM-MCXE247/start)

**Software and expansion boards**

- 5. Access software and tools through [nxp.com/MCUX\\_press](https://nxp.com/MCUX_press)
  - Expansion Board Hub [mcuxpresso.nxp.com/eb-hub](https://mcuxpresso.nxp.com/eb-hub) to find add-on boards from NXP and our partners with related MCUX press SDK-compatible drivers and examples
  - Application Code Hub [mcuxpresso.nxp.com/app\\_code\\_hub](https://mcuxpresso.nxp.com/app_code_hub) to browse application code examples from our experts to help kick start your project.
- 6. Explore our entire FRDM platform of MCUs and MPUs at [nxp.com/FRDM](https://nxp.com/FRDM)

**Customer Support**

Visit [nxp.com/support](https://nxp.com/support)

[nxp.com/FRDM-MCXE247](https://nxp.com/FRDM-MCXE247)

NXP and the NXP logo are trademarks of NXP B.V. All other product or service names are the property of their respective owners. © 2025 NXP B.V.  
Document Number: MCXE247QSG REV 0 APN: 926-10067



**Documents / Resources**

 <p>FRDM MCX E247 Development platform</p>	<p><a href="#">NXP MCXE247 FRDM MCX E247 Development Platform [pdf]</a> User Guide</p> <p>MCXE247, MCXE247 FRDM MCX E247 Development Platform, MCXE247, FRDM MCX E247 Development Platform, MCX E247 Development Platform, E247 Development Platform, Development Platform</p>
---	--

**References**

- [User Manual](#)

■ NXP

🔧 Development Platform, E247 Development Platform, FRDM MCX E247 Development Platform, MCX E247 Development Platform, MCXE247, MCXE247 FRDM MCX E247 Development Platform, NXP

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.

