

OKIN CB3433A Control Box Instructions

Home » OKIN » OKIN CB3433A Control Box Instructions



Contents

- 1 OKIN CB3433A Control Box
- 2 Electrical configuration diagram
- **3 Function Picture**
- 4 Interface function description
 - 4.1 PAIR & RESET button **Function**
- **5 FCC Warning**
- 6 Documents / Resources
- **7 Related Posts**




A Phoenix Mecano Company

OKIN CB3433A Control Box



Electrical configuration diagram



Function Picture



Interface function description

HEAD ACTUATOR

Connect to head actuator, control by a remote single:
Click head-up button on the remote, head actuator moves out, stop when released
Click the head down button the head actuator moves in, stop when released
This function takes effect only by pressing the corresponding button on the remote.

FOOT ACTUATOR

Connect to foot actuator, control by a remote single:

Click foot up button foot actuator moves out stop when released

Click foot down button foot actuator moves in stop when released

This function takes effect only by pressing the corresponding button on the remote.

LUMBAR ACTUATOR

Connect to foot actuator, control by a remote single:

Click Lumber up button foot actuator moves out stop when released

Click Lumber down button foot actuator moves in stop when released

This function takes effect only by pressing the corresponding button on the remote.

HEAD1 VIBRATION & HEAD2 VIBRATION

Connect to head massage, control by remote:

Click head massage + button, head massage strengthens by one level;

Click head massage – button, head massage weaken by one level;

This function takes effect only by pressing the corresponding button on the remote.

FOOT VIBRATION

Connect to Foot massage, control by remote:

Click FOOT massage + button, head massage strengthens by one level;

Click FOOT massage – button, head massage weaken by one level;

This function takes effect only by pressing the corresponding button on the remote.

Power LED & PAIRING LED

Power supply for control box, PAIRING LED of the control box is blue, POWER LED is green

PAIR & RESET button Function

Pair Function

Power supply for control box, Pair LED lights to blue the control box enters into the mode of code paring Press and hold the pairing button of Remote, the backlight of paring LED flashes, the backlight of remote flashes, the remote enters into the mode of code paring;

The backlight of paring LED of remote stops flashing, and the paring led of control box turns off, it indicates that the code paring is successful;

If fails, repeat all the processes above;

SYNC port

Connect with the same other Control box or Other accessories;

under bed light-RGB

Click the button of the under bed light, turns on(or change) the under bed light, switch the status once when clicking once This function takes effect only by pressing the corresponding button on the remote.

USB Power OUT

Connect USB panel

UART1 port & UART2 port

Connect other serial peripherals

Power

Connect to the 29V DC;

FCC Warning

Please take attention that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:


- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

ISED RSS Warning:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- 1. This device may not cause interference, and
- 2. This device must accept any interference, including interference that may cause undesired operation of the device.

Documents / Resources



OKIN CB3433A Control Box [pdf] Instructions CB3433A, 2AVJ8-CB3433A, 2AVJ8CB3433A, CB3433A Control Box, Control Box

Manuals+,