OKIN FP.26.02 Sleep Control Box User Guide

Contents

OKIN FP.26.02 Sleep Control Box

Specifications

- Part Number: FP.26.02
- Working Voltage: 29V
- Working Current: 5mA @29V
- Operation Temperature: -20~55°C
- Storage Temperature: -45~85°C
- RF Frequency Range: 2.402~2.480GHz
- RF Modulation: GFSK
- Housing Material: ABS 765A, 94V-0

Product Usage Instructions

Connecting and Setting Up Bluetooth

1. Connect the Bluetooth plugin first, then power on the main control box.
2. Follow these steps to connect Bluetooth hotspot:

    1. Sign up and sign in using the provided TEST ID and PW.
    2. Switch to Bluetooth on your device and select “SleepBT-xxxxxxxx”, then save.
    3. Select the device, hotpot, and connect it. Connection should succeed.

Note: If you encounter issues operating the bed via the app even after a successful Bluetooth connection, try power cycling the main control box or restarting the app.

Operating the Main Interface

After successfully pairing via Bluetooth, you can operate the main interface to control the box functionalities.

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to specific conditions to prevent interference and ensure proper operation. Follow the guidelines provided in the manual.

ISED Warning

This device complies with the Innovation, Science and Economic Development Canada license-exempt RSS standard(s). Follow operational conditions to prevent interference and maintain proper device functionality.

Appearance

Specification

1. Part Number: FP.26.02;
2. Working Voltage: 29V;
3. Working Current: 5mA @29V;
4. Operation Temperature:-20~55℃;
5. Storage temperature: -45~85℃;
6. RF Frequency Range: 2.402~2.480GHz;
7. RF Modulation: GFSK;
8. Housing Material: ABS 765A, 94V-0;

Interface Description

Status Indication: one color, two different states

Status 1: White light flashing, when Bluetooth broadcast;
Status 2: White light on, when Bluetooth is linked by smartphone;

APP

IOS

Instructions

- Connect the Bluetooth plugin first, then power on the main control box, follow the steps below to connect Bluetooth hotpot.



- Sign up and sign in



TEST ID: 13456397315 PW: a12345678

Switch to Bluetooth, select SleepBT-xxxxxxxx , direct selection save



- Select the device, hotpot, and connect it. Connection succeed.

Note: If you have already connected Bluetooth successfully, but you still cannot operate the bed via this app, then you can try to power off the main control box and repower it, or exit the app then re-enter.
After successful pairing, operate the main interface, you can operate the control box.

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment, this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

ISED WARNING

This device complies with the Innovation, Science and Economic Development Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. this device may not cause interference, and
2. this device must accept any interference, including interference that may cause undesired operation of the device.

FAQ

Q: What should I do if I encounter Bluetooth connectivity issues?
A: If you have trouble connecting via Bluetooth, try power cycling the main control box or restarting the app. Ensure you follow the provided instructions carefully.

Documents / Resources

	OKIN FP.26.02 Sleep Control Box [pdf] User Guide FP2602, 2AVJ8-FP2602, 2AVJ8FP2602, FP.26.02 Sleep Control Box, FP.26.02, FP.26.02 Control Box, Sleep Control Box, Control Box, Box

References

- **User Manual**