


# Olink OLK015C 20W USB-C Power Adapter User Guide

[Home](#) » [Olink](#) » Olink OLK015C 20W USB-C Power Adapter User Guide 

## Olink OLK015C 20W USB-C Power Adapter



## Contents

- [1 Package Content](#)
- [2 Before You Use](#)
- [3 Safety Notes](#)
- [4 Using Your Product](#)
- [5 Warning](#)
- [6 Care and Maintenance](#)
- [7 FCC Statement](#)
- [8 Specifications](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)
- [10 Related Posts](#)

## Package Content

- OLINK C Series-20WPDCharger
- User Guide

## Before You Use

### Thank You for Choosing OLINK Product

Please take your time and read the following instructions and information thoroughly before you operate the product.

## Safety Notes

- The product is intended for indoor use only.
- Use the product for its intended purpose only
- Use the product only in moderate climatic conditions.
- The maximum ambient temperature during the and overheating, use it in dry rooms only.
- Do not use the product in the immediate vicinity of heaters or other heat sources or direct sunlight.
- Do not operate the product outside the power limits given in the specifications.
- Do not drop the product and do not expose it to any major shocks.
- Do not continue to operate the product if it becomes visibly damaged.
- Do not modify the product in any way, doing so voids the warranty.
- The disconnection from line voltage is made by AC plug.
- The product is not intended to be repaired by service personnel in case of failure or component defect (the product can be disposed of).
- Keep this product out of the reach of children!
- The product is intended for indoor use only.
- Use the product for its intended purpose only.
- Use the product only in moderate climatic conditions.
- The maximum ambient temperature during the product's operation must not exceed 25 °c/ 77 °F.
- Protect the product from dirt, moisture, splashes, and overheating, use it in dry rooms only.

- Do not use the product in the immediate vicinity of heaters or other heat sources or direct sunlight.

## Using Your Product

- Connect your terminal device to a USB charging socket using a suitable USB cable.
- Connect the charger to a properly installed and easily accessible power socket.
- The charging process is displayed on your terminal device.
- Pay attention to the terminal device's maximum charging time for the batteries.
- Disconnect the terminal device from the charger if you want to stop charging or if the terminal device is fully charged, then disconnect the charger from the mains.

\*For the full performance of the product and your own safety, please use an OLINK™ cable, your device's original cable, or other certified cable.

## Warning

- Only connect the product to a socket that has been approved for the device. The socket must be installed close to the product and easily accessible.
- When using a multi-socket power strip, make sure that the sum power draw of all the connected devices does not exceed its maximum throughput rating.
- If you will not be using the product for a long period of time, disconnect it from mains power.

## Care and Maintenance

- Disconnect the product from the power supply before cleaning it.
- Only use a dry cloth or a dry brush to clean the product.

## FCC Statement

This device complies with part 75 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received. Including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, Uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the User is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

## Specifications

Product Model: OLK0ISC  
Port Type: Type-C  
Product Size: 42.6mmx41.1mmx28.8mm  
Operating Temperature: 0°C-25°C/32°F -77°F  
Input100-240V~S0/60 Hz 0.8A  
Output: {Type-C) SV ==3A 9V ==2.22A 12V ==1.67 A 20W MAX



## Documents / Resources

 OLINK C Series 20W PD Charger USER GUIDE	<a href="#">Olink OLK015C 20W USB-C Power Adapter</a> [pdf] User Guide OLK015C 20W USB-C Power Adapter, OLK015C, 20W USB-C Power Adapter, USB-C Power Adapter, Power Adapter, Adapter
--	--

## References

- [User Manual](#)