

 OptiSigns
**ARD3 Android Digital
Signage Player**



OptiSigns ARD3 Android Digital Signage Player User Guide

[Home](#) » [OptiSigns](#) » OptiSigns ARD3 Android Digital Signage Player User Guide 

Contents

- [1 OptiSigns ARD3 Android Digital Signage Player](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 OVERVIEW](#)
- [5 Also Included](#)
- [6 Connect cables & power](#)
- [7 SAFETY AND COMPLIANCE INFORMATION](#)
- [8 FCC](#)
- [9 Frequently Asked Questions](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)



OptiSigns ARD3 Android Digital Signage Player



Specifications

- **Model:** OptiSigns Android Digital Signage Player
- **Interfaces:** USB, TF Card, Ethernet, Bluetooth Remote
- **Included Accessories:** Power Cable & Adapter, HDMI Extension Cable

Product Usage Instructions

1. Unboxing and Setup:

- Unbox the OptiSigns Android Digital Signage Player.
- Connect the power cable and adapter to the device and plug it into a power outlet.
- Allow the device some time to fully boot up for the first time.


2. Pairing the Remote:

- Press and hold the specified buttons on the remote for 5 seconds until the light starts blinking.
- Once paired successfully, the light will stop blinking, and a Remote connection success message will display on the screen.
- Note: You can also use the OptiSigns Admin app as a remote control.


3. Connecting to Network & Assigning Contents:

- Press the button on the top right of the remote to configure Wi-Fi.
- If WiFi information was provided during the device order, it will automatically connect to WiFi. If using Ethernet, log in to <https://app.optisigns.com/> to start assigning content.
- For detailed network instructions or content assignment, scan the QR code or visit <https://links.optisigns.com/device-setup>.

OVERVIEW



Also Included



Connect cables & power

Please use the included cables & adapter to minimize issues

- Plug Android Stick into your TV HDMI port, use extention cable if needed.
- Connect the power adpater to the Android Stick and plug the adatper into a power outlet.

INFO: It may take a moment for the device to be fully booted for the first time

Pair your remote


Press and hold i and together for 5 seconds, the light on the remote will start to blink. Once it is paired, the light will stop blinking and "Remote connection success" message will show up on the screen.



Note: You can also download and use the OptiSigns Admin app as a remote control.

Connect Network & Assign contents



Press the  button on the top right of the remote to configure WiFi. If WiFi information was entered when you ordered the device, your device will automatically be connected to WiFi and ready to use. Or if you use an Ethernet connection.

Just log in to <https://app.optisigns.com/> and start assigning content to your device

If you need WiFi, network instructions, or more detail on how to assign content to your device, please scan the QR code on the right Or visit: <https://links.optisigns.com/device-setup>
For a more detailed guide.



SAFETY AND COMPLIANCE INFORMATION

For safety, compliance, recycling, and other important information regarding your OptiSigns Android Digital Signage Player device, please refer to the information at discover.optisigns.com/device-safety-info.

OPTISIGNS TERMS & POLICIES

OptiSigns subscription is required when using the OptiSigns devices, please read all the applicable terms, and policies (collectively, the “Agreements”) available at www.optisigns.com/terms-of-use. By using the device, you agree to be bound by the Agreements. You can find OptiSigns privacy notice at www.optisigns.com/privacy-policy.

FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference,
2. this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by s encouraged to try to correct the interference by one or more of the following measures: turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm from your body.


The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

If you have further questions or need support, please: contact us at support@optisigns.com

Frequently Asked Questions

- **Q: Is an OptiSigns subscription required for using the device?**
 - A: Yes, an OptiSigns subscription is required when using the OptiSigns devices. Ensure to read and agree to the applicable terms and policies available at www.optisigns.com/terms-of-use.
- **Q: How can I get further support for the product?**
 - A: For additional questions or support, please contact us at support@optisigns.com.
- **Q: What should I do if my device does not connect to WiFi automatically?**
 - A: If your device does not connect to WiFi automatically, you can manually configure the network by following the steps provided in the user manual or by visiting <https://links.optisigns.com/device-setup> for detailed instructions.

Documents / Resources



[OptiSigns ARD3 Android Digital Signage Player](#) [pdf] User Guide

ARD3 Android Digital Signage Player, ARD3, Android Digital Signage Player, Digital Signage Player, Signage Player, Player

References

- [🌐 OptiSigns | Device Safety and Compliance Information](#)
- [📄 Privacy Policy | OptiSigns Digital Signage](#)
- [📄 Terms of Use | OptiSigns Digital Signage](#)
- [📄 app.optisigns.com/](#)
- [🌐 OptiSigns Android Digital Signage Player – OptiSigns](#)
- [User Manual](#)

Manuals+. [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.