

Contents [[hide](#)]

- [1 oricom CU430 Additional Camera](#)
- [2 Specifications](#)
- [3 TURN ON THE BABY UNIT \(CAMERA\)](#)
- [4 PAIRING YOUR CAMERA UNIT WITH A PARENT UNIT](#)
- [5 EXPRESS WARRANTY \(AUSTRALIA\)](#)
- [6 FAQs](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)

oricom

oricom CU430 Additional Camera



Specifications

- **Model:** CU430
- **Version:** 1.1
- **Manufacturer:** Oricom International Pty Ltd
- **Warranty:** 2 Years
- **Power Source:** DC Plug
- **Country of Origin:** Australia

KEEP THIS USER GUIDE FOR FUTURE REFERENCE

Always retain your proof of purchase in case of warranty service.

TURN ON THE BABY UNIT (CAMERA)

1. Insert the DC plug of the power adaptor into the DC jack in the rear of the Baby Unit.
2. Insert the other end of the power adaptor into a suitable electrical outlet.
3. Keep the baby unit plugged in to mains power.

WARNING



Strangulation Hazard: Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 1 meter away). Never use extension cords with AC Adaptors. Only use the AC Adaptors provided.

PAIRING YOUR CAMERA UNIT WITH A PARENT UNIT









MENU OPERATION

PAIRING THE CAMERA AND PARENT UNITS

To register a new baby unit, follow the procedure below:

Note: Camera with “” icon means it is registered. You should select and pair with the camera without “”

ADD CAMERA

1. Press the MENU 
2. Press the  key until the camera icon  is selected.
3. press  key. Press  key to select,  then press  key
4. When the icon Vis is displayed on the LCD screen, press the PAIR button on the back of the camera.
5. Once paired, Successful pairing icon  shows on the LCD screen.
6. If fails, repeat the above steps.

EXPRESS WARRANTY (AUSTRALIA)

This Express Warranty is provided by Oricom International Pty Ltd ABN 46 086 116 369, Unit 1, 4 Sovereign Place, South Windsor NSW 2756, herein after referred to as “Oricom”. Oricom warrants that the product is free from defects in materials or workmanship during the Express Warranty Period. This Express Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia. The benefits of this Express Warranty are in addition to other rights and remedies you may have under the Australian Consumer Law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. In the event of a minor failure, Oricom reserves the right to choose to repair or replace the product. The Express Warranty Period will be a period of 2 Years beginning on the date of purchase of the product evidenced by your dated sales receipt. You are required to provide proof of purchase as a condition of receiving Express Warranty services. You are entitled to a replacement product or repair of the product at our discretion according to the terms and conditions of this document if your product is found to be faulty within the Express Warranty Period. This Express Warranty extends to the original purchaser only and is not transferable.

Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or

equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Express Warranty Period of the

Oricom branded product in which they are installed, whichever is longer. During the Express Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Express Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may always, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance. No change to the conditions of this Express Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom. Oricom will not be liable under this Express Warranty, and to the extent permitted by law will not be liable for any defect, loss, damage or injury arising out of or in connection with a:

1. Failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;
2. Wilful misconduct or deliberate misuse by you of the product;
3. Any external cause beyond our control, including but not limited to power failure, lightning or overvoltage; or
4. Modification to the product or services carried out on the product by anyone other than Oricom or Oricom's authorised service provider.

How to make a claim under your Express Warranty in Australia

Oricom has a simple warranty process for you to follow:

- Please call or email our Customer Support Team, (02) 4574 8888 or support@oricom.com.au.
- A Customer Support Team member will verify after troubleshooting with you if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.
- We will then email or fax a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the goods for warranty service.

Please note that if a Customer Support Team member advises that your product does

not qualify for return, this warranty does not apply to your product. Products that are authorised to be returned to Oricom in Australia must include all of the following:

- A completed Return Authorisation form
- A copy of your Proof of Purchase (please keep your original copy)
- The faulty product, including all accessories.

Send the approved returns to:

- Oricom International Pty Ltd Locked Bag 658
- South Windsor NSW 2756 Australia

Please note that this Express Warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.

Important Information

Repair Notice

Please be aware that the repair of your goods may result in the loss of any user generated data (such as stored telephone numbers, text messages and contact information). Please ensure that you have made a copy of any data saved on your goods before sending for repair. Please also be aware that goods presented for repair may be replaced by refurbished goods or parts of the same type rather than being repaired.

Warning



Strangulation Hazard: Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3 ft (0.9 m) away). Do not remove this tag.

FAQs


What should I do if my camera unit fails to pair with the parent unit?

If pairing fails, try repeating the pairing process by following the steps outlined in the user manual. Ensure both units are within range and that there is no interference.

How do I claim warranty service for my product?



To claim warranty service, retain your proof of purchase and contact Oricom International Pty Ltd at the provided address. The Express Warranty Period is 2 years from the date of purchase, and you may be entitled to a replacement or repair based on the terms and conditions outlined in the warranty document.

Documents / Resources

	oricom CU430 Additional Camera [pdf] User Guide CU430, CU430 Additional Camera, CU430, Additional Camera, Camera
---	---

References

- [User Manual](#)

 Additional Camera, camera, CU430, CU430 Additional Camera,
 oricom oricom

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.