

**/// PARKSIDE®**  
PAML 2000 A1 3 in 1  
Accu LED Lamp



# PARKSIDE PAML 2000 A1 3 in 1 Accu LED Lamp Instruction Manual

[Home](#) » [PARKSIDE](#) » PARKSIDE PAML 2000 A1 3 in 1 Accu LED Lamp Instruction Manual 

## Contents

- 1 [PARKSIDE PAML 2000 A1 3 in 1 Accu LED Lamp](#)
- 2 [Product Information](#)
- 3 [Product Usage Instructions](#)
- 4 [FAQ](#)
- 5 [List of pictograms used](#)
- 6 [Introduction](#)
- 7 [Safety instructions](#)
- 8 [Before use](#)
- 9 [Use](#)
- 10 [Maintenance and cleaning](#)
- 11 [Disposal](#)
- 12 [Warranty](#)
- 13 [Service](#)
- 14 [Documents / Resources](#)
  - 14.1 [References](#)
- 15 [Related Posts](#)

**/// PARKSIDE®**

**PARKSIDE PAML 2000 A1 3 in 1 Accu LED Lamp**



## Product Information

### Specifications

- Akku Multifunktionsleuchte 3-IN-1
- Cordless Multi-Function Light 3-IN-1
- Lampe Multifonction Rechargeable 3 EN 1
- **Model:** PAML 2000 A1 (IAN 461494\_2307)
- **LED Power:** Inspektionsleuchte – 2.1W, Taschenlampe – 2.6W, Werkstattleuchte – 3W
- **Battery:** Lithium-Ion Battery (LIR18650) 1ICR19/67

### Product Usage Instructions

#### Safety Instructions

Before using the product, please read the safety instructions provided in the manual carefully.

#### Charging the Product

To charge the product, use the provided USB cable to connect to a power source. The Ladestatusanzeige will indicate the charging status.

#### Using the Product

There are three main functions of the product:

1. **Inspektionsleuchte (Inspection Light):** Use the EIN-/AUS-Taste to turn on/off. The handle provides a firm grip for inspection purposes.

2. **Werkstattleuchte (Workshop Light):** Connect the Stecker to activate the light. Adjust the Gelenk for desired illumination.
3. **Taschenlampe (Flashlight):** Press the Stecker to operate the flashlight. The Typ-C-USB-Anschlussbuchse allows for easy charging.

### Maintenance and Cleaning

Regular maintenance and cleaning of the product will ensure optimal performance. Use a soft, damp cloth to clean the surfaces. Avoid using harsh chemicals.

### Disposal

When disposing of the product, follow local regulations for electronic waste disposal to protect the environment.

### FAQ






- **How do I know when the product is fully charged?**

The Ladestatusanzeige will indicate when the product is fully charged. It is recommended to disconnect the charger once fully charged to avoid overcharging.

- **Can I replace the battery in this product?**

The product comes with a Lithium-Ion Battery (LIR18650) which is replaceable. Please refer to the manual for instructions on replacing the battery.

### List of pictograms used

	Direct current/ voltage		USB-connection
	Class III product		CE mark indicates conformity with relevant EU directives applicable for this product.
	Safety information Instructions for use		

### Introduction


We congratulate you on the purchase of your new product. You have chosen a high quality product. The instructions for use are part of the product. They contain important information concerning safety, use and disposal. Before using the product, please familiarise yourself with all of the safety information and instructions for use. Only use the product as described and for the specified applications. If you pass the product on to anyone else, please ensure that you also pass on all the documentation with it.

### Intended use

This product is only suitable for private use in dry indoor locations, e.g. in storage room or corridor. The product is not intended for commercial use or for use in other applications. For indoor use only! This luminaire is intended for normal operations.

This product is not suitable for household room illumination.

## Description of parts (Fig. A and B)



1. Magnetic foot
2. ON/OFF button
3. Charging indicator
4. Accessory socket
5. Handle
6. Type-C USB input socket (with protective cap)
7. Accessory plug (Inspection light)
8. Inspection light
9. Accessory plug (Workshop light)
10. Joint
11. Workshop light

12. Accessory plug (Flashlight)
13. Flashlight
14. USB cable

## Technical data

- **LED power:**
    - **Inspection light:** 2.1 W
    - **Flashlight:** 2.6 W
    - **Workshop light:** 3 W
  - **Rechargeable battery:** lithium ion rechargeable battery (LIR18650), 1ICR19/67 3.7 V, 2000 mAh (not interchangeable)
  - **Charging time:** 4 to 5 hours
  - **Light duration (with fully loaded rechargeable battery):** At full power: approx. 2 hr (flashlight) / 2 hr (workshop light)/3 hr (inspection light)
  - **Protection class:** III/
  - **Degree of protection:** IP20
  - **Type-C-USB input voltage/current:** 5 V , 1 A
- Note:** Use only SELV power supply of maximum working output voltage 5 V (Uout) 1A
- Note:** An AC power adapter is not included. Use a SELV power supply of maximum working output voltage 5 V (Uout), 1 A.

## Scope of delivery

- 1 Inspection light
- 1 Flashlight
- 1 Workshop light
- 1 Handle
- 1 USB cable
- 1 Set of instructions

## Safety instructions

BEFORE USING THE PRODUCT, PLEASE FAMILIARISE YOURSELF WITH ALL OF THE SAFETY INFORMATION AND INSTRUCTIONS FOR USE! WHEN PASSING THIS PRODUCT ON TO OTHERS, PLEASE ALSO INCLUDE ALL THE DOCUMENTS!

- **WARNING** DANGER TO LIFE AND RISK OF ACCIDENTS FOR INFANTS AND CHILDREN! Never leave children unsupervised with the packaging material. Always keep children away from the packaging material.
- This product may be used by children aged 8 years and up, as well as by persons with reduced physical, sensory or mental capacities, or those lacking experience and/or knowledge provided they are supervised or instructed in the safe use of the product and they understand the associated risks. Do not allow children to play with the product. Cleaning and user maintenance must not be performed by children without supervision.
- This product is not a toy and should be kept out of the reach of children. Children are not aware of the dangers associated with handling electrical products.

- Do not use the product if you detect any type of damage.
- Protect the product from moisture and humidity. Never immerse the product in water or other liquids!
- When connecting the product to a power supply, make sure that the respective voltage corresponds to the information in the chapter "Technical data".
- Do not carry out any modifications or repairs to the product yourself. The LEDs cannot and must not be replaced.
- The LEDs are not replaceable.
- If the LEDs fail at the end of their lives, the entire product must be replaced.
- Dispose of the product when the product and the USB cable 14 are damaged.
- Ensure the USB cable 14 cannot become damaged by sharp edges or hot objects. Unwind the USB cable 14 completely before use. Protect the product from extreme heat and cold.
- Battery not replaceable.
- Please be aware that while the adapters are plugged in, they use a small amount of power, even when the product is not switched on. To take the adapters out of operation, unplug from the socket. Mains adapter is not included.
- The USB cable 14 provided is only suitable for use with the product. Do not look directly into the light of the product and do not direct the product into other people's eyes. This can impair the eyesight. This product may emit dangerous optical radiation. Do not look directly into the light of the product. This may be harmful to your eyes.

#### **Safety instructions for batteries/rechargeable batteries**

- DANGER TO LIFE! Keep batteries/rechargeable batteries out of reach of children. If accidentally swallowed seek immediate medical attention.
- Swallowing may lead to burns, perforation of soft tissue, and death. Severe burns can occur within 2 hours of ingestion.
- DANGER OF EXPLOSION! Never recharge non-rechargeable batteries. Do not short-circuit batteries/rechargeable batteries and/or open them. Overheating, fire or bursting can be the result.
- Never throw batteries/rechargeable batteries into fire or water.
- Do not exert mechanical loads to batteries/rechargeable batteries.

#### **Risk of leakage of batteries/rechargeable batteries**

- Avoid extreme environmental conditions and temperatures, which could affect batteries/rechargeable batteries, e.g. radiators/direct sunlight.
- If batteries/rechargeable batteries have leaked, avoid contact with skin, eyes and mucous membranes with the chemicals! Flush immediately the affected areas with fresh water and seek medical attention!
- WEAR PROTECTIVE GLOVES! Leaked or damaged batteries/rechargeable batteries can cause burns on contact with the skin. Wear suitable protective gloves at all times if such an event occurs.
- This product has a built-in rechargeable battery which cannot be replaced by the user. The removal or replacement of the rechargeable battery may only be carried out by the manufacturer or his customer service or by a similarly qualified person in order to avoid hazards. When disposing of the product, it should be noted that this product contains a rechargeable battery.

## Before use

### Charging the product

- **Note:** Remove all packaging materials from the product.
  - **Note:** The product must be connected to an AC adapter or to a computer. The technical data of these devices (not included in the scope of delivery) must be observed.
  - **Note:** In order to use the product without a USB cable 14 , you need to recharge the rechargeable battery before use. The charging process takes about 4 to 5 hours. The rechargeable battery is firmly integrated into the product.
  - **Note:** Charge the product for approx. 12 hours prior to first use.
    - Open the protective cap and connect the USB cable 14 with a computer or with the USB connector of a power adapter.
    - Connect the type-C-USB connector on the USB cable 14 to the type-C-USB input socket 6 on the product.
    - Plug the power adapter into a socket.
  - **Note:** The battery charging status is shown by the charging indicator 3 :
    - 1 LED lights up = 25 %\*
    - 2 LEDs light up = 50 %\*
    - 3 LEDs light up = 75 %\*
    - 4 LEDs light up = 100 %\*

\* This is the approximate percentage of battery capacity but not actual measurement.
  - The charging time is approximately 4–5 hours when the battery was drained.
  - Disconnect the USB cable 14 from the product to prevent the batteries discharging themselves.
  - Close the protective cap before you start to use the product again.
  - The product is not working at temperatures below 0 °C and above +45 °C due to its battery protection.
- Note: Fully charged the battery before storage. If you want to store the product for longer than 3 months, fully charged the battery every 3 months.


## Use

**Note:** Fully charge the product as described in chapter “Charging the product”.



- Attach the inspection light 8 /flashlight 13 /workshop light 11 to the handle 5 of the product as shown in figure C/figure F.
  - Press the ON/OFF button 2 to switch on the light.
  - You can attach the product to a flat, ferromagnetic surface using the magnetic foot 1 (see fig. D).
- Note:** Be aware of the weight of the product.
- You can operate the product in 3 different modes. Select them by repeatedly pressing the ON/OFF button 2 .


ON/OFF button/modes:	
1x press	100 % luminosity
2x press	50 % luminosity
3x press	SOS
4x press	switch off light

**CAUTION!** Do not pull the inspection light 8 /workshop light 11 / flash light 13 directly out of the accessory socket 5 on the handle 4 , as this may damage them. Instead, turn the corresponding light out of the accessory socket 4 and then pull it off the handle 5 (see fig. E)









## Maintenance and cleaning

The product requires no maintenance. The LEDs cannot be replaced.

- Switch off the product and the USB charging cable must be disconnected from the power adapter (external) or from the computer (external) or from the “charging device”.
- Close the protective cap on the type-C-USB input socket 6 . Never immerse the product in water or other liquids.
- Never use caustic cleaners.
- Regularly clean the product with a dry, lint-free cloth.
- Use a slightly moist cloth to remove any stubborn dirt.

## Disposal

The packaging is made entirely of recyclable materials, which you may dispose of at local recycling facilities.

- Observe the marking of the packaging materials for waste separation, which are marked with abbreviations (a) and numbers (b) with following meaning: 1–7: plastics/20–22: paper and fibreboard/80–98: composite materials.
- Contact your local refuse disposal authority for more details of how to dispose of your worn-out product.
- To help protect the environment, please dispose of the product properly when it has reached the end of its useful life and not in the household waste. Information on collection points and their opening hours can be obtained from your local authority.
- The product incl. accessories and packaging materials are recyclable and are subject to extended producer responsibility. Dispose them separately, following the illustrated Info-tri (sorting information), for better waste treatment. The Triman logo is valid in France only.
- Faulty or used batteries/rechargeable batteries must be recycled in accordance with Directive 2006/66/EC and its amendments. Please return the batteries/ rechargeable batteries and/or the product to the available collection points.

### **Environmental damage through incorrect disposal of the batteries/rechargeable batteries!**

Batteries/rechargeable batteries may not be disposed of with the usual domestic waste. They may contain toxic heavy metals and are subject to hazardous waste treatment rules and regulations. The chemical symbols for heavy metals are as follows: Cd = cadmium, Hg = mercury, Pb = lead. That is why you should dispose of used batteries/rechargeable batteries at a local collection point.

### **Warranty**

- The product has been manufactured to strict quality guidelines and meticulously examined before delivery. In the event of material or manufacturing defects you have legal rights against the retailer of this product. Your legal rights are not limited in any way by our warranty detailed below.
- The warranty for this product is 3 years from the date of purchase. The warranty period begins on the date of purchase. Keep the original sales receipt in a safe location as this document is required as proof of purchase.
- Any damage or defects already present at the time of purchase must be reported without delay after unpacking the product.
- Should the product show any fault in materials or manufacture within
- 3 years from the date of purchase, we will repair or replace it – at our choice – free of charge to you. The warranty period is not extended as a result of a claim being granted. This also applies to replaced and repaired parts.
- This warranty becomes void if the product has been damaged, or used or maintained improperly.
- The warranty covers material or manufacturing defects. This warranty does not cover product parts subject to normal wear and tear, thus considered consumables (e.g. tubes, cartridges), nor damage to fragile parts, e.g. switches or glass parts.
- For this product, the rechargeable battery is also covered by its warranty period.

### **Warranty claim procedure**


- To ensure quick processing of your case, please observe the following instructions:

- Please have the till receipt and the item number (IAN 461494\_2307) available as proof of purchase.
- You will find the item number on the rating plate, an engraving on the front page of the instructions for use (bottom left), or as a sticker on the rear or bottom of the product.
- If functional or other defects occur, please contact the service department listed either by telephone or by e-mail.
- You can return a defective product to us free of charge to the service address that will be provided to you. Ensure that you enclose the proof of purchase (till receipt) and information about what the defect is and when it occurred.

## Service

- **Service Great Britain**
  - **Tel.:** 08000569216
  - **E-Mail:** [owim@lidl.co.uk](mailto:owim@lidl.co.uk)
- **Service Ireland**
  - **Tel.:** 1800 200736
  - **E-Mail:** [owim@lidl.ie](mailto:owim@lidl.ie)

## Documents / Resources

	<p><b><a href="#">PARKSIDE PAML 2000 A1 3 in 1 Accu LED Lamp</a> [pdf] Instruction Manual</b></p> <p>PAML 2000 A1, IAN 461494_2307, PAML 2000 A1 3 in 1 Accu LED Lamp, PAML 2000 A1, 3 in 1 Accu LED Lamp, Accu LED Lamp, LED Lamp, Lamp</p>
---	--

## References

- [User Manual](#)

### [Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.