



## PAX A910 Smart Mobile Payment Terminal User Manual

[Home](#) » [Pax](#) » PAX A910 Smart Mobile Payment Terminal User Manual 

### PAX A910 Smart Mobile Payment Terminal User Manual



## **Contents**


- [1 Checklist](#)
- [2 Product Description](#)
- [3 Installation](#)
- [4 Instructions](#)
- [5 General Usage Tips](#)
- [6 Important Safety Warning](#)
- [7 Working mode Tips](#)
- [8 Environmental Parameters](#)
- [9 Icons](#)
- [10 FCC Regulations](#)
- [11 FCC RF Exposure Information \(SAR\)](#)
- [12 Quick Setup Guide](#)
- [13 Documents / Resources](#)
  - [13.1 References](#)

## **Checklist**


Congratulations on receiving your PAX Technology payment terminal. We do hope you enjoy it! The box you have just opened should contain the following items:

- 1 x PAX A910S Smart Mobile Payment Terminal
- 1 x Thermal Paper Roll
- 1 x AC Power Adapter
- 1 x Battery
- 1 x Cable

## **Product Description**



## Installation



**USB Port:** connect to a USB-enabled device.

**SAM/SIM/microSD Cards:**

- Open the battery cover underneath the terminal.
- Remove the battery.
- Insert SAM/SIM/microSD cards into the corresponding card slots.

**Instructions**

- **Power On/Off:** Power On: press and hold the Power button for 5 seconds until the IC card slot LED illuminates, showing that the terminal is being turned on.  
**Power Off:** press and hold the Power button for 3 seconds until the shutdown menu appears, tap Power Off > Click Power Off, and “Shutting Down” will appear.
- **Contactless Transactions:** Tap a contactless enabled card or smartphone in proximity to the top end of the terminal where the contactless sensor is located, indicated by the contactless icon.
- **Chip Card Transactions:** With the card’s chip facing upwards, insert the chip card fully into the hybrid chip & magnetic card slot.
- **Magnetic Stripe Transactions:** With the card’s magnetic stripe facing downwards, swipe the card through the hybrid chip & magnetic reader at a constant speed, in either direction.
- **Paper Receipts:** Tear off the receipt at a 45-degree angle to the paper cutter.
- **Battery Charging:** With a charging cable connected, the device’s charging status shows on the display

## General Usage Tips

- 1 Avoid putting the terminal in direct sunlight, high temperature, moist, or dusty environment.
- 2 Forbid non-professional to repair the terminal.
- 3 Before insert the card, please check internal and around of IC card slot. when you found some suspicious objects , must report to related administrator.
- 4 a door or cover intended only for occasional use by the ordinary person, such as for the installation of accessories, may be removable if an instructional safeguard is provided for correct removal and reinstallation of the door or cover.

## Important Safety Warning

- Do not place the terminal or battery in direct sunlight, nor in environments with excessively high temperatures, smoke, dust, or dampness.
- Do not attempt to disassemble the battery, nor insert or use foreign objects to penetrate the casing. Never place the battery in a fire or excessively hot surfaces. Take care not to drop the battery. Excessive external shocks or pressure could cause battery liquid leakage or result in the battery catching fire or even exploding. Keep the battery well away from children and animals.
- Immediately replace any battery which appears to be deformed, expanded or in an overheated state.
- We recommend you only use power adaptors supplied by PAX Technology. If you must use 3rd party supplier accessories, please ensure specifications meet exactly those recommended for our products, which must comply with international and local. regulations & standards. Non-compatible power supplies, chargers or batteries could cause fires or even explosions, and will invalidate any product warranty.
- Charge the battery when the indicator level is low, but make sure to never charge a battery continuously for more than 24 hours. If a battery is not used for a long time, please charge it at least once every 6 months to avoid overcharge or discharge damage. For long-term optimal product performance, it is recommended that a battery be replaced after 2 years of continual usage.
- When disposing of the device, battery, or accessories, please do so responsibly and according to local regulations. These are not household waste items. Improper disposal of the battery could cause a fire or explosion, and any liquid leakage could be damaging to the environment and toxic to humans & animals.

## Working mode Tips

A910S has BMS(Battery management system) function to protect the lithium battery from being over-charged, so A910S can work either on Desktop mode or Mobile Mode (Select “Settings” > “Battery” > “More Settings” > “Power Supply Work Mode”).

### Desktop Mode

The terminal is mainly powered by external power supply, which includes charging base, power adapter and wireless charging

### Mobile Mode

The terminal is mainly powered by battery, and generally no external power is inserted.

We specify different charging and discharging parameters for the two working modes, as detailed below.

	Full charge	Recharging
Mobile Mode	100%	90%
Desktop Mode	80%	70%

## Environmental Parameters

- **Working Environment Temperature:-10°C 45°C(14°F 113°F)** (non-charging)
- **Storage Environment: Temperature:-20°C 70°C(-4°F 158°F)** (non-charging)
- **Humidity 5% 95%** (non-condensing)

## Icons

### Trademark notice:

“microSD logo is a trademark of SD-3C LLC.”

## FCC Regulations

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

## FCC RF Exposure Information (SAR)

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States.

During SAR testing, this device is set to transmit at its highest certified power level in all tested frequency bands, and placed in positions that simulate RF exposure in usage near the body. Although the SAR is determined at the highest certified power level, the actual SAR level of the while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. The exposure standard for wireless employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg.

For this device, the highest reported SAR value for usage near the body is 1.302 W/kg under the test separation distance: 5 mm.

While there may be differences between the SAR levels of various devices and at various positions, they all meet

the government requirement.

The FCC has granted an Equipment Authorization for this model device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model device is on file with the FCC and can be found under the Display Grant section of [www.fcc.gov/oet/ea/fccid](http://www.fcc.gov/oet/ea/fccid) after searching on FCC ID: V5PA910S

For body worn operation, this device has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and be positioned a minimum of 10mm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory, position the handset a minimum of 10mm from your body when the device is switched on.

## Quick Setup Guide

PAX reserves the right to change product specifications & material components at any time Scan here for latest version.



PAX continually invests to maintain its high quality products up to date with the latest certifications, therefore a comprehensive list can be requested via the website's contact form or on downloadable product brochures.

**Built by:** PAX Computer Technology (Shenzhen) Co. Ltd.

**Address:** 4/F, No.3 Building, Software Park, Second Central Science-Tech Road, High-Tech Industrial Park, Shenzhen, Guangdong, China.

**Tel:** +86 755 86169630

**Website:** [www.pax.com.cn](http://www.pax.com.cn)


## FCC Supplier's Declaration of Conformity

**Smart Mobile Payment Terminal / A910S** This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Responsible Party:** PAX Technology, Inc. 8880 Freedom Crossing Trail, Building 400, 3rd Floor Suite 300, Jacksonville, Florida, 32256

**Help-desk** 1 877-859-0099



  <small>Installation Manual A910 Smart Mobile Payment Terminal</small>  <small>PAX TECHNOLOGIES LIMITED</small>	<a href="#">PAX A910 Smart Mobile Payment Terminal</a> [pdf] User Manual A910 Smart Mobile Payment Terminal, A910, Smart Mobile Payment Terminal, Mobile Payment Terminal, Payment Terminal
---	--

## References

- [PAX Technology | Global Website | Payment Terminals](#)
- [PAX Technology | Global Website | Payment Terminals](#)
- [User Manual](#)

### Manuals+, [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.