

PCE Instruments PCE428 Outdoor Condition Monitoring Sound Level Meter User Manual

Home » PCE Instruments » PCE Instruments PCE428 Outdoor Condition Monitoring Sound Level Meter User Manual

Contents

- 1 PCE Instruments PCE428 Outdoor Condition Monitoring Sound Level
- 2 Safety notes
- 3 Introduction
- **4 Delivery contents**
- **5 Specifications**
- 6 Device description
- 7 Installing the measuring system
- 8 Recharging the batteries
- 9 Warranty
- 10 Disposal
- 11 PCE Instruments' contact information
- 12 Documents / Resources
 - 12.1 References
- 13 Related Posts



PCE Instruments PCE428 Outdoor Condition Monitoring Sound Level Meter



Safety notes

Please read this manual carefully and completely before you use the device for the first time. The device may only be used by qualified personnel and repaired by PCE Instruments personnel. Damage or injuries caused by non-observance of the manual are excluded from our liability and not covered by our warranty.

- The device must only be used as described in this instruction manual. If used otherwise, this can cause dangerous situations for the user and damage to the meter.
- The instrument may only be used if the environmental conditions (temperature, relative humidity, ...) are within the ranges stated in the technical specifications. Do not expose the device to extreme temperatures, direct sunlight, extreme humidity, or moisture.
- Do not expose the device to shocks or strong vibrations.
- The case should only be opened by qualified PCE Instruments personnel.
- · Never use the instrument when your hands are wet.
- You must not make any technical changes to the device.
- The appliance should only be cleaned with a damp cloth. Use only pH-neutral cleaner, no abrasives or solvents.
- The device must only be used with accessories from PCE Instruments or equivalent.
- Before each use, inspect the case for visible damage. If any damage is visible, do not use the device.
- Do not use the instrument in explosive atmospheres.
- The measurement range as stated in the specifications must not be exceeded under any circumstances.
- Non-observance of the safety notes can cause damage to the device and injuries to the user.
- Remove the batteries when the meter is not used for more than 60 days.
- Turn off the meter when not in use.

We do not assume liability for printing errors or any other mistakes in this manual. We expressly point to our general guarantee terms which can be found in our general terms of business. If you have any questions please contact PCE Instruments. The contact details can be found at the end of this manual.

Introduction

The kit for outdoor noise measurement PCE-4xx-EKIT is combinable with the noise meters PCE-428, 430, and PCE-432. This outdoor kit makes it possible to measure outdoor noise with an SPL level meter over a longer period of time. The environmental noise monitoring system comes in a waterproof Peli carrying case with rollers. A charger and two additional lead gel batteries are installed in this case, which allows operation for up to 10 days. During the outdoor noise measurement, the case can remain closed. Due to the external connections for the microphone and the power supply, all electronic components are protected from water.


Delivery contents

- 1 x Outdoor Sound Monitor Kit PCE-4xx-EKIT
- 1 x Waterproof PELI transport case
- 1 x Wind and rain protection for a microphone of the PCE-4xx series
- 1 x Charger for internal batteries
- 2 x 12 V lead gel batteries
- 1 x Tripod
- 1 x 2 m / 6ft 6" microphone cable
- 1 x Connection cable for power supply 110 V / 230 V (optional Schuko or US connection)

Specifications

Carrying case	PELI 1510 with rollers with grid foam
Protection	IP65
Connections on the suitcase	Microphone: TNC 12 V charging voltage: XLR 110 V / 230 V charging voltage: PowerCon TRU
Charger	Victron Blue Smart 12 V / 4 A IP65
Internal batteries	2 x 12 V / 12 Ah lead gel
Battery running time	min. 10 days
Power supply	With charger EU Version: 180 265 V AC With charger US Version: 100 130 V AC Battery operation: 2 x 12 V / 12 Ah
Cable length	Microphone cable: 2 m / 6 ft 6" with TNC connector Power supply: 2 m / 6 ft 6" with PowerCon TRU
Dimensions	56 x 35 x 23 cm / 2.2 x 1.3 x 0.9"
Weight	about 14 kg / 30 lb 13 oz with batteries about 8 kg / 17 lb 10 oz withou t batteries

Device description



First, unfold the tripod. Then guide the measurement signal cable through the microphone holder. Now connect the microphone to the measurement signal cable and screw the microphone onto its holder. Then screw the microphone holder onto the tripod. Use the measurement signal input to connect the measurement signal cable to the measuring case. Finally, connect the measuring cable and the power supply cable to your sound level meter in the case.

Note:

Always ensure the vertical position of the microphone. Otherwise, damage through weathering may occur.

Recharging the batteries

There are two methods to charge the batteries.

First method

If you wish to charge the batteries with the charger directly installed in the case, connect the charger to the voltage supply and to the battery supply within the case. Connect the included supply cable outside the measuring case.

Second method

When the temperature within the measuring case could possibly exceed 50 °C, it is recommended to use the charging method with the charger outside the case to avoid overheating which can cause the charger to turn off automatically. Connect the charger to the charger port outside the measuring case. Now connect the included supply cable to the charger directly.

The different shapes of the plugs do not allow for incorrect connection of the charger.

Warranty

You can read our warranty terms in our General Business Terms which you can find here: https://www.pce-instruments.com/english/terms.

Disposal

For the disposal of batteries in the EU, the 2006/66/EC directive of the European Parliament applies. Due to the contained pollutants, batteries must not be disposed of as household waste. They must be given to collection points designed for that purpose. In order to comply with the EU directive 2012/19/EU we take our devices back. We either re-use them or give them to a recycling company that disposes of the devices in line with the law. For countries outside the EU, batteries, and devices should be disposed of in accordance with your local waste regulations.

If you have any questions, please contact PCE Instruments.



www.pce-instruments.com.

PCE Instruments' contact information

_	France	
Germany	112.1100	Spain
PCE Deutschland GmbH	PCE Instruments France EURL	PCE Ibérica S.L.
Im Langel 4	23, rue de Strasbourg	Calle Mayor, 53
D-59872 Meschede	67250 Soultz-Sous-Forets	02500 Tobarra (Albacete)
Deutschland	France	España
Tel.: +49 (0) 2903 976 99 0	Téléphone: +33 (0) 972 3537 17	Tel. : +34 967 543 548
Fax: +49 (0) 2903 976 99 29	Numéro de fax: +33 (0) 972 3537 18	Fax: +34 967 543 542
info@pce-instruments.com	info@pce-france.fr	info@pce-iberica.es
www.pce-instruments.com/deutsch	www.pce-instruments.com/french	www.pce-instruments.com/espanol
Germany	United Kingdom	Italy
PCE Produktions- und	PCE Instruments UK Ltd	PCE Italia s.r.l.
Entwicklungsgesellschaft mbH	Unit 11 Southpoint Business Park	Via Pesciatina 878 / B-Interno 6
Im Langel 26	Ensign Way, Southampton	55010 Loc. Gragnano
D-59872 Meschede	Hampshire	Capannori (Lucca)
Deutschland	United Kingdom, SO31 4RF	Italia

Tel.: +49 (0) 2903 976 99 471	Tel: +44 (0) 2380 98703 0	Telefono: +39 0583 975 114
Fax: +49 (0) 2903 976 99 9971	Fax: +44 (0) 2380 98703 9	Fax: +39 0583 974 824
info@pce-instruments.com	info@pce-instruments.co.uk	info@pce-italia.it
www.pce-instruments.com/deu tsch	www.pce-instruments.com/english	www.pce- instruments.com/italiano
The Netherlands	China	Hong Kong
PCE Brookhuis B.V.	PCE (Beijing) Technology Co., Limited	PCE Instruments HK Ltd.
Institutenweg 15	1519 Room, 6 Building	Unit J, 21/F., COS Centre
7521 PH Enschede	Zhong Ang Times Plaza	56 Tsun Yip Street
Nederland	No. 9 Mentougou Road, Tou Gou Distric	Kwun Tong
Telefoon: +31 (0)53 737 01 92	102300 Beijing, China	Kowloon, Hong Kong
info@pcebenelux.nl	Tel: +86 (10) 8893 9660	Tel: +852-301-84912
www.pce-instruments.com/dut	info@pce-instruments.cn www.pce-instruments.cn	jyi@pce-instruments.com www.pce-instruments.cn
United States of America	Turkey	

PCE Americas Inc.

711 Commerce Way Suite 8 Jupit

er / Palm Beach

33458 FL USA

Tel: +1 (561) 320-9162

Fax: +1 (561) 320-9176

info@pce-americas.com www. pce-instruments.com/us PCE Teknik Cihazları Ltd.Şti. Halkalı Me

rkez Mah.

Pehlivan Sok. No.6/C

34303 Küçükçekmece – İstanbul Türkiye

Tel: 0212 471 11 47

Faks: 0212 705 53 93

info@pce-cihazlari.com.tr www.pce-i

nstruments.com/turkish

User manuals can be found by using our product search on: www.pce-instruments.com.



Documents / Resources



PCE Instruments PCE428 Outdoor Condition Monitoring Sound Level Meter [pdf] User Manual

PCE428 Outdoor Condition Monitoring Sound Level Meter, PCE428, Outdoor Condition Monitoring Sound Level Meter, Monitoring Sound Level Meter, Level Meter

References

- S France.fr : Actualités, destinations et infos du tourisme en France
- O iberica.es
- Instruments.cn
- Make an offer on the domain instruments.co.uk Domains.co.uk
- @ Computer Instruments | Home
- T Discover Italy: Official Tourism Website Italia.it
- [@] PCEï¼^北京ï¼%.c§'技æœ%.é™å...¬å
- Industrial Measurement Products and Solutions | PCE Instruments
- © PCE Deutschland GmbH Prüfgeräte vom Hersteller | PCE Instruments
- © PCE Brookhuis B.V. | PCE Instruments

- © PCE Americas Inc. : Test Instruments | PCE Instruments
- © PCE Iberica S.L. Instrumentación | PCE Instruments
- © PCE Italia s.r.l. / Strumenti di Misura | PCE Instruments
- © PCE Teknik Cihazlar Paz. Tic. Ltd.Sti. | PCE Instruments
- © PCE Americas Inc. : Test Instruments | PCE Instruments
- © PCE Deutschland GmbH Prüfgeräte vom Hersteller | PCE Instruments

Manuals+,