



Phonocar SM014 Retrofit Android 13 Screen Installation Guide

[Home](#) » [Phonocar](#) » Phonocar SM014 Retrofit Android 13 Screen Installation Guide 

Contents

- [1 Phonocar SM014 Retrofit Android 13 Screen](#)
- [2 WARNINGS](#)
- [3 DESCRIPTION](#)
- [4 INTENDED USE](#)
- [5 TECHNICAL SPECIFICATIONS](#)
- [6 PACKAGE CONTENTS](#)
- [7 CONNECTIONS](#)
- [8 FIRST START-UP](#)
- [9 SYSTEM CONFIGURATION](#)
- [10 CONTACT](#)
- [11 Frequently Asked Questions](#)
- [12 Documents / Resources](#)
 - [12.1 References](#)



Phonocar SM014 Retrofit Android 13 Screen



WARNINGS

PLEASE READ THIS INSTRUCTION MANUAL CAREFULLY BEFORE INSTALLATION.

1. Phonocar S.p.A. does not accept any responsibility for damage resulting from improper installation or misuse of the product.
2. Installation must be carried out by qualified personnel.
3. Installation must be carried out in a properly equipped workshop, with the vehicle stationary, the engine switched off and the parking brake engaged.
4. In addition, refer to the safety instructions given in the instructions for the vehicle on which the product is to be installed.
5. Do not attempt to repair the device: if necessary, consult your reseller or qualified technical staff .
6. Take all necessary precautions and use personal protective equipment to avoid any injuries or damage to property.
7. When installation is complete, check that the work has been carried out correctly and according to the instructions in this manual.
8. Use only with a 12 VDC electrical system with a negative ground system.
9. Disconnect the negative terminal of the vehicle battery when making connections to the unit.
10. When replacing the fuse, use one of the same amperage.
11. Turn on the unit only after ensuring the temperature inside the passenger compartment has stabilised to a standard range.
12. Set the volume low enough so you can still hear sounds like car horns or emergency sirens while in the car.
13. Do not connect any cables in places where they could obstruct the operation of the car's safety devices.
14. Keep out of the reach of children.

INFORMATION AND TECHNICAL CHARACTERISTICS

FOREWORD

- This manual is for installers.
- Installation must be carried out by qualified personnel only.
- For any questions or doubts, please contact Phonocar S.p.A.
- Always adopt all appropriate safety measures to prevent injuries or damage to property.

DESCRIPTION

Media station for OEM system upgrade. It allows you to use all the features of the ANDROID operating system on the extra-large touchscreen monitor without limiting the use of the original operating system.



INTENDED USE

- Product intended for installation on BMW X1 F48 (2016-2017), X2 F39 (2018-2023) NBT.
- Any other use is to be considered improper and unpredictable.

TECHNICAL SPECIFICATIONS

- ANDROID 13 operating system.
- 64GB ROM memory.
- 4GB RAM.
- QUALCOMM SNAPDRAGON 665 OCTA-CORE CPU
- 12.3" capacitive touch screen LCD/IPS monitor.
- Resolution 1920×720 pixels.
- 2 rear USB Type-A ports
- 1 micro SD CARD slot
- 1 SIM CARD slot for 4G internet access WIFI.
- Bluetooth V5: Hands-free with external microphone and A2DP.
- GPS antenna.
- ONLINE navigation
- OFF-LINE navigation
- 1 rear camera input.
- Subwoofer output and Pre-out.
- 16-band equalizer.
- APP: Google Maps, YouTube, Chrome

PACKAGE CONTENTS



1. MULTIMEDIA SYSTEM
2. MULTIMEDIA SYSTEM SUPPORT
3. POWER WIRING HARNESS
4. USB CABLE
5. GPS ANTENNA
6. RCA CABLE
7. AUDIO CABLE
8. 4G ANTENNA
9. INSTRUCTION MANUAL

CONNECTIONS



1. 40 PIN FEMALE CONNECTOR (connect to OEM system)
2. 40 PIN MALE CONNECTOR (connect to the OEM radio connector)
3. 12V REAR VIEW CAMERA
4. GND REAR VIEW CAMERA
5. MIC
6. CVBS OUTPUT 1
7. CVBS OUTPUT 2
8. CVBS REAR CAMERA INPUT
9. AUX-R INPUT
10. AUX-L INPUT
11. AUDIO OUTPUT
12. GPS ANTENNA
13. CHAMBER ACTIVATION
14. AUX-R INPUT
15. AUX-L INPUT
16. 12V DVR
17. IR TV
18. IR DVR
19. GND
20. ACCTV
21. CVBS TV INPUT
22. CVBS DVR
23. 12V TV
24. USB OTG
25. USB
26. 4G ANTENNA

FIRST START-UP


ANDROID SYSTEM ACTIVATION

- Long press MENU key to switch between OEM system and ANDROID system.
- To return to the OEM system, long press the MENU key.




SYSTEM CONFIGURATION


A Enter the settings menu.




B Enter password: 2018.



C Screen Setting, select the OEM system screen from the drop-down menu.



D Audio setting.



DISPOSAL

The product is classified as waste electrical/electronic equipment. Comply with applicable regulations when disposing of the device. The product must not be dumped or disposed of with unsorted domestic waste

APPROVAL



ATTENTION

All images are included for illustrative purposes only. Phonocar S.p.A. reserves the right to make changes to the products even without notice. Any changes to the products are to be considered improvements and do not affect their functionality. All mentioned trademarks and reproduced logos belong to their legitimate owners and have been indicated for information purposes only.

CONTACT


- Phonocar S.p.A. Via F.lli Cervi 167/C
- 42124 Reggio Emilia (Italy)
- Tel. 0522 941621
- Fax 0522 1602093
- info@phonocar.it
- Export Office +39 0522 941243
- info@phonocar.eu
- phonocar.it

VIDEOS



Frequently Asked Questions

- **Q: How do I switch between the OEM and Android systems?**
 - A: Press and hold the MENU button to switch between the two systems.
- **Q: What is the default password for system configuration?**
 - A: The default password is 2018.
- **Q: What should I do before disposing of the product?**
 - A: Follow specific regulations for electronic device disposal to ensure proper handling.

	<p>Phonocar SM014 Retrofit Android 13 Screen [pdf] Installation Guide</p> <p>SM014, SM014 Retrofit Android 13 Screen, SM014, Retrofit Android 13 Screen, Android 13 Screen, 13 Screen, Screen</p>
---	---

References

- [User Manual](#)

Manuals+. [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.