

Plume F1A SuperPod with WiFi 6 Instruction Manual

Home » Plume » Plume F1A SuperPod with WiFi 6 Instruction Manual





F1A SuperPod with WiFi 6 **Instruction Manual**

Welcome to Plume Adaptive WiFi!

This short informative guide will familiarize you with the Plume Pod(s) setup. Additional help is available on Plume's website at https://support.plume.com/hc/en-us

Contents

- 1 Getting Started
- 2 Compliance
- **3 Product Information**
- 4 Documents /

Resources

- 4.1 References
- **5 Related Posts**

Getting Started

Before you use the Pod, please download the Plume WiFi app to your smartphone and follow the in-app 2-minute setup guide.

The Plume WiFi app can be downloaded on:

- App Store iOS
- Google Play Android or
- our website https://support.plume.com/hc/en-us/articles/235905827-Where-can-Idownload-the-Plume-

App




Step 1


- 1. Once the Plume Wifi is downloaded and successfully instal led.
- TAP "set up Plume WiFi" from the landing page

If you are having trouble, please co ntact us at: https://support.plume.com/hc/en-us

Step 2


Step 3








The Plume app will automatically advance once a second Pod is detected





Compliance

LEGAL

- Terms of use, privacy policy, and terms of sale can be found at: www.plumewifi.com/legal
- Regulatory compliance information, including EU and FCC Declaration of Conformity, can be found at: www.plumewifi.com/regulatory

- ALWAYS READ THE ONLINE USER MANUAL BEFORE SET UP OR USE.
- IT IS YOUR RESPONSIBILITY TO FAMILIARIZE YOURSELF WITH THE ONLINE USER MANUAL AND WARNINGS AND TO USE THE DEVICE PROPERLY.
- To prevent fire or electric shock hazards, keep away from rain or moisture. Clean only with a clean, dry cloth.
- Do not connect the plug to an extension cord, receptacle, or another outlet unless the plug can be fully inserted with no part of the blades exposed.
- The socket outlet shall be installed near the equipment and shall be easily accessible.
- Do not cover the device or block the airflow to the device. Do not expose the device to temperatures below freezing or above 95°F.
- The device may contain small parts and be otherwise hazardous to children. Keep out of reach of children.
- If the device malfunctions or fails to perform as expected, stop using it immediately.
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Double Insulation

This symbol indicates that this product incorporates double insulation between hazardous mains voltage and user-accessible parts. Earthing wire is therefore not necessary.

• For indoor use only

This electrical equipment is designed primarily for indoor use only

Product Information

FCC Regulations:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device for operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems; 5GHz band (W52, W53): Indoor use only (Except for the transmission with High Power Data Communication System Base Station or Relay Station) Japanese version: 5.2/5.3GHz Indoor use only Fixed (5.2GHz registration bureau and communication)

FCC RF Exposure Compliance

This equipment complies with radio frequency (RF) exposure limits adopted by the Federal Communications Commission for an uncontrolled environment. This equipment

should be installed and operated to ensure a minimum of 22 cm spacing to any person at all times. Your Plume Pod information is on file with FCC and can be found on the FCC website http://www.fcc.gov/oet/ea/ by searching the FCC ID on the device, which can be found on the bottom of the Plume Pod.

ISED Regulations:

This device complies with ISED applicable license-exempt RSS. Operation is subject to the following two conditions:

- 1. This device may not cause interference; and
- 2. This device must accept any interference, including interference that may cause undesired operation of the device.

CAN ICES-3(B)/NMB-3(B)

The device could automatically discontinue transmission in case of the absence of information to transmit or operational failure. Note that this is not intended to prohibit transmission of control or signaling information or the use of repetitive codes where required by the technology.

The device for operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;

In addition, high-power radars are allocated as primary users (i.e. priority users) of the bands 5250–5350 MHz and 5650–5850 MHz and these radars could cause interference and/or damage to LE-LAN devices.

ISED RF Exposure Compliance

This equipment complies with ISED RF exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated to ensure a minimum of 22 cm spacing to any person at all times.

EU Declaration Of Conformity:

The CE mark indicates this product is complied with the following EU directives and is in conformity with the relevant Union harmonization legislation:

RE Directive (2014/53/EU), RoHS Directive (2011/65/EU)

The following harmonized standards and/or other relevant standards have been applied:

- 1. Health and Safety (Article 3.1(a) of the RE Directive)
 - EN 62311:2008
 - EN 60950-1:2006/A11:2009+A1:2010+A12:2011+A2:2013
- 2. Electromagnetic compatibility (Article 3.1 (b) of the RE Directive)
 - EN 301 489-1 V2.1.1, EN 301 489-17 V3.1.1
- 3. Radiofrequency spectrum usage (Article 3.2 of the RE Directive)
 - EN 300 328 V2.1.1, EN 301 893 V2.1.1
- 4. RoHS Directive (2011/65/EU)
 - EN 50581:2012

The 5150 – 5350 MHz bands are for indoor use only. In according with article 10(10) this product is restricted to indoor use only bearing the following pictogram.

AT	BE	BG	HR	CY	CZ	DK	
EE	FI	FR	DE	EL	HU	IE	
IT	LV	LT	LU	MT	NL	PL	
PT	RO	SK	SI	ES	SE	UK(NI)	
IS	LI	NO	СН	TR			

RF Exposure Information (MPE)

This device meets the EU requirements and the International Commission on Non-Ionizing Radiation Protection (ICNIRP) on the limitation of exposure of the general public to electromagnetic fields by way of health protection. This equipment should be installed and operated to ensure a minimum of 20 cm spacing to any person at all times.

Maximum RF Transmit Power

Frequency Band	Power
Bluetooth 2402-2480 MHz	-0.4 dBm
WLAN 2412-2472 MHz	19.9 dBm
WLAN 5180-5240 MHz	22.98 dBm
WLAN 5260-5320MHz	22.98 dBm
WLAN 5500- 5700MHz	29.56 dBm

Hereby, Plume Design, Inc declares that the radio equipment type Plume Adaptive WiFi AP is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: https://www.plume.com/homepass/legal?tabld=websiteterms&countryld=us

North America

Plume Design Inc., 325 Lytton Ave., Palo Alto, CA 94301-USA 1-519-772-8720 Or 325 Lytton Ave., Palo Alto, CA 94301 **Europe** Plume Design D.O.O.

Železna Cesta 14 1000 Ljubljana, Slovenia



Plume F1A SuperPod with WiFi 6 [pdf] Instruction Manual F1A, 2AG7G-F1A, 2AG7GF1A, F1E, F1U, F1A SuperPod with WiFi 6, SuperPod with WiFi 6

References

- F© Equipment Authorization | Federal Communications Commission
- Plume Legal
- Website Terms

Manuals+,