

Polaris 4082137 Wireless Winch Remote Instructions

Home » Polaris » Polaris 4082137 Wireless Winch Remote Instructions

#### **Contents**

- 1 Polaris 4082137 Wireless Winch Remote
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 Wireless remote instruction
- **5 FCC Statement**
- 6 Documents / Resources
- 7 Related Posts



# Polaris 4082137 Wireless Winch Remote



#### **Product Information**

This product is a wireless remote control for controlling a winch operation. It is designed to provide convenience and flexibility in operating the winch remotely. The wireless remote control utilizes radio frequency energy to communicate with the winch, allowing the user to control the winch operation from a distance. The device has been evaluated to meet general RF exposure requirements, ensuring that it can be used in portable exposure

conditions without any restrictions. However, it is important to follow the instructions provided to minimize the risk of harmful interference to radio communications.

### **Product Usage Instructions**

#### Warning

Before using the wireless remote control, it is crucial to ensure that it is installed and used in accordance with the instructions to prevent harmful interference to radio communications.

#### **Wireless Start Indicator**

When the wireless mode is activated, the indicator light on the remote control will turn on.


#### **Winch Out Operation**

- 1. Ensure that the wireless mode is activated (indicated by the lit indicator light).
- 2. Press and hold the "Winch Out" button on the remote control to initiate the winch-out operation.

#### Winch In Operation

- 1. Ensure that the wireless mode is activated (indicated by the lit indicator light).
- 2. Press and hold the "Winch In" button on the remote control to initiate the winch in operation.

Remember to release the buttons once the desired winch operation is achieved. It is recommended to refer to the complete user manual for detailed instructions and safety precautions related to the installation and usage of the wireless remote control.



# Wireless remote instruction

### Warning

- If the winch is under load, the winch rope is under tension or the drum is in motion, do not engage or release the clutch
- Never place the winch remote control where it can be activated when the natural coil, drive, or capstan is not in
  use
- Never place a wireless winch remote in a place where it can be activated during installation, natural winding, driving, or servicing of a winch, or when the winch is not in use

• The wireless function is automatically turned off after 2 minutes without any operation• Remote control (4082137) operating voltage 3V, receiver operating voltage 12V. Frequency range 433-434MHz. Operating temperature: -40°C to 65°C

#### **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

## **RF Exposure Information**

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

#### **Documents / Resources**



Polaris 4082137 Wireless Winch Remote [pdf] Instructions 4082137, 2BBUI-4082137, 2BBUI-4082137, 4082137 Wireless Winch Remote, Wireless Winch Remote, Remote

Manuals+,