




## Power Dynamics PD ComboSet Series 1200 Active Sound System Instruction Manual

[Home](#) » [Power Dynamics](#) » Power Dynamics PD ComboSet Series 1200 Active Sound System Instruction Manual 



**PD ComboSet Series 1200/1500/1800**  
Ref. nr.: 178.660; 178.662; 178.664



## INSTRUCTION MANUAL

### Contents

- [1 PD ComboSet Series 1200 Active Sound System](#)
- [2 UNPACKING INSTRUCTION](#)
- [3 CONTROLS AND CONNECTIONS](#)
- [4 CONNECTING WITH BT](#)
- [5 REPLACING THE FUSE](#)
- [6 TECHNICAL SPECIFICATION](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)

## PD ComboSet Series 1200 Active Sound System

Congratulations to the purchase of this Power Dynamics product. Please read this manual thoroughly prior to using the unit in order to benefit fully from all features.

Read the manual prior to using the unit. Follow the instructions in order not to invalidate the warranty. Take all precautions to avoid fire and/or electrical shock. Repairs must only be carried out by a qualified technician in order to avoid electrical shock. Keep the manual for future reference.

- Prior to using the unit, please ask advice from a specialist. When the unit is switched on for the first time, some

smell may occur. This is normal and will disappear after a while.

- The unit contains voltage carrying parts. Therefore, do NOT open the housing.
- Do not place metal objects or pour liquids into the unit This may cause electrical shock and malfunction.
- Do not place the unit near heat sources such as radiators, etc. Do not place the unit on a vibrating surface. Do not cover the ventilation holes.
- The unit is not suitable for continuous use.
- Be careful with the mains lead and do not damage it. A faulty or damaged mains lead can cause electrical shock and malfunction.
- When unplugging the unit from a mains outlet, always pull the plug, never the lead.
- Do not plug or unplug the unit with wet hands.
- If the plug and/or the mains lead are damaged, they need to be replaced by a qualified technician.
- If the unit is damaged to such an extent that internal parts are visible, do NOT plug the unit into a mains outlet and DO NOT switch the unit on. Contact your dealer.
- To avoid fire and shock hazard, do not expose the unit to rain and moisture.
- All repairs should be carried out by a qualified technician only.
- Connect the unit to an earthed mains outlet (220-240Vac/50Hz) protected by a 10-16A fuse.
- During a thunderstorm or if the unit will not be used for a longer period of time, unplug it from the mains. The rule is: Unplug it from the mains when not in use.
- If the unit has not been used for a longer period of time, condensation may occur. Let the unit reach room temperature before you switch it on.
- Never use the unit in humid rooms or outdoors.
- To prevent accidents in companies, you must follow the applicable guidelines and follow the instructions.
- Do not repeatedly switch the fixture on and off. This shortens the lifetime.
- Keep the unit out of the reach of children. Do not leave the unit unattended.
- Do not use cleaning sprays to clean switches. The residues of these sprays cause deposits of dust and grease. In case of malfunction, always seek advice from a specialist.
- Do not force the controls.
- This unit is with speaker inside which can cause magnetic field. Keep this unit at least 60cm away from computer or TV.
- If this product has a built-in lead-acid rechargeable battery. Please recharge the battery every 3 months if you are not going to use the product for a long period of time. Otherwise, the battery may be permanently damaged.
- If the battery is damaged, please replace with same specifications battery. And dispose the damaged battery environment friendly.
- If the unit has fallen, always have it checked by a qualified technician before you switch the unit on again.
- Do not use chemicals to clean the unit. They damage the varnish. Only clean the unit with a dry cloth.
- Keep away from electronic equipment that may cause interference.
- Only use original spares for repairs, otherwise serious damage and/or dangerous radiation may occur.
- Switch the unit off prior to unplugging it from the mains and/or other equipment. Unplug all leads and cables prior to moving the unit.
- Make sure that the mains lead cannot be damaged when people walk on it. Check the mains lead before every use for damages and faults!
- The mains voltage is 220-240Vac/50Hz. Check if power outlet match. If you travel, make sure that the mains voltage of the country is suitable for this unit.

- Keep the original packing material so that you can transport the unit in safe conditions.



This mark attracts the attention of the user to high voltages that are present inside the housing and that are of sufficient magnitude to cause a shock hazard.



This mark attracts the attention of the user to important instructions that are contained in the manual and that he should read and adhere to.

The unit has been certified CE. It is prohibited to make any changes to the unit. They would invalidate the CE certificate and their guarantee!

**NOTE:** To make sure that the unit will function normally, it must be used in rooms with a temperature between 5°C/41°F and 35°C/95°F.



Electric products must not be put into household waste. Please bring them to a recycling centre. Ask your local authorities or your dealer about the way to proceed. The specifications are typical. The actual values can slightly change from one unit to the other. Specifications can be changed without prior notice.

Do not attempt to make any repairs yourself. This would invalid your warranty. Do not make any changes to the unit. This would also invalid your warranty. The warranty is not applicable in case of accidents or damages caused by inappropriate use or disrespect of the warnings contained in this manual. Power Dynamics cannot be held responsible for personal injuries caused by a disrespect of the safety recommendations and warnings. This is also applicable to all damages in whatever form.

## UNPACKING INSTRUCTION

**CAUTION!** Carefully unpack the box upon receipt. Check the contents to ensure that all parts are present and have been received in good condition. Notify the shipper immediately and retain packaging material if any parts appear damaged from shipping or the package itself shows signs of mishandling. Save the package and all packaging materials. If the product must be returned, it is important that the product is returned in the original factory box and packaging.

If the device has been exposed to drastic temperature fluctuation (e.g. after transportation), do not switch it on immediately. The arising condensation water might damage your device. Leave the device switched off until it has reached room temperature.


## POWERSUPPLY

On the label on the backside of the product is indicated on this type of power supply must be connected. Check that the mains voltage corresponds to this, all other voltages than specified, the light effect can be irreparably damaged. The product must also be directly connected to the mains and may be used. No dimmer or adjustable power supply.



Always connect the device to a protected circuit (circuit breaker or fuse). Make sure the device has an appropriate electrical ground to avoid the risk of electrocution or fire.

## CONTROLS AND CONNECTIONS



1. **SUBWOOFER VOLUME:** Control the volume level of the subwoofer.
2. **SATELLITE VOLUME:** Control the volume level of the satellite speakers.
3. **COMBO JACKS LINE IN:** Balanced stereo inputs with combo connectors.  
Use standard XLR or 6.3 mm jack cables to connect audio units with line level output (e.g. mixers or preamplifiers) to these inputs. When connecting a mono device, only use the left jack and depress the mono/stereo switch.
4. **XLR LINE OUTPUTS:** Balanced XLR jacks, connected in parallel to the inputs, to connect another device, e.g. a further active speaker system.
5. **BT PAIR BUTTON:** Push to set up pairing with BT-capable devices.
6. **RCA LINE INPUT:** Additional stereo input on unbalanced RCA jacks. Use a standard stereo RCA cable to connect a line-level device to this input. Use the SENSITIVITY switch to adjust the input level for the signal source.
7. **DSP PRESET:** Choose between Monitor, DJ and Live.
8. **MONO/STEREO:** Switch between mono and stereo.
9. **SENSITIVITY SWITCH:** To match the level for units with a low output level at the RCA inputs. With the button engaged, the input level is boosted by 5 dB.
10. **SPEAKER CONNECTORS:** High-pass filtered speaker jacks for connecting the left and right satellite speaker.
11. **POWER SWITCH:** Switch to turn the device ON or OFF.
12. **AC IN AND FUSE HOLDER:** Socket for plugging in the supplied power cord.

## CONNECTING WITH BT



1. Activate the BT-function on your device (Mobile phone, tablet etc.) from which you want to play the music. See the operating instructions for that device.
2. Press the "BT" button and activate BT-function.
3. Select "PD COMBOSET" on your BT-device and make the BT-connection


If password is required, you can enter “0000”.

**Attention:** The BT distance is approx. 10 meter without any barrier.

## REPLACING THE FUSE

If the fuse is defective, replace the fuse with a fuse of the same type and value. Before replacing the fuse, unplug mains lead.

### Procedure:



**Step 1:** Open the fuse holder on the rear panel with a fitting screwdriver.

**Step 2:** Remove the old fuse from the fuse holder.

**Step 3:** Install the new fuse in the fuse holder.

**Step 4:** Replace the fuse holder in the housing.

## TECHNICAL SPECIFICATION

	<b>PD Combo 1200</b>	<b>PD Combo 1500</b>	<b>PD Combo 1800</b>
Ref. Nr:	178.660	I 178.662	I 178.664
Input connections	6.3mm lack, RCA, XLR (3-pin)		
Output connections	NL-4, XLR (3-pin)		
Output power: max	1200W	1500W	1800W
Output power: rms	600W	800W	900W
Amplifier type	Class D		
Diameter tweeter	1"	1"	1.35"
Tweeter type	Dome		
Diameter woofer	12"	15"	18"
Magnet type	Ferrite		
Magnet weight	40oz	70oz	80oz
Voice coil	1.5"	3"	
Frequency response	40Hz-17KHz	35Hz-18KHz	32Hz-18KHz
Dispersion	90° x 60°		
Impedance	4ohm		
Crossover frequency	120Hz	80Hz	
SPL a 1W/1m	94dB	95dB	96dB
SPL max	119dB	120dB	123dB
Weight (kg)	33,40	42,60	57,20

The specifications are typical. The actual values can slightly change from one unit to the other. Specifications can be changed without prior notice.

The products referred to in this manual is conforming European and UK legislation directives to which they are subject:



**European Union**

Tronios B.V.,  
Bedrijvenpark Twente Noord 18,  
7602KR Almelo, The Netherlands

2014/35/EU  
2014/30/EU  
2014/53/EU  
2011/65/EC



**United Kingdom**  
Tronios Ltd.,  
130 Harley Street,  
London W1G 7JU, United Kingdom


S.I. 2016:1101  
S.I. 2016:1091  
S.I. 2017:1206  
S.I. 2012:3032

Specifications and design are subject to change without prior notice.


[www.tronios.com](http://www.tronios.com)

Copyright © 2022 by Tronios The Netherlands

## Documents / Resources

 <p>PD ComboSet Series 1200 178.660/178.662/178.664</p> <p>INSTRUCTION MANUAL GEBRUIKSAANWIJZING BEDIJNINGSAANWIJZING MANUAL DE INSTRUCCIONES MANUEL D'INSTRUCTIONS INSTRUCCIONES DE USO</p>	<p><a href="#">Power Dynamics PD ComboSet Series 1200 Active Sound System</a> [pdf] Instruction Manual 178.660, 178.662, 178.664, PD ComboSet Series, PD ComboSet Series 1200 Active Sound System, Active Sound System, Sound System</p>
---	--

## References

-  [Stibat](#)
-  [Stibat](#)
-  [Sound & Light distributor - Tronios.com](#)
-  [Inleveren is terugkrijgen - Wecycle](#)
-  [Inleveren is terugkrijgen - Wecycle](#)